

Toothbrush Charging Case User Guide



Instruction for Use:

The portable charging case is mainly used to charge the designated electric toothbrush, put the toothbrush in it directly, and it can be charged after plugging in the power supply. When the power indicator light on the toothbrush stops blinking, it means charging is complete

* Note: The toothbrush & brush heads are not included.

Important Notice:

Read all instructions carefully before use and save it for future reference.

Danger

Keep the charging case away from water. Do not place or store it over near water contained in a bathtub, washbasin, etc. Do not immerse the charging case in water or any other liquid. After cleaning and make sure the charging case is completely dry before connect it to the mains.

Warning

- Check the USB cord before you connect the local mains.
- Never use the charging case if it is damaged in any way. If the USB cable is damaged, always have it replaced with one of the original type in order to avoid a hazard.
- Do not use the charging case near heated surface and keep the appliance away from strong electromagnetic field when charging..

Specifications:

Model: 1741X

Charging Type: Wireless Charging

Rated Input: DC5V/400MA

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.