


USER MANUAL




Model:MA64191-6

WIRELESS CONVERTIBLE MOUSE

CAUTION: To use this device properly, please read the user's manual before installation.

CONNECTING THE MOUSE

1. Open the battery cover and insert 2 x AAA batteries (Not included).
2. Turn mouse on using the Right/Left switch found on the bottom.
3. Insert the USB nano receiver into your computer's USB port.



FEATURES

USB 2.4G Wireless Optical Mouse with interchangeable magnetic cover.
Additional magnetic cover allows for two colors options.
Compact design for ultimate portability.
Convenient USB receiver storage compartment hidden beneath mouse cover.
Scroll wheel for easy navigation.
Turn switch to RIGHT to use, or LEFT when storing product.

SPECIFICATIONS

Resolution: 1200DPI
Working Voltage: 3V
Working Current: < 20mA
Interface: USB Power save mode and Standby mode current: < 1mA
System Compatibility: Windows XP/VISTA/7/8/8.1/10/Mac OS
2*AAA alkaline batteries (Not included)
User Manual

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- consult the dealer or an experienced radio/TV technician for help

! WARNING:
CHOKING HAZARD--Small parts.

Not for children under 3 yrs.

This product contains small magnets. Seek immediate medical attention if magnets are swallowed or inhaled.

To claim your repair or replacement, contact product support at
1-800-425-0049.