


USER MANUAL




DOURADA™ CLASSIC WIRELESS OPTICAL MOUSE


CAUTION: To use this device properly, please read the user's manual before installation

CONNECTING THE MOUSE

1. Open the battery cover and insert 2 x AAA batteries (not included); Turn mouse on using the On/Off switch found on the bottom



2. Insert the USB nano receiver into your computer's USB port



FEATURES

Aluminum wireless optical mouse with 4 keys
Ergonomic design suitable for use in both hands
Compatible with computers featuring standard USB ports

SPECIFICATIONS

Resolution: 800/1200/1600 DPI

Wireless Range: 10M

Dimensions: 4.5" x 2.4" x 1.26"

Designed and distributed by indiCo, LLC
Oberlin, OH 44074 USA
DOURADA™ is a trademark of indiCo, LLC.,
and is registered in the U.S. and Canada.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.