

Anker A7910 Pocket Bluetooth Speaker

Package Contents

Anker A7910 Pocket Bluetooth Speaker
Micro USB charging cable (2.3 ft)
AUX to Micro USB audio cable (2.3 ft)
Welcome Guide

Product Features

- Ring-box size profile fits easily into your pocket, or the small side pocket of your backpack.
- Impressively full sound powered by a powerful 3 watt audio driver.
- 12 hours of play time significantly outlasts other Bluetooth speakers.
- Non-Bluetooth devices enjoy unhampered compatibility with the provided AUX to Micro USB audio cable.
- NFC compatibility enables easier pairing.
- Connects automatically to the last-connected device once powered on.

Specifications

Product Model	A7910
Bluetooth Standard	3.0
Product Weight	90 ± 5g / 3.2 ± 0.2oz
Product Size	45 × 45 × 45mm / 1.8 × 1.8 × 1.8in
Play Time	12 hours
Charge Time	1.5 hours
Input	5V / 1A
Operating Range	10m / 33ft
Speaker Output Power	3W
Audio Cable Type	AUX to Micro USB audio cable
Supported Bluetooth Profiles	A2DP, AVRCP

Product Overview

Power button
LED indicator
Micro USB charging & audio 2-in-1 port
NFC chip location

How to Turn On / Off the Speaker

Press the power button for 3 seconds to turn the speaker on or off.

How to Pair with Your Device

1. Press the power button for 3 seconds. The speaker will turn on and automatically enter pairing mode indicated by the flashing blue LED.
2. Activate your device's Bluetooth function and search for the device.
3. Once the Bluetooth speaker has been detected, select the product name "Anker A7910" to connect. (For devices with Bluetooth versions below 3.0, press "Yes" to confirm pairing. Enter a passkey or PIN code "0000" (4 zeros), then press the "Yes" or "OK" key to finish pairing.)
4. When the Bluetooth speaker and your device are successfully paired, the blue LED will go on and remain on while connected.

How to Pair with a NFC-Supportive Device

1. Press the power button for 3 seconds. The speaker will turn on and the indicator will start flashing

blue.

2. Enable your device's NFC function.
3. Put your device near the NFC chip location.
4. Click "Yes" on your device's screen to confirm Bluetooth connection.
5. When the Bluetooth speaker and your device are successfully paired, the blue indicator will go on and remain on while connected.

Note: When turning on the speaker, it will automatically connect to the last-connected device (Bluetooth function needs to be enabled). When pairing with an additional device, disable the Bluetooth function on the previous device, the speaker will automatically return to pairing mode. Then, repeat the pairing process.

How to Recharge

When the speaker's battery is low, the speaker will announce "Battery low", and the red battery indicator will flash for about 10 minutes.

1. Plug the Micro USB cable into the speaker's Micro USB charging port.
2. Insert the remaining end of the USB power wire into (a) a USB AC adapter (not included) connected to a wall socket, or (b) a charging computer USB port. A steady red battery indicator will show that it is charging.
3. The red battery indicator will go off when the speaker is fully charged.

LED Indicator Instructions

LED indicator	Meaning
Blue indicator rapidly flashing	Pairing mode
Steady blue indicator	Connected to a device
Red indicator flashing	Low Battery
Steady red indicator	Charging
Red indicator goes off	Fully charged

Usage Tips

1. Power off the speaker when not in use and before storing.
2. The operational range of the speakers may be influenced by obstructions, such as walls, pillars, etc. To ensure a stable connection, we recommend avoiding such obstructions whenever possible and/or shortening the distance during use.
3. To protect the long-term performance of the battery, please do not place the speaker in high temperatures above 140°F/60°C, such as in a hot vehicle or under direct sunlight.
4. Do not expose the speaker or any of its supplied parts to water or liquids.

FAQ and Solutions

1. Why can't the speaker connect to my device?

- a. Check to ensure your device's Bluetooth function is enabled.
- b. Make sure your device is within 3ft/1m of the speaker.
- c. Delete the pairing record(s) on the speaker or your device.

2. Can I use the speaker to play music while charging?

To protect the long-term performance of the battery, it is better to charge it when the speaker is turned off, especially when the battery is low.

3. Can I make or answer phone calls through the speaker?

No. The speaker does not feature a built-in microphone.

4. Why can't I connect by NFC?

- a. Make sure that your device supports NFC functionality.
- b. Keep your mobile device close to the NFC chip location of the speaker when attempting to connect.
- c. Disable the Bluetooth connection of the speaker to other devices.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.