



434*60mm

MINISO
BLUETOOTH SPEAKER
User Manual



MINISO life

Dear customers:
Thank you for choosing MINISO Portable Bluetooth Speaker. Please read this manual carefully before use for correct operation and better performance.



Speaker
Charging Cord

Caution

- Please store or use this product at normal temperature.
- Do not expose this product in the rain or humid environment.
- Do not throw it to avoid the damage caused by dropping.
- Do not disassemble, repair or modify this product.
- Built-in lithium battery. Please do not discard it carelessly or put it in fire to avoid danger.

Tip

- To prolong its service life and protect your health, please do not listen to music at high volume for a long time, so as not to injure your hearing.
- If malfunction occurs, please immediately shut off the power and unplug it to prevent damage to the speaker and other components.
- Please charge it in time when electricity shortage occurs to avoid influence to the transmission distance and connection of Bluetooth.

Button Functions

- Power Switch:** Push the switch to "ON" to boot, push the switch to "OFF" to shutdown.
- Audio Input Port:** Need an audio cable with 3.5 mm. Connect the audio cable to the port and insert the other end into the audio device.
- Power Input Port:** Insert the USB plug into the power supply to charge. It is fully charged if the indicator is off.
- TF Card Slot:** Insert the TF card with downloaded songs into the slot and the speaker reads and plays the songs in the TF card.
- Charging Indicator:** The speaker lights if it is low battery and then you need to charge it. The indicator turns red when charging and lights off when finish charging.
- Bluetooth Indicator:** When the speaker is started, the indicator turns on and slowly flashes. When it is waiting for connection, the indicator quickly flashes. When it is successfully pairing, the indicator keeps on. When it is playing music, the indicator slowly flashes.


MC Hole: Short press pause/play button to answer the call when a call is coming. You can talk through MC hole. Short press pause/play button to hang up when on the phone.

Pause/Play Button: Press pause/play button to pause/play when listening to the music. Long press pause/play button for 4s to disconnect Bluetooth.

Volume: Short press this button to volume up. Long press this button to switch to the next song.

Volume: Short press this button to volume down. Long press this button to switch to the previous song.

Mode Switch Button: Switch between TF card reading mode and Bluetooth mode.



Bluetooth Indicator
Charging Indicator
Power Switch
Audio Input Port
Power Input Port
TF Slot

Product Parameters

- Model No.: D39F
- Bluetooth Specification: RD48595
- Transmission Distance: 10m
- USB Charging Power: 500mA or 500mA
- Built-in Battery: 1200mAh
- Output Power: 3W
- Frequency Response: 100Hz~20KHz(±10dB)

Specifications

- Sensitivity: 4000V
- S/NR: 90dB
- Net Weight: 478.5g
- Product Size: 100x57x30mm


Common Problems & Solutions

Problems	Solutions
Failed to connect for many times	1. Check if the speaker is in working state, or just restart it. 2. If it still can't connect when restart the speaker many times, please turn off other Bluetooth devices.
Low sound or sound distortion occurs	1. Check the volume of Bluetooth device and adjust it to a suitable value. 2. Check whether device charge fully.
Speaker light is not on when the speaker is on Bluetooth status	1. Check if it is supported the operating range or there are any obstacles between the speaker and Bluetooth devices. 2. Remove the battery power is low, please charge it and connect.

Standard

Check if it is supported the operating range or there are any obstacles between the speaker and Bluetooth devices.

2. Remove the battery power is low, please charge it and connect.



FCC Statement:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, we encourage you to consult the manufacturer for one or more of the following solutions:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the manufacturer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not expressly approved by manufacturer could void your warranty or void the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from any authorized radio transmitter.
The device has been evaluated for most general RF exposure requirements. The device can be used up to the maximum exposure conditions without restriction.