







## M61F English Manual


### Package:

1. Bluetooth Speaker x 1 pc
2. Micro USB cable x 1 pc
3. 3.5mm Audio cable x 1 pc
4. User manual x 1 pc

### Function panel:




1.  : Power ON/Power OFF
2.  : Volume Down/ Last Track
3.  : Volume Up/Next Track
4.  : Play/Pause/BT disconnect







5.  : Hands Free/Switch Modes

6.  : DC 5V IN Charging Port





7.  : Aux in

8.  : SD card slot

### Bluetooth Mode:

1. Press and hold button  to turn the speaker ON/OFF. Under the Bluetooth mode, the LED light will be Blue, when the speaker is on, the LED light will keep flashing quickly.
2. Turn on the BT function of your mobile device to find "M61F" , then make speaker and mobile device connected. When it connected, the Blue LED light will keep lighting.
3. Press and hold button  to disconnect Bluetooth; Press button  to Pause or Play media. When playing, the Blue LED will flash slowly.
4. Press button  to decrease volume; press and hold it to play the last track.
5. Press button  to increase volume; press and hold it to play the next track.
6. When there is a coming call, press button  to answer it, then press it again to hang it up. Press and hold it to reject a coming call.

### AUX IN Mode:

1. After turn the speaker on, connect your mobile device with speaker via the audio cable, Under the AUX in mode, the LED light will be blue and keep bright.
2. Press button  to Pause or Play media
3. Press button  to decrease volume; press and hold it to play the last track.
4. Press button  to increase volume; press and hold it to play the next track.
5. When there is a coming call, press button  to answer it, then press it again to hang it

up. Press and hold it to reject a coming call.

6. Press and hold  to switch to Bluetooth mode.

### **SD card Mode:**

1. As long as you insert your SD card into the SD card slot, the speaker will turn into SD card mode and play automatically, when playing it will flash quickly.

2. Press button  to Pause or Play media

3. Press button  to decrease volume; press and hold it to play the last track.

4. Press button  to increase volume; press and hold it to play the next track.

**Pls. Note, under SD card mode, mode switching and hands free function is not available.**

### **Charging:**

The speaker is with built in rechargeable battery, before using it, please make it full charged using the USB cable. During the charging time, the LED light next to the charging port will be red, and it will turn off when the speaker is full charged. It will make 2-3 hours to make the speaker full charged.

### **CAUTION:**

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.

the battery shall not be exposed to excessive heat such as sunshine, fire or the like

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,

may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.