




USER GUIDE




Product Specifications
 Model : CT170509
 Power Output : 5W X 1
 SNR : ≥70dB
 Frequency : 20HZ-20KHZ
 Power Supply : DC5V
 Horn : 4Ω
 Bluetooth v4.2
 Battery : 400mAh
 Size : 58*58*62mm




1.OPEN
 Put switch to "ON" to open the power.




2.SEARCHING
 Open your Phone and search the Bluetooth.



3.Recognition name
 Click our Bluetooth recognition name, then connect the speaker.



4.Play music
 When Bluetooth is connected, you can use your phone play music.




5.LED Light
 Press once "LIGHT" to change the monochrome light. Press 5 seconds "LIGHT" to turn into colorful light.



6.Switch / sound
 Short press "+" to turn up/turn down the volume. Long press "+" to switch to next/last song.




7.Pause/call
 Press once "CALL" to answer the phone. Press twice "CALL" to call the last phone number.



8.Charging
 Use the Micro cable to charge.



9.Line
 Use the 3.5mm AUX cable to play music by linking to mobile phones



10.OFF
 Push switch to "OFF" to turn off the power.

SAFETY CAUTIONS:

- Please read the instructions carefully before using.
- Avoid touch with liquids; keep away from water and out of damp conditions.
- Do not be located the speaker or cord near heat sources such as radiators, heaters, air ducts, or direct sunlight.
- Do not place a naked flame source such as candles on the mini Speaker.
- Recharge the battery with suitable voltage output (5V/400mAh).
- Do not hit the product severely or insert any conductive objects into the speaker/ charging jack.
- Do not block the speaker grill when the speaker is running.
- Stop using at once if it becomes hot, smoke, burning smell, non-normal noise, or fire is noticed coming from product.
- Do not repair on your own. Seek the help of a professional.
- To avoid electrical shock. Do not touch product with wet hand.
- Keep out of reach of children.
- Never store or use this product in temperatures below 32°F (0°C) or above 115°F (45°C)

TROUBLESHOOTING

No Sound:

- Audio cable is not fully plugged into the 3.5mm audio part on Device.
- Audio cable is damaged.
- Source of audio is not working.
- No LED Indication when audio cable is plugged.
- Mini speaker is out of power.

No Charge:

- Input power source is not normal.(5V/400mAh)
- Charging cable is not fully plugged into the charging port.
- Charging cable is damaged.
- Battery failure

NO LED Indication:

- LED indication failure.
- No battery power left.
- Charging cable is not fully plugged into the socket.

Manual for Bluetooth speaker

This mini audio box can be deemed as perfect Combination of classical and modern performance. New aluminum vibration film loud speaker which has clear alt and pure woof, that you can take with you enjoy anywhere.

FEATURES:

- Portable Speaker for your smartphone, tablet, laptop, or MP3 Player.
- Lightweight, small in size but incredible sound.
- Metal housing provides protection and a great sound.
- UP to 2-3 hours playback time with full charge.

Components included

- Mini speaker
- 3.5mm Audio+Micro USB charging combination cable
- User manual

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1)This device may not cause harmful interference, and
 (2)This device must accept any interference received, including interference that may cause undesired operation.

Warning:
 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID : 2ABHA0025

Made in China

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction