

# Bluetooth Earbuds

## Instruction Manual

### 7198-42

1. Phone/music Button
2. Next/Previous song (Volume Up+/Down-) Button
3. LED Indicator
4. Charging Port

### What's included:

- 1 x Bluetooth Earbuds
- 1 x USB to Micro-USB charging cable
- 1 x Instruction Manual

### Technical Specifications:

- Rated output: 3mW
- Max. output: 10mW
- Frequency response: 20Hz-20kHz
- Built-in 55mAh/3.7V lithium polymer battery in each earbud
- Charging input: 5V/0.055A

It takes 2 hours to recharge from 0 to 100%.  
Playback at max. volume: up to 2 hour.

### LED Indicators:

- Solid Red: Earbuds are being charged
- Red LED turned off: Charging complete

### Bluetooth Set Up:

- During the connection process the Right and Left channel will be indicated.
- Search the possible Bluetooth connections from a Bluetooth enabled device. Select pairing name "7198-09" from list of available devices.
- Once selected, the Earbuds will announce "connected." You may now play audio.

### Phone/music Button Function:

- Short press phone/music button: Play/Pause,
- Long press +/- button: Next/Previous song
- Short press +/- button: volume up/down

### Phone Functions:

When a phone call comes in while the Earbuds are connected:

- Press and hold the Phone/music button to reject
- Press once to answer
- Press once to hang up when finishing the call

### SAFETY PRECAUTIONS:

1. Please read all the instructions carefully before using the product.
2. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.
3. To reduce the risk of injury, close supervision is necessary when the product is used near children.
4. Do not expose the device to moisture.
5. Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
6. Do not use the device if damaged or modified. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire, explosion or risk of injury.
7. Do not disassemble the device. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or
8. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 212°F/100°C may cause explosion.
9. Have servicing performed by a qualified repair person using only identical replacement parts.
10. This will ensure that the safety of the product is maintained.

### FCC Statement:

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide

reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1)This device may not cause harmful interference, and(2)This device must accept any interference received, including interference that may cause undesired operation.