


Lantern Speaker Instruction Manual SL332



Functions:

1. Micro-USB charging port
2. Charging LED Indicator
3. Vol-/Previous Track
4. Lantern ON/OFF button
5. Play/Pause/ON/OFF
6. Vol+/Next Track
7. Bluetooth LED Indicator
8. Lantern

What's included:

- 1 x Speaker
- 1 x USB to Micro-USB Charging Cable
- 1 x Instruction Manual

Tech Specifications

Model: SL332
 Item No.: BC20789
 Input: DC 5V/2A
 Battery capacity: 3.7V/3600 mAh
 Speaker output power: 3W

Instructions:

(Be sure to fully charged the speaker before using for the first time).

1. Charging the Speaker

- Connect the provided charging cable to a power source and micro USB port on the speaker (1). The LED indicator will flash red when charging and turned into solid when fully charged.

2. Pairing Setup:

- Long press the Play/Pause/ON/OFF button (5), the Bluetooth LED Indicator (8) will flash blue. Turn on the Bluetooth function on mobile device, select "BC20789" pairing name, the

LED will flash blue slowly if it is successfully paired.

- Speaker will automatically pair if the mobile device has been paired before.
 - Long press the Play/Pause/ON/OFF button (5) again to turn off the speaker.
- 3. Playing Music:**
- Short press "Play/Pause" key to pause or Play music.
 - "Vol+/Next track":
 Short press - next track.
 Long press - increase volume.
 - "Vol-/Previous track":
 Short press - previous track
 Long press - reduce volume
- 4. Lantern:**
- Short press Lantern ON/OFF button sequentially to enable the "High lightness" → "Low lightness" → "Flash" → "Lantern off".
 - Long press Lantern ON/OFF button to turn on the SOS function.

5. To reduce the risk of injury, close supervision is necessary when the product is used near children.
6. Do not expose the device to moisture.
7. Do not use the device in excess of its output rating. Overload outputs above rating may result in a risk of fire or injury.
8. Do not use the device if damaged or modified.
9. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
11. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 113°F may cause explosion.
12. Ensure that qualified service professionals use only identical replacement parts to ensure product safety

SAFETY PRECAUTIONS:

- WARNING-When using this product, basic precautions should always be followed:
 1. Read all the instructions before use.
 2. Never store or use this product in temperatures below 32°F(0°C) or above 113°F(45°C).
 3. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.
 4. The unit's full performance is achieved only after 2 or 3 completed charge and discharge cycles.

FCC Statement:

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

Front

(1) However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- (2)- Reorient or relocate the receiving antenna.
 - (3)- Increase the separation between the equipment and receiver.
 - (4)- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - (5)- Consult the dealer or an experienced radio/TV technician for help
- To assure continued compliance, any changes or modifications not expressly approved by the party Responsible for compliance could void the user's authority to operate this equipment.
- This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

How to Use Correctly?



MADE IN CHINA

Back