


H288 (2.4G) 键盘使用说明书

1: 将 MINI 接收器插入电脑 USB 口 (MINI 接收器在键盘的底部收藏盒), 如图



2: 将 2 节 3A 电池放入键盘的收藏盒 (注意正负极), 盖上收藏盒的盖子。点击键盘任何一个字母, 键盘与 MINI 接收器都可以连接。连接之后, 你就可以使用的你无线键盘了。如果发现连接不上时, 你可以拔出 MINI 接收器, 按住键盘 ESC+Q 不松手, 指示灯红色闪烁, 然后再将 MINI 接收器插入电脑 USB 口, 当指示灯不闪时, 松开 ESC+Q 键, 说明键盘与 MINI 接收器已经连接上了, 这样你可以使用你的无线键盘了。



1: Plug the MINI receiver into the USB port of the computer (the MINI receiver is in the collection box at the bottom of the keyboard), as shown in the figure.



2: Put 2 3A batteries into the collection box of the keyboard

(pay attention to the positive and negative poles) and cover the collection box. Click any letter of the keyboard, and the keyboard and MINI receiver can be connected. After connecting, you can use your wireless keyboard. If you find that you can't connect, you can pull out the MINI receiver, hold down the keyboard ESC+Q, the indicator light flashes red, and then insert the MINI receiver into the USB port of the computer. When the indicator light doesn't flash, release the ESC+Q key, indicating that the keyboard and MINI receiver have been connected, so that you can use your wireless keyboard.



FCC Warning Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.