



Bluetooth receiver


MODEL NO. : BTR

Product Overview

EQ Button:
<Tap>-Dynamic Music mode/Clear
Voice mode/Clear Voice Plus
mode/Bass Boost mode



3.5 Female Plug
ON/OFF Key



Volumn Up/Skip Track Button
<Tap>-Increase Volume
<Hold 2 Sec>-Next Track

Multifunction Button
<Hold 2 Sec>-Pairing
<Tap>-Play/Pause (during media
palyback)

<Tap>-Answer Incoming Call/End
Call
<Hold 1 sec>-Reject Call (during
incoming call)

<Double Tap>-Redial

<Hold 1 Sec>-Activate Siri/Voice
Command

Volumn Down/Previous Track Button
<Tap>-Decrease Volume
<Hold 2 Sec>-Previous Track



Installing Earphone

Attach the earphone by aligning the 3.5 male plug with the receiver and push them in until they “click”. Pull them pack slightly on each connector to make sure it is fitted securely.

Pairing

Push the ON/OFF button to the "On" Place.

Press the hold the Multifunction button for about 2 seconds until you hear the headset say "Pairing" and the light flashes red and blue.

Open the Bluetooth menu on the device you wish to pair (usually located in Settings > Bluetooth). If needed, select "search for devices", "add new device", or "refresh"

Select "MEE audio BTR" and allow pairing to complete. Use "0000" if a pin is required.



Charging

Connect the Micro-USB charging cable to any powered USB port and to the charging port of the BTR. The status indicator light will go off once the BTR is charged and ready for use. Close the USB port completely after charging for maximum sweat resistance.

Factory Reset

To perform a full reset, first put the BTR in standby mode (receiver is powered on but not connected to any devices). Make sure to turn off Bluetooth or delete the "MEE audio BTR" pairing from any nearby devices that have previously been paired with the BTR.

Once in standby mode, press and hold the Multifunction and EQ buttons simultaneously until you hear the receiver say "Factory reset complete" "Pairing". All previously paired devices will be cleared from memory and a new pairing will need to be created before the BTR can be used.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.