

SPECIFICATIONS

| | |
|---------------------------|--------------------------|
| Product Dimension: | 45mm(L)x25mm(W)x3.3mm(T) |
| Weight: | 5.5g (with battery) |
| Button: | 1 button |
| Led Indication: | Green LED |
| Sound: | Buzzer |
| Range: | 50m |

POWER SOURCE

| | |
|----------------------|------------------------------------|
| Battery: | CR2016 battery |
| Battery Life: | Up to 6 months, depending on usage |

SYSTEM REQUIREMENTS

| | |
|---------------------|--|
| iOS Devices: | Devices with Bluetooth 4.0 (iPhone 4S, iPhone 5, iPhone 5C, iPhone 5S, iPad Mini 1st and 2nd gen, iPad 3rd and 4th gen, iPad Air and iPod touch 5th gen) |
| iOS Version: | iOS 6 and iOS 7 |
| Features: | Pocket, Sharing, Phone Finder, Reminder, Location/Map, TagGo Finder |

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

Questions about TagGo ?

support@d-toi.com



Version 1

© 2014 Systech Electronics Ltd. All rights reserved.

TagGo

QUICK START GUIDE




D + OI

Thanks for purchasing TagGo.

Before using the product, please read the safety information below carefully.

- The product is not waterproof. Do not use or store this product near any source of water.
- Do not use or store this product near any heat source or in direct sunlight.
- Do not attempt to disassemble or modify the device, which may result in malfunction or damage to the product.
- Not recommended for children under 3 years of age.

How to wake up TagGo

Wake up TagGo by pressing the button  on the back and you will see a flash of green light.

(will stay awake for 30 seconds, if not paired with a phone during that time, it will go back to sleep)



How to change battery

Pull the battery out from the slot and replace with a new one.

Under the environment with electrostatic discharge, the TagGo may malfunction and require user to reset the TagGo.



Place the battery with positive side up

Set up your TagGo

Step 1

Go to the App store and download the app "TagGo App".

Step 2


Once the App is installed, create an account on the App. Then you are ready to add a TagGo to your account.

Step 3

On the App, tap the Add TagGo icon .



Step 4

Press the  button to wake up your TagGo (will stay awake for 30 seconds)

Step 5

The App will begin to search for TagGo. Once it is found, just click on the TagGo number to add.



Step 6

Choose / Take a photo to represent the TagGo and you can customize the name.

Click when you are finished. You are now done with Set up.

