



Uses Manual

1, Power on : Press “” for a while ,LED light on .


2,LINE IN (AUX) Mode : After LED light on , using 3.5 audio jack plug into Blue-tooth speaker ,another 3.5 audio jack plug into your mobile or other playback devices .Then open playback devices can play music .

For short press “” is mute . Press “-/+” can adjust "volume".

For short press “” can switch to Bluetooth /LINE IN/TF card .


3, TF card Mode: After LED light on ,plug into TF card with MP3 songs.



For short press “” is Pause /play .Press can adjust "volume".

For short press “” can switch to Bluetooth /LINE IN/TF card .

4,Bluetooth mode :After LED light on ,open your mobile Bluetooth connect with Bluetooth speaker .

For short press “” is Pause / play . .Press “-/+” can adjust "volume".

For short press “” can switch to Bluetooth /LINE IN/TF card .

Free call answer : incoming calls ,short press “” can answer the phone (you can speak through Bluetooth speaker's mic) . After finish calls , short press “” can end the calls .

Press “-/+” can adjust "volume".

5 , AUTO POWER OFF

A : In Bluetooth condition ,if do not connect with mobile, it will power off after 6 minutes .

B :In TF CARD OR LINE IN condition,without any operations ,it will power off after 6 minutes .

How to connect with Bluetooth

1, Open mobile phone's Bluetooth , search Bluetooth speaker devices "H8G" and connect with it . IF need code , then inter "0000"

FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates,

uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is

encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.