



















Conducted RF Spurious Emission

Condition	Mode	Frequency (MHz)	Antenna	Max Value (dBc)	Limit (dBc)	Verdict
NVNT	ac20	5500	Ant1	-30.71	-27	Pass
NVNT	ac20	5600	Ant1	-29.06	-27	Pass
NVNT	ac20	5700	Ant1	-35.21	-27	Pass
NVNT	ac20	5500	Ant2	-29.86	-27	Pass
NVNT	ac20	5600	Ant2	-30.08	-27	Pass
NVNT	ac20	5700	Ant2	-30.14	-27	Pass
NVNT	ac20	5500	Ant3	-29.66	-27	Pass
NVNT	ac20	5600	Ant3	-29.28	-27	Pass
NVNT	ac20	5700	Ant3	-29.57	-27	Pass
NVNT	ac20	5500	Ant4	-29.75	-27	Pass
NVNT	ac20	5600	Ant4	-27.73	-27	Pass
NVNT	ac20	5700	Ant4	-29.63	-27	Pass
NVNT	ac40	5510	Ant1	-34.74	-27	Pass
NVNT	ac40	5590	Ant1	-30.88	-27	Pass
NVNT	ac40	5670	Ant1	-28.39	-27	Pass
NVNT	ac40	5510	Ant2	-30.33	-27	Pass
NVNT	ac40	5590	Ant2	-29.88	-27	Pass
NVNT	ac40	5670	Ant2	-30	-27	Pass
NVNT	ac40	5510	Ant3	-29.65	-27	Pass
NVNT	ac40	5590	Ant3	-29.92	-27	Pass
NVNT	ac40	5670	Ant3	-29.1	-27	Pass
NVNT	ac40	5510	Ant4	-29.88	-27	Pass
NVNT	ac40	5590	Ant4	-30.02	-27	Pass
NVNT	ac40	5670	Ant4	-29.45	-27	Pass
NVNT	ac80	5530	Ant1	-35.06	-27	Pass
NVNT	ac80	5610	Ant1	-33	-27	Pass
NVNT	ac80	5530	Ant2	-29.36	-27	Pass
NVNT	ac80	5610	Ant2	-29.17	-27	Pass
NVNT	ac80	5530	Ant3	-29.17	-27	Pass
NVNT	ac80	5610	Ant3	-30.05	-27	Pass
NVNT	ac80	5530	Ant4	-29.74	-27	Pass
NVNT	ac80	5610	Ant4	-27.15	-27	Pass
NVNT	ac160	5570	Ant1	-35.44	-27	Pass
NVNT	ac160	5570	Ant2	-30.21	-27	Pass
NVNT	ac160	5570	Ant3	-29.04	-27	Pass
NVNT	ac160	5570	Ant4	-29.99	-27	Pass
NVNT	ax160	5570	Ant1	-29.02	-27	Pass
NVNT	ax160	5570	Ant2	-30.49	-27	Pass
NVNT	ax160	5570	Ant3	-30.5	-27	Pass
NVNT	ax160	5570	Ant4	-29.04	-27	Pass

NVNT	ax20	5500	Ant1	-35.92	-27	Pass
NVNT	ax20	5600	Ant1	-35.4	-27	Pass
NVNT	ax20	5700	Ant1	-33.08	-27	Pass
NVNT	ax20	5500	Ant2	-29.3	-27	Pass
NVNT	ax20	5600	Ant2	-29.47	-27	Pass
NVNT	ax20	5700	Ant2	-29.4	-27	Pass
NVNT	ax20	5500	Ant3	-38.87	-27	Pass
NVNT	ax20	5600	Ant3	-30.55	-27	Pass
NVNT	ax20	5700	Ant3	-30.09	-27	Pass
NVNT	ax20	5500	Ant4	-29.65	-27	Pass
NVNT	ax20	5600	Ant4	-29.38	-27	Pass
NVNT	ax20	5700	Ant4	-29.93	-27	Pass
NVNT	ax40	5510	Ant1	-32.49	-27	Pass
NVNT	ax40	5590	Ant1	-35.15	-27	Pass
NVNT	ax40	5670	Ant1	-34.22	-27	Pass
NVNT	ax40	5510	Ant2	-29.01	-27	Pass
NVNT	ax40	5590	Ant2	-29.79	-27	Pass
NVNT	ax40	5670	Ant2	-29.97	-27	Pass
NVNT	ax40	5510	Ant3	-29.66	-27	Pass
NVNT	ax40	5590	Ant3	-29.81	-27	Pass
NVNT	ax40	5670	Ant3	-30.46	-27	Pass
NVNT	ax40	5510	Ant4	-29.86	-27	Pass
NVNT	ax40	5590	Ant4	-30.01	-27	Pass
NVNT	ax40	5670	Ant4	-30.17	-27	Pass
NVNT	ax80	5530	Ant1	-35.39	-27	Pass
NVNT	ax80	5610	Ant1	-35.75	-27	Pass
NVNT	ax80	5530	Ant2	-29.95	-27	Pass
NVNT	ax80	5610	Ant2	-29.98	-27	Pass
NVNT	ax80	5530	Ant3	-29.88	-27	Pass
NVNT	ax80	5610	Ant3	-30.05	-27	Pass
NVNT	ax80	5530	Ant4	-29.6	-27	Pass
NVNT	ax80	5610	Ant4	-29.91	-27	Pass
NVNT	ac20	5500	Ant5	-33.83	-27	Pass
NVNT	ac20	5600	Ant5	-35.35	-27	Pass
NVNT	ac20	5700	Ant5	-35.08	-27	Pass
NVNT	ac20	5500	Ant6	-29.45	-27	Pass
NVNT	ac20	5600	Ant6	-29.49	-27	Pass
NVNT	ac20	5700	Ant6	-29.45	-27	Pass
NVNT	ac20	5500	Ant7	-29.29	-27	Pass
NVNT	ac20	5600	Ant7	-30.46	-27	Pass
NVNT	ac20	5700	Ant7	-29.6	-27	Pass
NVNT	ac20	5500	Ant8	-29.81	-27	Pass
NVNT	ac20	5600	Ant8	-30.05	-27	Pass
NVNT	ac20	5700	Ant8	-29.68	-27	Pass

NVNT	ac40	5510	Ant5	-34.91	-27	Pass
NVNT	ac40	5590	Ant5	-35.58	-27	Pass
NVNT	ac40	5670	Ant5	-35.38	-27	Pass
NVNT	ac40	5510	Ant6	-29.83	-27	Pass
NVNT	ac40	5590	Ant6	-30.06	-27	Pass
NVNT	ac40	5670	Ant6	-29.24	-27	Pass
NVNT	ac40	5510	Ant7	-29.78	-27	Pass
NVNT	ac40	5590	Ant7	-30.01	-27	Pass
NVNT	ac40	5670	Ant7	-30.43	-27	Pass
NVNT	ac40	5510	Ant8	-29.7	-27	Pass
NVNT	ac40	5590	Ant8	-29.32	-27	Pass
NVNT	ac40	5670	Ant8	-29.49	-27	Pass
NVNT	ac80	5530	Ant5	-35.86	-27	Pass
NVNT	ac80	5610	Ant5	-34.93	-27	Pass
NVNT	ac80	5530	Ant6	-29.98	-27	Pass
NVNT	ac80	5610	Ant6	-29.82	-27	Pass
NVNT	ac80	5530	Ant7	-30.23	-27	Pass
NVNT	ac80	5610	Ant7	-29.86	-27	Pass
NVNT	ac80	5530	Ant8	-29.88	-27	Pass
NVNT	ac80	5610	Ant8	-29.41	-27	Pass
NVNT	ac160	5570	Ant5	-34.99	-27	Pass
NVNT	ac160	5570	Ant6	-29.65	-27	Pass
NVNT	ac160	5570	Ant7	-29.69	-27	Pass
NVNT	ac160	5570	Ant8	-29.33	-27	Pass
NVNT	ax160	5570	Ant5	-34.27	-27	Pass
NVNT	ax160	5570	Ant6	-30.21	-27	Pass
NVNT	ax160	5570	Ant7	-29.91	-27	Pass
NVNT	ax160	5570	Ant8	-29.44	-27	Pass
NVNT	ax20	5500	Ant5	-34.7	-27	Pass
NVNT	ax20	5600	Ant5	-29.44	-27	Pass
NVNT	ax20	5700	Ant5	-34.53	-27	Pass
NVNT	ax20	5500	Ant6	-29.97	-27	Pass
NVNT	ax20	5600	Ant6	-29.59	-27	Pass
NVNT	ax20	5700	Ant6	-28.05	-27	Pass
NVNT	ax20	5500	Ant7	-29.31	-27	Pass
NVNT	ax20	5600	Ant7	-29.75	-27	Pass
NVNT	ax20	5700	Ant7	-28.01	-27	Pass
NVNT	ax20	5500	Ant8	-27.95	-27	Pass
NVNT	ax20	5600	Ant8	-29.3	-27	Pass
NVNT	ax20	5700	Ant8	-29.23	-27	Pass
NVNT	ax40	5510	Ant5	-34.85	-27	Pass
NVNT	ax40	5590	Ant5	-33.88	-27	Pass
NVNT	ax40	5670	Ant5	-32.25	-27	Pass
NVNT	ax40	5510	Ant6	-30.4	-27	Pass

NVNT	ax40	5590	Ant6	-29.52	-27	Pass
NVNT	ax40	5670	Ant6	-29.57	-27	Pass
NVNT	ax40	5510	Ant7	-29.64	-27	Pass
NVNT	ax40	5590	Ant7	-30.17	-27	Pass
NVNT	ax40	5670	Ant7	-29	-27	Pass
NVNT	ax40	5510	Ant8	-30.13	-27	Pass
NVNT	ax40	5590	Ant8	-29.69	-27	Pass
NVNT	ax40	5670	Ant8	-29.57	-27	Pass
NVNT	ax80	5530	Ant5	-32.83	-27	Pass
NVNT	ax80	5610	Ant5	-31.15	-27	Pass
NVNT	ax80	5530	Ant6	-29.93	-27	Pass
NVNT	ax80	5610	Ant6	-29.62	-27	Pass
NVNT	ax80	5530	Ant7	-29.82	-27	Pass
NVNT	ax80	5610	Ant7	-30.07	-27	Pass
NVNT	ax80	5530	Ant8	-29.7	-27	Pass
NVNT	ax80	5610	Ant8	-29.88	-27	Pass





















































