

## **User manual Supplementary information**

- a) Trace layout and dimensions including specific designs for each type:
  - 1. Layout of trace design, parts, antenna, connectors, and isolation requirements:




2. Boundary limits of size, thickness, length, width, shape(s), dielectric contain, and impedance must be clearly described for each type of antenna:

PCB Antenna trace antenna Dimension:








Note: 1. RF trace between module RF pinout to antenna width is 0.6mm. 2. RF trace between module and antenna impedance is 0ohm.

## IPEX connector information:

Connector 1	IPEX	Male	50Ω	Surface mount	varies	Size:
		pin				İ



## b) Appropriate parts of manufacturers and specifications:

Information about devices on RF lines:

Parts list	Parts number	Size	Manufacturer
Tuning 1/0Ω	/	0201	varies

If customers completely refer to our antenna design for their own design, the antenna performance should also be the same as ours.

## C) Test procedures and design verifications:

Customer product development and design

- > Must copy the RF traces of the DXF file on the board completely. Follow up PCB design rule and PCB stack.

- -> Design Input
- -> Review customer design

RF circuit matching and components selection confirmation

-> Design output

Process monitoring need for improvement

- > Customer Validate the design until it satisfies the needs and FCC/IC requirements

Successfully validated design goes for production

d) Production test procedures for ensuring compliance

