

DR-1226-TX Manual

Ground stake with timer

Type: DR-1226-TX

1. plugged, indicate light shows OFF




2. According to the MANUAL button, indicate light shows ON




Outlets are working

3. Press the transmitter on the OFF button indicate light shows OFF




Outlets are stop working

4. Press the transmitter on the ON button indicate light shows ON




Outlets are working

5. Press the transmitter on the D/W button, indicate light shows ON and D/D




when the sky turn dark or in dim light, the outlets will start to work within 4~6 seconds. When the sky turn bright or in bright light, the outlets will power off within 8~10 seconds.

6. Press the transmitter on the 1HR button, indicate light shows ON and 1HR




It means the outlets will start to working for 1 hours when the sky turn dark or in dim light

7. Press the transmitter on the 2HR button, indicate light shows ON and 2HR




It means the outlets will start to working for 2 hours when the sky turn dark or in dim light

8. Press the transmitter on the 4HR button, indicate light shows ON and 4HR




It means the outlets will start to working for 4 hours when the sky turn dark or in dim light

9. Press the transmitter on the 6HR button, indicate light shows ON and 6HR



It means the outlets will start to working for 6 hours when the sky turn dark or in dim light

10. Press the transmitter on the 8HR button, indicate light shows ON and 10HR



It means the outlets will start to working for 8 hours when the sky turn dark or in dim light

DR-1226 Manual

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However,

there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.