

# **USER MANUAL**

---

PROFESSIONAL BATTERY TROLLEY SPEAKER

**Please read this user manual carefully before system connection**

**THANK YOU FOR PURCHASING OUR SPEAKER. PLEASE READ THE MANUAL CAREFULLY BEFORE OPERATING.**

## **IMPORTANT SAFETY MEASURES**

Before using this unit, please read all the safety and operating instructions. Please adhere to all the instructions herein, and keep the instruction manual in a safe place for future reference.



1. Please ensure the power cord for this unit is out of the path of foot traffic. Do not place heavy objects on the power cord as it will cause damage to the cord. Avoid the use of an extension cable.
2. Ventilation: This unit should be placed in a well ventilated space where it has no less than 10cm ventilation space on either side of it. Do not cover the unit with a cloth or blanket. Do not put it on a bed, sofa or carpet as this will stifle the ventilation.
3. Casing Dismantling: **DO NOT** dismantle the casing . There are no usable parts inside the unit. Make use of a service center in order to have your unit repaired.
4. Should the unit emit any smell or smoke, immediately turn off the power supply. Take the unit to the service center from which you bought it for repairs.

## **FEATURES**

- Bluetooth & TWS function
- Plays Mp3 files stored on SD cards/USB drives/external audio devices
- FM radio & Recording
- Remote control
- Guitar & Microphone inputs
- 5 Band graphic equalizer
- Built-in 12V/7A rechargeable battery
- Microphone priority on/off switch

## **CONNECTION**

1. This unit applies to AC 110V-240V~50/60Hz.
2. AC Power: The battery will charge when it is connected to the AC power. The red light indicates it is charging. The green light indicates it is fully charged.
3. The internal battery will charge even when the unit is switched off as long as it is plugged into the AC power.
4. The speaker battery can also be charged using a 12V external car battery or a DC 12V input (Please note: The connection cable is included). Please connect according to the "+" and "-".
5. Adjust the function keys to suit your audio preference.

## **BLUETOOTH**

Select Bluetooth mode ("BLUE") on the unit. The Bluetooth logo will twinkle and an alarm sound will be heard. Ensure you enable the Bluetooth function on your Bluetooth device and search for the unit. Once found, click on it and it will pair automatically.

## **TWS CONNECTION**

- STEP 1** - Push the Mode Button on both speakers until speakers are in Bluetooth Mode. Screen will display the word "**BLUE**".
- STEP 2** - When both speakers are in Bluetooth mode, push and hold the TWS button for 3 seconds. You will hear a beep & screen display "bt/btst". Next time you put both speakers in Bluetooth mode at the same time, speakers will connect automatically.
- STEP 3** - On your device, turn your Bluetooth settings "ON", you will then select the unit and pair. Enjoy TWS (True Wireless Stereo) sound from your phone via Bluetooth!

## **BATTERY & CHARGING**


1. The units takes approximately 8 hours to fully charge. It will automatically begin charging once the power cord is connected.
2. Low battery level may result in distorted sound, for best acoustical performance please monitor battery charge level.
3. To maximize the battery's lifespan, please charging the battery immediately. When the unit is not used for prolonged periods of time, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30days.
4. Power off unit when not in use to save battery.

## **REMOTE CONTROL**



- ⏻ Standby
- 📶 USB/SD/LINE/BLUETOOTH (Audio input)
- ⏮ Prev/FM CH-
- ⏸ Play/pause/FM tuner
- ⏭ Next/FM CH+
- 🔄 Repeat
- ⏹ Stop
- 🔊 Volume up
- 🔇 Volume down
- 🔇 Mute
- 🎛 Equalizer
- 1-9 0 Number

# CONTROL PANEL



## **CONTROL PANEL FUNCTION**

1. POWER SWITCH
2. LED LIGHT ON/OFF SWITCH
3. POWER : POWER SUPPLY AC 110-240V
4. VOLUME: ADJUST THE MASTER VOLUME
5. X-BASS:ADJUST THE X-BASS VOLUME
6. MIC. ECHO: ADJUST THE ECHO
7. MIC BASS: ADJUST THE MICROPHONE BASS VOLUME
8. MIC TREBLE : ADJUST THE MICROPHONE TREBLE VOLUME
9. MIC VOL. : ADJUST THE MICROPHONE VOLUME
10. GUITAR VOL.:ADJUST THE GUITAR VOLUME
11. MIC PRI.: MICROPHONE PRIORITY ON/OFF SWITCH
12. GUITAR IN: GUITAR INPUT
13. MIC IN: MICROPHONE INPUT
14. FM ANTENNA
15. USB PANEL FUNCTION:

 : MODE SELECT

 : REC: INSERT THE USB MEMORY/SD CARD AND PRESS THIS BUTTON TO START RECORDING. PRESS AGAIN TO STOPS RECORD.

 : REPEAT

 : PLAY/PAUSE; FM STATION AUTO SEARCHING;  
 TWS ON/OFF SWITCH(PRESS & HOLD)

 : PREVIOUS TRACK

 : NEXT TRACK

16. EQUALIZER
17. 12V EXTERNAL INPUT
18. AUX IN: RCA AUXILIARY INPUT

## **FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

### **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.