

Technical support

Please visit SEUIC's official website "www.chinaautoid.net" to download User Manual , SDK , different Apps or software in order to help you better use the device.


2016 SEUIC Company . All rights reserved.

It is strictly prohibited to copy, transfer, distribute and store any content in the document in any form without the SEUIC's permission.

JIANGSU SEUIC TECHNOLOGY CO.,LTD
No.23 Wenzhu Road. Yuhuatai District Nanjing.
(Service Telephone) : 400-777-0876
(Company Website) : www.seuic.com
(Product Website) : www.chinaautoid.com
(Service E-mail) : AUTOID@seuic.com
(Postal Code) : 210012


Seuic

Quick Use Guide



(Picture 1)

(Picture 2)



(Picture 3)

Applicable to CRUISE1 series

First use

First use or first open some applications, the system will pop up quick tips to guide you how to use this device.

Power on


Long press on power key until CRUISE1 vibrates.

Power off

Long press the power button to open the options menu, click the Power off.


Install Micro SD card and Micro SIM card

Below is Micro SIM 1 deck, above is Micro SIM 2 deck and Micro SD deck (Note : The device only supports Micro SIM card, do not use Micro SIM card sets, so as not to cause damage to the SIM card and equipment) , insert the card into the slot until you hear or feel sound of vibration.



Micro SIM card installation diagram

Micro SD card installation diagram



Micro SIM card slot

Micro SD card slot

(Picture 4: SIM card and SD card installation diagram)

Charging

The device could be charged through USB cable.

USB cable: use USB cable to connect adapter or PC for charging .
Red indicator means under charging ; green one means full charging.

Note : If disuse for a long time, please charge the whole device at least once a month to ensure that the battery is not over.



(Picture 5: USB cable charging diagram)

Common functions

■ Connect with PC

Connect your device to PC via the USB cable or a single cradle.

■ Barcode scanning

SEUIC's scan tool or customers' scan tool are optional to scan the barcodes.

Common problem : Scan without light, please make sure whether the scan function is closed, if closed, please open it in the scan tool. It appears two barcodes after one scanning, please check if SEUIC's scan tool and Customer application are open at the same time, please close SEUIC's scan tool, and set "not boot from the start" .

■ WIFI connection

Click "settings" in main screen.

In the wireless and network area, turn on the WLAN.

In the wireless and network area, click WLAN, the device will search and list the available WLAN.

Please select the one that you want , and then click it to connect. If you select a secured network, you will need to input password.

Note: if WLAN and mobile data are both opened, WLAN is optimized. When WLAN is off line, the system will ask whether to use mobile data if it's available.

■ LTE/WCDMA/EVDO/TD-SCDMA/GSM connection

At first use , when you insert SIM card , CRUISE1 will automatically select and register network service operator. The mobile data is opened by default.

Attention

Do not soak USB cable into water.

Do not use full RAM, otherwise it will cause system exception.

Please close 2D scan engine when you don' t use it , please do not keep it open for a long time.

Please do not directly look into the light beam of scan engine during scanning in order to avoid injury.

Please first connect the USB cable to device, then connect to the USB port in PC.

When replacing SIM card, need to restart the device while for Micro SD card, no need to restart the device.

Trouble shooting

Please check whether your SIM card is out of service if you can't use network, then check whether the CRUISE1 supports the corresponding network mode.

If the device is not connected to the PC, please check whether the connection of USB cable and CRUISE1 is good.

If the device can't sleep, please check whether network data exchange is working , or whether NAND is in the operating processes of reading and writing data.

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information (SAR) :

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The highest SAR value for the device as reported to the FCC when tested for use at the ear is 0.462W/kg and when worn on the body, as described in this user guide, is 1.119W/kg (Body-worn measurements differ among devices, depending upon available enhancements and FCC requirements.) While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement. The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on FCC ID: 2AC68-CRUISE1.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.0 cm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.0 cm from your body when the device is switched on. ng at its highest certified power level in all tested frequency bands.