


1. Open battery cover and connect and charge battery on the car by USB cable.
2. Install 2pcs AA batteries into remote.
3. Turn on the stunt car, car and remote will pair automatically, and operate according to remote instruction on right.



- Electronic controlled product, please pay attention to and prevent electrical shock when using this product.

- Please use this product under the supervision of an adult.

**Warning:** Please do not disassemble or modify this product or it may not function properly due to any changes.

- Please also avoid removing rechargeable battery pack from the RC car unit if possible.

**Note:** One remote controller used to connect with one car only, when the signal pairing is completed, the car drives without any interference. Multiple connections at the same time is not allowed.

Please charge your RC Car before use. Insert the plug of the battery pack to the port of the USB charging cable and connect the USB charging cable plug to the socket.

Charging time approx: 4-5hrs.

The indicator light of the USB charging cable will turn red when charging and will turn off when fully charged.

**Note:** Do not over charge.

The effective control range of the RC Car is about 30 meters, if the car is beyond this range it will stop running.

#### **Warm tips & Maintenance:**

- When the car is moving please do not touch the wheels of the car to avoid injuries.

- Do not play on the roads or in dangerous places in case of an accident.

- Do not play with the RC Car in sumps.

- Do not play close to fire sources and keep away from direct sunlight, high temperature and humidity which may cause short-circuit or electrical fire.

- Take out the batteries from the car and remote then place into packaging to avoid damages when transporting or being in storage.

- Use dry and soft cloth to clean the car.

**Battery Information:**

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel cadmium) batteries
  - Non - rechargeable batteries are not to be recharged.
- Batteries should only be changed under adult supervision.
- Do not dispose of batteries in fire, batteries may explode or leak.
  - Exhausted batteries are to be removed from the product.
  - The supply terminals are not to be short-circuited.
  - Do not use rechargeable batteries.
- Batteries are harmful if swallowed, so keep away from young children.
- Only batteries of the same or equivalent type as recommended are to be used.
- Clean the battery contacts and also those of the device prior to battery installation.
  - Remove battery if product left unused for long time.

<b>Problems</b>	<b>Causes</b>	<b>Solutions</b>
The car has no response	<ol style="list-style-type: none"><li>1. The remote control fail to connect or the car is sitting on "OFF".</li><li>2. The remote control and remote control car batteries are installed improperly.</li><li>3. The power of the rechargeable battery pack is weak.</li></ol>	<ol style="list-style-type: none"><li>1. Turn on the car and repeat the operation of signal connection.</li><li>2. Install the batteries according to the polarity instructions on the battery box correctly.</li><li>3. Please fully charge the battery pack.</li></ol>
The car is out of control, or the control range turn short	<ol style="list-style-type: none"><li>1. The batteries of the remote control is low, or the power of the battery pack is weak.</li><li>2. There may be interference near the site.</li></ol>	<ol style="list-style-type: none"><li>1. Replace with new batteries for the remote control, or charge the battery pack.</li><li>2. Replace the battery.</li></ol>

#### FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



#### Product Disposal

Where you see either symbol on any of our electrical products, batteries or packaging, it indicates that the relevant electrical product or battery should not be disposed of as general household waste in Europe. To ensure the correct waste treatment of the product and batteries, please dispose of them in accordance with any applicable local laws or requirements for disposal of electrical equipment/batteries. By disposing of batteries and electrical waste correctly, you will help to conserve natural resources and improve standards of environmental protection.



**Typo**

Designed in Australia. Made in China  
[www.typo.com](http://www.typo.com)