


# T-MAX Bluetooth Headset QUICK START GUIDE

## Product Details



## Instructions

1. Charge the headset in the case to fully charge the battery.
2. Open the case lid, take out the headset and insert the USB-C charging cable into the charging port on the back of the case.
3. Charge the headset for 2 hours to fully charge the battery.
4. Press the Power On/Off button to turn on the headset.
5. Press the Call Answer/End Call button to answer the call.
6. Press the Volume Up/Down buttons to adjust the volume.

## Basic Operations

**Power On** **Power Off**

**Volume Up** **Volume Down**

**Language Switching** **Activate the Voice Command**

## Check the Battery Level

**Check on Phone** **Listen to the voice reminder** (Under the power off status)

**80% battery**

## Pair with iPhone/iPad

**Check on Phone** **Connect**

## Phone Call Operations

**Answer a Call** **End of Call**

**Convert the Phone Answering Receiver Mode**

**Auto Answer Function On/Off**

## Music Control

**Play/Pause** **Next Song**

**Last Song** **Music/PM Switching**

## FM Operations

**Turn On/Off FM** **Next Channel**

**Last Channel** **Play/Pause FM**

## Pairing Between T-MAX and Other Bluetooth

**Enter the Pincode on other** **Click the connection**

## Pairing Between Two Devices

**Device A** **Device B**

## Start/End Intercom

**Start/End Intercom**

## Music Sharing

**Turn on share** **Turn off share**

**Turn on share**

## Clear the Pairing History

**Under the Power on status**

**Group linking pairing**

**Part A** **Part B** **Part C** **Part D** **Part E** **Part F**

**Part A and B** **Part B and C** **Part C and D** **Part D and E** **Part E and F**

**Part A and B and C** **Part B and C and D** **Part C and D and E** **Part D and E and F**

**Part A and B and C and D** **Part B and C and D and E** **Part C and D and E and F**

**Part A and B and C and D and E** **Part B and C and D and E and F**

**Part A and B and C and D and E and F**

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device must not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Manufacturer:** Shenzhen Goodson(Elec) Electronics Co., Ltd.  
**Address:** East Gate 4th Floor, 8 Shuanghu New (Chang) Industrial park, No. 116 HongChang Road, Baoan, Shenzhen, China

## Warranty Card

**Model Number: T-MAX**

Please keep your purchase receipt together with your warranty card for reference.

**1 Year**

Name: \_\_\_\_\_  
 Address: \_\_\_\_\_  
 Phone: \_\_\_\_\_

**Failure Description:**

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Please affix a copy of invoice on the back of warranty card as a proof of purchase date. If you find any problems during use of your product, please contact our after sales service. Please make sure that you describe the problems clearly on warranty card so that we can handle them timely.