


TCL MOVETIME

MT43K



Family Watch Quick Start Guide

Getting to know your watch



Power key

- Long press for 3 seconds to power off when the SIM card is inserted and paired with your smartphone. In other case, long press for 3 seconds to restart except you have an incoming call.
- Press to increase the volume when you have an incoming call.
- Short press to wake up the device.
- Short press to go back to Home screen when the current screen is not the Home page. Press again to turn off the screen.


SOS key

- Long press for 3 seconds to call SOS, but continuously reduce volume when you have an incoming call.
- Press twice to reduce the volume when you have an incoming call.
- Press twice to start the voice assistant when you're on the home page. Press twice again to back.

Setting up your watch

Getting a SIM card

A nano-SIM (not included) is required in order to set up and use your watch. Contact your network operator to request a nano-SIM with a voice and data plan.



Note: Use standard nano-SIM card (0.6~0.7mm thickness), the normal SIM or Micro SIM card may cause abnormal operation due to different thickness after card cutting.



Inserting the SIM card

1. Push the SIM card tray to eject it.
2. Place the SIM card on the SIM card tray correctly.
3. Push the SIM card tray to close it.



Charging your watch

Ensure that the pins in the charging dock are aligned with the pins in the back cover of your Watch. Connect the USB port with a computer to begin charging via the USB cable.



Note: When charging port is corroded or covers dirt, it will seriously affect the charging, which need to keep clean. Wipe sweat on your band after sporting before charging.

Powering on your watch

Long press the **Power key** for 3 seconds to power on your watch.

Language

You will be asked to select the system language when powering on your watch for the first time. To change the system language when the watch is unpaired, swipe right twice from the Home screen and then go to **Settings** > **Language** to select a language.



Download and install the app on your smartphone

To download the app you can:

- Search for “TCL Connect” in the Google Play store (Android 5.0 and above), or App store (iOS 10.0 and above).
- Scan the following QR code.



Create an account

1. Touch **Create Account** to create your **TCL Connect** account.
2. Enter your name, email address and set a password for your account.⁽¹⁾
3. Enter the verification code sent to your email address. This email address will be used to help you reset your password should you forget it.
4. Touch **Confirm email** in the verification email.
5. Touch **Done**.

(1) Read the “Terms of use” and “Privacy and security” and check the box.

Log in to your account

Enter your email address and password to log in.

Pairing


Make sure the SIM card is correctly inserted and you are able to connect to the internet before pairing your watch with your phone. The connected network icon will appear at the top left of your watch's Home screen once connected to the internet.

 4G network

 3G network

 2G network

 Data roaming network

 No network but can make calls

 No network and can't make calls


1. Touch **Add Watch** on the home page of the **TCL Connect** app.
2. Follow the instructions to complete your child's personal information (profile picture, SOS number, name and gender) and touch **NEXT**.

3. There are two ways to pair your watch with your phone:
 - Scan the QR code to pair your watch
Swipe left from the Home screen of your watch to obtain the QR code when pairing the watch for the first time. Scan the QR code.
 - Enter the mobile number of your watch to pair
Check the SIM card packaging or contact the SIM card operator of your watch to know the mobile number. Enter the number on your **TCL Connect** app.
 4. The server will send a random code to your watch and the information displayed on the screen should be noted at this time. Enter the verification code and touch **Next** to pair your watch with your phone.
- Once the MOVETIME Family Watch has been successfully paired with your phone, you will be brought to the application main screen. The location of the watch will be displayed here on the map.

Using your watch

Screen

Press the **Power key** to wake up the Home screen.



Touch

To select an application or confirm an action, use your finger to touch it.



Touch and hold

Long press the Home screen, swipe left to view different options, and touch a watch face to select it.



Swipe left/right

Swipe left/right to view applications, settings, and functions.

Swipe right to return to the previous page after you have entered any application.





Swipe up/down

Swipe up from the Home screen to view notifications. Swipe down from the Home screen for volume and brightness controls and to turn on/off the wireless connection.


Call

Phone call

1. Swipe left from the Home screen and touch **Contacts**.
2. Touch the contact and choose  to place a phone call. Touch  to end the call.

Message

Voice message

Touch **Chat** to select a contact or a group. Hold  to record, and release it to send the message.

Emoji

Touch **Chat** to select a contact or a group. Touch  to select and send an emoji.




Note: If the message fails to send,  will appear next to the message. Touch the icon to resend the message.

Friends



Adding new friends

Swipe left from the Home screen and touch **Contacts** > **+ Friend**. Keep both watches in close proximity, shake them, and touch **OK**.


Deleting a friend

In the contact list, swipe left on the name of the friend. Touch the Delete icon  that then appears on screen. Touch  to confirm, or touch  to cancel.

Group chat

Add friends first before you create a group. Swipe left twice from the Home screen and touch **Chat** > **Create a group**. Choose a group picture and invite friends. Touch  to create a group, or touch  to cancel.

Sports

Swipe left/right from the Home screen to select the application. Touch **Sports** to view your sports statistics including steps, distances and calories burned. If you have inserted a SIM card in your watch, you can view the daily steps rankings for you and your friends. You can touch the  to “praise” their steps. You will receive a notification if one of your friends “praises” your steps. You can also swipe up to the end of this page and touch **Who praised me** to view the friends who have “praised” you.

Using your voice assistant


Press the SOS key to start voice assistant. Voice assistant could help you using your watch by voice control.

You can say:


- Call to dad
- Call dad
- Message to dad
- Volume up
- Volume down
- Turn up volume
- Turn down volume"
- Open sport
- Open games
- Play games

Straps

Remove straps



Attaching new straps



Waterproof notice

This product has an IP67 rating and is suitable for everyday use. DO NOT use it when swimming, diving, scuba diving and taking shower.



More information

For more information, please refer to the help section in the TCL Connect app or visit www.tcl.com/wearables/.

