

User manual

Bluetooth Speaker









Brand: The JUKE

Model:MX-300

FCC ID:2ACDAMX-300

Function

Bluetooth Mode

- 1.Power on/off: long press  for 2seconds to power on
2. the speaker will automatically enter pairing mode. To pair, go to Bluetooth settings on your smart phone, tablet, computer or device and connect to “MX-300”. Enter “0000” if asked for a pass code. To enter pairing mode thereafter, it will show another tone after pair successfully. The speaker is ready for use.
3. Play/pause: short press  to play or pause music.
- 4.Long press  to increase volume, short press  to next song
- 5.Long press  to decrease volume, short press  to previous song
6. Calling: when there is calling, press  to receive it, after talking to short press  to end the call.

LINE IN function

Plug the provided audio cable into the B37 Speaker and then plug into your portable Device. The B37 Speaker is now ready for use.

LINE OUT function

You can use the built-in LINE OUT port to connect another speaker to this speaker.

Specification

Dual speaker Diameter:40mm Power: 4 Ω 3W

Frequency range: 130HZ---20KHZ

Battery: 1200mAh

SNR: 90 ± 3 db

Bluetooth version: 2.1+EDR

Bluetooth effective range: 10m

Indicator LED:

Bluetooth: blue light flash

LINE IN: blue light on

Charging: red light on, it will die out after full charged.

FCC Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.