



Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5745 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	32.44	40.02	72.46	109.40	-36.94	peak	
2		5725.000	42.48	40.05	82.53	122.20	-39.67	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5745 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11489.96	46.26	-0.36	45.90	54.00	-8.10	AVG	
2		11490.13	52.17	-0.36	51.81	74.00	-22.19	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5745 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	29.43	40.02	69.45	109.40	-39.95	peak	
2		5725.000	33.87	40.05	73.92	122.20	-48.28	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5745 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11489.78	50.40	-0.36	50.04	74.00	-23.96	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	26



No.	Mk.	Freq.	Reading Level	Correct Factor	Measure-ment	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5715.000	25.83	40.02	65.85	109.40	-43.55	peak	
2		5725.000	32.04	40.05	72.09	122.20	-50.11	peak	
3		5850.000	28.29	40.34	68.63	122.20	-53.57	peak	
4		5860.000	25.10	40.36	65.46	109.40	-43.94	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	26

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	23.75	40.02	63.77	109.40	-45.63	peak	
2		5725.000	23.17	40.05	63.22	122.20	-58.98	peak	
3		5850.000	24.02	40.34	64.36	122.20	-57.84	peak	
4		5860.000	22.65	40.36	63.01	109.40	-46.39	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	52



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	23.16	40.02	63.18	109.40	-46.22	peak	
2		5725.000	24.53	40.05	64.58	122.20	-57.62	peak	
3		5850.000	25.34	40.34	65.68	122.20	-56.52	peak	
4	*	5860.000	24.44	40.36	64.80	109.40	-44.60	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	52

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	23.05	40.02	63.07	109.40	-46.33	peak	
2		5725.000	23.45	40.05	63.50	122.20	-58.70	peak	
3		5850.000	22.65	40.34	62.99	122.20	-59.21	peak	
4		5860.000	22.68	40.36	63.04	109.40	-46.36	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	21.35	40.02	61.37	109.40	-48.03	peak	
2		5725.000	22.46	40.05	62.51	122.20	-59.69	peak	
3		5850.000	23.01	40.34	63.35	122.20	-58.85	peak	
4	*	5860.000	22.32	40.36	62.68	109.40	-46.72	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	106




No. Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	5715.000	21.96	40.02	61.98	109.40	-47.42	peak	
2	5725.000	22.73	40.05	62.78	122.20	-59.42	peak	
3	5850.000	23.03	40.34	63.37	122.20	-58.83	peak	
4 *	5860.000	23.69	40.36	64.05	109.40	-45.35	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	22.70	40.02	62.72	109.40	-46.68	peak	
2		5725.000	21.91	40.05	61.96	122.20	-60.24	peak	
3		5850.000	23.12	40.34	63.46	122.20	-58.74	peak	
4	*	5860.000	23.33	40.36	63.69	109.40	-45.71	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		11569.64	52.07	-0.34	51.73	74.00	-22.27	peak	
2	*	11569.94	46.91	-0.34	46.57	54.00	-7.43	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	21.96	40.02	61.98	109.40	-47.42	peak	
2		5725.000	22.73	40.05	62.78	122.20	-59.42	peak	
3		5850.000	23.03	40.34	63.37	122.20	-58.83	peak	
4	*	5860.000	23.69	40.36	64.05	109.40	-45.35	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5785 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11570.02	51.31	-0.34	50.97	74.00	-23.03	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5850.000	54.01	40.34	94.35	122.20	-27.85	peak	
2		5860.000	39.02	40.36	79.38	109.40	-30.02	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5850.000	45.99	40.34	86.33	122.20	-35.87	peak	
2	*	5860.000	36.46	40.36	76.82	109.40	-32.58	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	52

Vertical




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1		5850.000	44.83	40.34	85.17	122.20	-37.03	peak	
2	*	5860.000	36.49	40.36	76.85	109.40	-32.55	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5850.000	38.46	40.34	78.80	122.20	-43.40	peak	
2	*	5860.000	29.77	40.36	70.13	109.40	-39.27	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5850.000	41.53	40.34	81.87	122.20	-40.33	peak	
2	*	5860.000	34.29	40.36	74.65	109.40	-34.75	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	106




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1		5850.000	35.58	40.34	75.92	122.20	-46.28	peak	
2	*	5860.000	33.64	40.36	74.00	109.40	-35.40	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5850.000	33.38	40.34	73.72	122.20	-48.48	peak	
2	*	5860.000	26.48	40.36	66.84	109.40	-42.56	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		11649.90	52.81	-0.29	52.52	74.00	-21.48	peak	
2	*	11649.93	48.57	-0.29	48.28	54.00	-5.72	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5850.000	28.97	40.34	69.31	122.20	-52.89	peak	
2	*	5860.000	22.78	40.36	63.14	109.40	-46.26	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE20) Mode 5825 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		11649.78	51.82	-0.29	51.53	74.00	-22.47	peak	
2	*	11649.93	47.11	-0.29	46.82	54.00	-7.18	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5135.850	29.62	39.05	68.67	74.00	-5.33	peak	
2	*	5135.850	11.57	39.05	50.62	54.00	-3.38	AVG	
3		5150.000	22.67	39.07	61.74	74.00	-12.26	peak	
4		5150.000	7.16	39.07	46.23	54.00	-7.77	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	26

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5136.150	20.91	39.05	59.96	74.00	-14.04	peak	
2	*	5136.150	8.47	39.05	47.52	54.00	-6.48	AVG	
3		5150.000	19.74	39.07	58.81	74.00	-15.19	peak	
4		5150.000	7.13	39.07	46.20	54.00	-7.80	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5138.850	24.66	39.05	63.71	74.00	-10.29	peak	
2	*	5138.850	13.82	39.05	52.87	54.00	-1.13	AVG	
3		5150.000	24.71	39.07	63.78	74.00	-10.22	peak	
4		5150.000	10.78	39.07	49.85	54.00	-4.15	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	52

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5139.600	22.15	39.05	61.20	74.00	-12.80	peak	
2	*	5139.600	9.13	39.05	48.18	54.00	-5.82	AVG	
3		5150.000	23.37	39.07	62.44	74.00	-11.56	peak	
4		5150.000	7.73	39.07	46.80	54.00	-7.20	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	106

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5148.300	23.99	39.07	63.06	74.00	-10.94	peak	
2	*	5148.300	13.84	39.07	52.91	54.00	-1.09	AVG	
3		5150.000	24.11	39.07	63.18	74.00	-10.82	peak	
4		5150.000	12.21	39.07	51.28	54.00	-2.72	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.39	39.07	61.46	74.00	-12.54	peak	
2	*	5150.000	7.45	39.07	46.52	54.00	-7.48	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	242



No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1		5150.000	28.91	39.07	67.98	74.00	-6.02	peak	
2	*	5150.000	13.36	39.07	52.43	54.00	-1.57	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.59	39.07	61.66	74.00	-12.34	peak	
2	*	5150.000	8.95	39.07	48.02	54.00	-5.98	AVG	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	484

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.13	39.07	61.20	74.00	-12.80	peak	
2	*	5150.000	11.91	39.07	50.98	54.00	-3.02	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10378.49	48.15	-1.63	46.52	68.30	-21.78	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	484


Horizontal



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	23.66	39.07	62.73	74.00	-11.27	peak	
2	*	5150.000	8.97	39.07	48.04	54.00	-5.96	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5190 MHz	RU configuration	484



No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	10380.23	49.39	-1.63	47.76	68.30	-20.54	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	26

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5139.600	21.77	39.05	60.82	74.00	-13.18	peak	
2	*	5139.600	10.64	39.05	49.69	54.00	-4.31	AVG	
3		5150.000	21.98	39.07	61.05	74.00	-12.95	peak	
4		5150.000	7.92	39.07	46.99	54.00	-7.01	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	23.25	39.07	62.32	74.00	-11.68	peak	
2	*	5150.000	6.91	39.07	45.98	54.00	-8.02	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5143.500	24.23	39.06	63.29	74.00	-10.71	peak	
2	*	5143.500	11.55	39.06	50.61	54.00	-3.39	AVG	
3		5150.000	22.51	39.07	61.58	74.00	-12.42	peak	
4		5150.000	7.87	39.07	46.94	54.00	-7.06	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	21.93	39.07	61.00	74.00	-13.00	peak	
2	*	5150.000	7.52	39.07	46.59	54.00	-7.41	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	106

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	29.51	39.07	68.58	74.00	-5.42	peak	
2	*	5150.000	14.27	39.07	53.34	54.00	-0.66	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	106

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	23.14	39.07	62.21	74.00	-11.79	peak	
2	*	5150.000	9.51	39.07	48.58	54.00	-5.42	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	26.92	39.07	65.99	74.00	-8.01	peak	
2	*	5150.000	10.16	39.07	49.23	54.00	-4.77	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.32	39.07	61.39	74.00	-12.61	peak	
2	*	5150.000	8.28	39.07	47.35	54.00	-6.65	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	21.82	39.07	60.89	74.00	-13.11	peak	
2	*	5150.000	8.99	39.07	48.06	54.00	-5.94	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10459.75	48.42	-1.55	46.87	68.30	-21.43	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	484

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.77	39.07	61.84	74.00	-12.16	peak	
2	*	5150.000	8.28	39.07	47.35	54.00	-6.65	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE40) Mode 5230 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10458.54	48.74	-1.55	47.19	68.30	-21.11	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.74	39.32	63.06	74.00	-10.94	peak	
2	*	5350.000	5.71	39.32	45.03	54.00	-8.97	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	21.14	39.32	60.46	74.00	-13.54	peak	
2	*	5350.000	5.49	39.32	44.81	54.00	-9.19	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	52



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.95	39.32	62.27	74.00	-11.73	peak	
2	*	5350.000	6.09	39.32	45.41	54.00	-8.59	AVG	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	52

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.02	39.32	61.34	74.00	-12.66	peak	
2	*	5350.000	5.24	39.32	44.56	54.00	-9.44	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	106

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.46	39.32	62.78	74.00	-11.22	peak	
2	*	5350.000	6.48	39.32	45.80	54.00	-8.20	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	106

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.62	39.32	61.94	74.00	-12.06	peak	
2	*	5350.000	5.94	39.32	45.26	54.00	-8.74	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.43	39.32	61.75	74.00	-12.25	peak	
2	*	5350.000	5.68	39.32	45.00	54.00	-9.00	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	242




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin	
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector Comment
1		5350.000	22.97	39.32	62.29	74.00	-11.71	peak
2	*	5350.000	5.37	39.32	44.69	54.00	-9.31	AVG

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.32	39.32	61.64	74.00	-12.36	peak	
2	*	5350.000	7.25	39.32	46.57	54.00	-7.43	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10539.78	49.17	-1.36	47.81	68.30	-20.49	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.57	39.32	61.89	74.00	-12.11	peak	
2	*	5350.000	6.53	39.32	45.85	54.00	-8.15	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5270 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10538.50	48.15	-1.37	46.78	68.30	-21.52	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	26

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.46	39.32	62.78	74.00	-11.22	peak	
2		5350.000	5.93	39.32	45.25	54.00	-8.75	AVG	
3		5364.450	28.86	39.34	68.20	74.00	-5.80	peak	
4	*	5364.450	11.41	39.34	50.75	54.00	-3.25	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	26

Horizontal



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	21.81	39.32	61.13	74.00	-12.87	peak	
2		5350.000	5.84	39.32	45.16	54.00	-8.84	AVG	
3		5363.550	20.74	39.34	60.08	74.00	-13.92	peak	
4	*	5363.550	8.78	39.34	48.12	54.00	-5.88	AVG	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	52

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.28	39.32	62.60	74.00	-11.40	peak	
2		5350.000	8.07	39.32	47.39	54.00	-6.61	AVG	
3		5359.950	32.02	39.34	71.36	74.00	-2.64	peak	
4	*	5359.950	13.35	39.34	52.69	54.00	-1.31	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.70	39.32	62.02	74.00	-11.98	peak	
2		5350.000	6.94	39.32	46.26	54.00	-7.74	AVG	
3		5360.550	25.22	39.34	64.56	74.00	-9.44	peak	
4	*	5360.550	10.03	39.34	49.37	54.00	-4.63	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	106

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.35	39.32	62.67	74.00	-11.33	peak	
2	*	5350.000	6.07	39.32	45.39	54.00	-8.61	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	106

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.04	39.32	62.36	74.00	-11.64	peak	
2	*	5350.000	5.78	39.32	45.10	54.00	-8.90	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	242

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	26.16	39.32	65.48	74.00	-8.52	peak	
2	*	5350.000	7.30	39.32	46.62	54.00	-7.38	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	242

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.57	39.32	62.89	74.00	-11.11	peak	
2	*	5350.000	5.72	39.32	45.04	54.00	-8.96	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.34	39.32	62.66	74.00	-11.34	peak	
2	*	5350.000	7.64	39.32	46.96	54.00	-7.04	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10620.25	48.40	-1.08	47.32	74.00	-26.68	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.85	39.32	62.17	74.00	-11.83	peak	
2	*	5350.000	7.12	39.32	46.44	54.00	-7.56	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE40) Mode 5310 MHz	RU configuration	484



No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	10621.56	49.84	-1.08	48.76	74.00	-25.24	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	26

Vertical



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5456.033	23.60	39.45	63.05	74.00	-10.95	peak	
2	*	5456.033	10.98	39.45	50.43	54.00	-3.57	AVG	
3		5460.000	22.45	39.46	61.91	74.00	-12.09	peak	
4		5460.000	5.03	39.46	44.49	54.00	-9.51	AVG	
5		5470.000	25.23	39.47	64.70	68.30	-3.60	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	26

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	23.60	39.46	63.06	74.00	-10.94	peak	
2		5460.000	5.43	39.46	44.89	54.00	-9.11	AVG	
3	*	5470.000	21.49	39.47	60.96	68.30	-7.34	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	52

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5458.108	10.84	39.45	50.29	74.00	-23.71	peak	
2	*	5458.108	24.70	39.45	64.15	54.00	10.15	AVG	
3		5460.000	27.12	39.46	66.58	74.00	-7.42	peak	
4		5460.000	10.17	39.46	49.63	54.00	-4.37	AVG	
5		5470.000	25.60	39.47	65.07	68.30	-3.23	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	52


Horizontal



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.65	39.46	61.11	74.00	-12.89	peak	
2		5460.000	6.30	39.46	45.76	54.00	-8.24	AVG	
3	*	5470.000	22.04	39.47	61.51	68.30	-6.79	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	26.47	39.46	65.93	74.00	-8.07	peak	
2		5460.000	8.62	39.46	48.08	54.00	-5.92	AVG	
3	*	5470.000	25.40	39.47	64.87	68.30	-3.43	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	106

Horizontal



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.20	39.46	61.66	74.00	-12.34	peak	
2		5460.000	6.41	39.46	45.87	54.00	-8.13	AVG	
3	*	5470.000	24.15	39.47	63.62	68.30	-4.68	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	242

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5460.000	31.81	39.46	71.27	74.00	-2.73	peak	
2		5460.000	7.92	39.46	47.38	54.00	-6.62	AVG	
3		5470.000	25.73	39.47	65.20	68.30	-3.10	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.16	39.46	61.62	74.00	-12.38	peak	
2		5460.000	6.49	39.46	45.95	54.00	-8.05	AVG	
3	*	5470.000	24.59	39.47	64.06	68.30	-4.24	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	484

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.17	39.46	61.63	74.00	-12.37	peak	
2		5460.000	6.73	39.46	46.19	54.00	-7.81	AVG	
3	*	5470.000	22.12	39.47	61.59	68.30	-6.71	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	484



No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin	Detector	Comment
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB		
1	*	11019.75	50.26	0.26	50.52	74.00	-23.48	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	484

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.38	39.46	60.84	74.00	-13.16	peak	
2		5460.000	5.79	39.46	45.25	54.00	-8.75	AVG	
3	*	5470.000	22.98	39.47	62.45	68.30	-5.85	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5510 MHz	RU configuration	484




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	11019.65	48.41	0.26	48.67	74.00	-25.33	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.32	39.46	60.78	74.00	-13.22	peak	
2		5460.000	5.50	39.46	44.96	54.00	-9.04	AVG	
3	*	5470.000	21.08	39.47	60.55	68.30	-7.75	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	26

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.41	39.46	60.87	74.00	-13.13	peak	
2		5460.000	5.10	39.46	44.56	54.00	-9.44	AVG	
3	*	5470.000	22.62	39.47	62.09	68.30	-6.21	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	24.44	39.46	63.90	74.00	-10.10	peak	
2		5460.000	5.70	39.46	45.16	54.00	-8.84	AVG	
3	*	5470.000	22.94	39.47	62.41	68.30	-5.89	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	52



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.57	39.46	61.03	74.00	-12.97	peak	
2		5460.000	4.75	39.46	44.21	54.00	-9.79	AVG	
3	*	5470.000	21.42	39.47	60.89	68.30	-7.41	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	106

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.33	39.46	61.79	74.00	-12.21	peak	
2		5460.000	4.90	39.46	44.36	54.00	-9.64	AVG	
3	*	5470.000	22.50	39.47	61.97	68.30	-6.33	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	106

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.37	39.46	61.83	74.00	-12.17	peak	
2		5460.000	5.28	39.46	44.74	54.00	-9.26	AVG	
3	*	5470.000	22.22	39.47	61.69	68.30	-6.61	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.61	39.46	62.07	74.00	-11.93	peak	
2		5460.000	6.29	39.46	45.75	54.00	-8.25	AVG	
3	*	5470.000	23.19	39.47	62.66	68.30	-5.64	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.26	39.46	61.72	74.00	-12.28	peak	
2		5460.000	5.81	39.46	45.27	54.00	-8.73	AVG	
3	*	5470.000	21.75	39.47	61.22	68.30	-7.08	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	21.64	39.46	61.10	74.00	-12.90	peak	
2		5460.000	5.63	39.46	45.09	54.00	-8.91	AVG	
3	*	5470.000	22.72	39.47	62.19	68.30	-6.11	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	484

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11099.82	50.98	0.15	51.13	74.00	-22.87	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5460.000	22.56	39.46	62.02	74.00	-11.98	peak	
2		5460.000	5.46	39.46	44.92	54.00	-9.08	AVG	
3	*	5470.000	22.79	39.47	62.26	68.30	-6.04	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5550 MHz	RU configuration	484

Horizontal




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	11100.20	48.92	0.15	49.07	74.00	-24.93	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	23.46	40.05	63.51	68.30	-4.79	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	26




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5725.000	22.33	40.05	62.38	68.30	-5.92	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	52




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5725.000	24.70	40.05	64.75	68.30	-3.55	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	22.34	40.05	62.39	68.30	-5.91	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	25.31	40.05	65.36	68.30	-2.94	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	21.61	40.05	61.66	68.30	-6.64	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	23.13	40.05	63.18	68.30	-5.12	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	242




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5725.000	22.34	40.05	62.39	68.30	-5.91	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	484




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin	
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector Comment
1	*	5725.000	23.38	40.05	63.43	68.30	-4.87	peak

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11339.83	50.27	-0.17	50.10	74.00	-23.90	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5725.000	23.98	40.05	64.03	68.30	-4.27	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE40) Mode 5670 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11340.12	48.15	-0.17	47.98	74.00	-26.02	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	26




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5715.000	48.37	40.02	88.39	109.40	-21.01	peak	
2		5725.000	44.14	40.05	84.19	122.20	-38.01	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	38.89	40.02	78.91	109.40	-30.49	peak	
2		5725.000	41.35	40.05	81.40	122.20	-40.80	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	52



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	48.22	40.02	88.24	109.40	-21.16	peak	
2		5725.000	50.64	40.05	90.69	122.20	-31.51	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	41.11	40.02	81.13	109.40	-28.27	peak	
2		5725.000	43.17	40.05	83.22	122.20	-38.98	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	47.12	40.02	87.14	109.40	-22.26	peak	
2		5725.000	46.22	40.05	86.27	122.20	-35.93	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	37.58	40.02	77.60	109.40	-31.80	peak	
2		5725.000	44.21	40.05	84.26	122.20	-37.94	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	41.34	40.02	81.36	109.40	-28.04	peak	
2		5725.000	44.25	40.05	84.30	122.20	-37.90	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	242




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	5715.000	34.91	40.02	74.93	109.40	-34.47	peak	
2		5725.000	42.18	40.05	82.23	122.20	-39.97	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	32.79	40.02	72.81	109.40	-36.59	peak	
2		5725.000	40.72	40.05	80.77	122.20	-41.43	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11509.91	51.15	-0.38	50.77	74.00	-23.23	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	484

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	5715.000	32.13	40.02	72.15	109.40	-37.25	peak	
2		5725.000	32.70	40.05	72.75	122.20	-49.45	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5755 MHz	RU configuration	484




No.	Mk.	Freq.	Reading Level	Correct Factor	Measure-ment	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	11510.97	49.30	-0.38	48.92	74.00	-25.08	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	22.88	40.02	62.90	109.40	-46.50	peak	
2		5725.000	38.40	40.05	78.45	122.20	-43.75	peak	
3	*	5850.000	52.40	40.34	92.74	122.20	-29.46	peak	
4		5860.000	29.39	40.36	69.75	109.40	-39.65	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	22.25	40.02	62.27	109.40	-47.13	peak	
2		5725.000	33.64	40.05	73.69	122.20	-48.51	peak	
3	*	5850.000	44.88	40.34	85.22	122.20	-36.98	peak	
4		5860.000	29.66	40.36	70.02	109.40	-39.38	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	27.68	40.02	67.70	109.40	-41.70	peak	
2		5725.000	36.40	40.05	76.45	122.20	-45.75	peak	
3		5850.000	39.16	40.34	79.50	122.20	-42.70	peak	
4	*	5860.000	36.83	40.36	77.19	109.40	-32.21	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	24.92	40.02	64.94	109.40	-44.46	peak	
2		5725.000	31.16	40.05	71.21	122.20	-50.99	peak	
3		5850.000	31.62	40.34	71.96	122.20	-50.24	peak	
4	*	5860.000	31.00	40.36	71.36	109.40	-38.04	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	106




No. Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	5715.000	28.08	40.02	68.10	109.40	-41.30	peak	
2	5725.000	30.48	40.05	70.53	122.20	-51.67	peak	
3	5850.000	34.38	40.34	74.72	122.20	-47.48	peak	
4 *	5860.000	30.11	40.36	70.47	109.40	-38.93	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	24.50	40.02	64.52	109.40	-44.88	peak	
2		5725.000	25.71	40.05	65.76	122.20	-56.44	peak	
3		5850.000	28.06	40.34	68.40	122.20	-53.80	peak	
4	*	5860.000	27.43	40.36	67.79	109.40	-41.61	peak	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	25.41	40.02	65.43	109.40	-43.97	peak	
2		5725.000	32.42	40.05	72.47	122.20	-49.73	peak	
3		5850.000	33.83	40.34	74.17	122.20	-48.03	peak	
4	*	5860.000	31.04	40.36	71.40	109.40	-38.00	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	242



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	23.26	40.02	63.28	109.40	-46.12	peak	
2		5725.000	24.74	40.05	64.79	122.20	-57.41	peak	
3		5850.000	34.50	40.34	74.84	122.20	-47.36	peak	
4	*	5860.000	25.45	40.36	65.81	109.40	-43.59	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	484

Vertical




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5715.000	23.25	40.02	63.27	109.40	-46.13	peak	
2		5725.000	23.68	40.05	63.73	122.20	-58.47	peak	
3		5850.000	32.87	40.34	73.21	122.20	-48.99	peak	
4	*	5860.000	26.88	40.36	67.24	109.40	-42.16	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	484




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	11589.92	50.59	-0.33	50.26	74.00	-23.74	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	484




No. Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	5715.000	22.91	40.02	62.93	109.40	-46.47	peak	
2	5725.000	23.33	40.05	63.38	122.20	-58.82	peak	
3	5850.000	25.12	40.34	65.46	122.20	-56.74	peak	
4 *	5860.000	23.89	40.36	64.25	109.40	-45.15	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-3_TX AX (HE40) Mode 5795 MHz	RU configuration	484




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	11589.59	48.51	-0.33	48.18	74.00	-25.82	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5134.200	27.90	39.05	66.95	74.00	-7.05	peak	
2	*	5134.200	13.48	39.05	52.53	54.00	-1.47	AVG	
3		5150.000	23.53	39.07	62.60	74.00	-11.40	peak	
4		5150.000	8.76	39.07	47.83	54.00	-6.17	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.24	39.07	61.31	74.00	-12.69	peak	
2	*	5150.000	8.47	39.07	47.54	54.00	-6.46	AVG	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	52


Vertical



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5131.200	25.83	39.05	64.88	74.00	-9.12	peak	
2	*	5131.200	14.32	39.05	53.37	54.00	-0.63	AVG	
3		5150.000	22.75	39.07	61.82	74.00	-12.18	peak	
4		5150.000	8.00	39.07	47.07	54.00	-6.93	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	52



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5132.700	23.06	39.05	62.11	74.00	-11.89	peak	
2	*	5132.700	10.20	39.05	49.25	54.00	-4.75	AVG	
3		5150.000	23.13	39.07	62.20	74.00	-11.80	peak	
4		5150.000	8.67	39.07	47.74	54.00	-6.26	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	106



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5134.050	24.23	39.05	63.28	74.00	-10.72	peak	
2	*	5134.050	14.36	39.05	53.41	54.00	-0.59	AVG	
3		5150.000	26.30	39.07	65.37	74.00	-8.63	peak	
4		5150.000	10.18	39.07	49.25	54.00	-4.75	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	21.01	39.07	60.08	74.00	-13.92	peak	
2	*	5150.000	8.19	39.07	47.26	54.00	-6.74	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	242

Vertical




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin	Detector	Comment
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB		
1		5150.000	22.93	39.07	62.00	74.00	-12.00	peak	
2	*	5150.000	9.32	39.07	48.39	54.00	-5.61	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	242

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	23.37	39.07	62.44	74.00	-11.56	peak	
2	*	5150.000	8.11	39.07	47.18	54.00	-6.82	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	24.67	39.07	63.74	74.00	-10.26	peak	
2	*	5150.000	11.95	39.07	51.02	54.00	-2.98	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	484



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	23.41	39.07	62.48	74.00	-11.52	peak	
2	*	5150.000	9.15	39.07	48.22	54.00	-5.78	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	996




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5148.000	23.96	39.07	63.03	74.00	-10.97	peak	
2	*	5148.000	14.66	39.07	53.73	54.00	-0.27	AVG	
3		5150.000	22.88	39.07	61.95	74.00	-12.05	peak	
4		5150.000	13.80	39.07	52.87	54.00	-1.13	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	996




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10421.74	48.20	-1.58	46.62	68.30	-21.68	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	996




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5150.000	22.96	39.07	62.03	74.00	-11.97	peak	
2	*	5150.000	10.34	39.07	49.41	54.00	-4.59	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-1_TX AX (HE80) Mode 5210 MHz	RU configuration	996




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10417.55	48.32	-1.58	46.74	68.30	-21.56	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.41	39.32	62.73	74.00	-11.27	peak	
2		5350.000	6.92	39.32	46.24	54.00	-7.76	AVG	
3		5367.000	29.40	39.34	68.74	74.00	-5.26	peak	
4	*	5367.000	12.41	39.34	51.75	54.00	-2.25	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	26



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.85	39.32	62.17	74.00	-11.83	peak	
2	*	5350.000	6.85	39.32	46.17	54.00	-7.83	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.23	39.32	61.55	74.00	-12.45	peak	
2		5350.000	7.28	39.32	46.60	54.00	-7.40	AVG	
3		5360.850	26.49	39.34	65.83	74.00	-8.17	peak	
4	*	5360.850	12.18	39.34	51.52	54.00	-2.48	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	52




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.56	39.32	61.88	74.00	-12.12	peak	
2		5350.000	7.11	39.32	46.43	54.00	-7.57	AVG	
3		5360.850	23.64	39.34	62.98	74.00	-11.02	peak	
4	*	5360.850	9.24	39.34	48.58	54.00	-5.42	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.96	39.32	62.28	74.00	-11.72	peak	
2		5350.000	7.99	39.32	47.31	54.00	-6.69	AVG	
3		5356.500	28.82	39.33	68.15	74.00	-5.85	peak	
4	*	5356.500	11.08	39.33	50.41	54.00	-3.59	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	106




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	24.32	39.32	63.64	74.00	-10.36	peak	
2		5350.000	7.21	39.32	46.53	54.00	-7.47	AVG	
3		5358.900	23.42	39.34	62.76	74.00	-11.24	peak	
4	*	5358.900	9.20	39.34	48.54	54.00	-5.46	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	242




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.25	39.32	62.57	74.00	-11.43	peak	
2	*	5350.000	7.27	39.32	46.59	54.00	-7.41	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	242

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	23.36	39.32	62.68	74.00	-11.32	peak	
2	*	5350.000	6.79	39.32	46.11	54.00	-7.89	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	484

Vertical




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1		5350.000	22.56	39.32	61.88	74.00	-12.12	peak	
2	*	5350.000	7.94	39.32	47.26	54.00	-6.74	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	484

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.04	39.32	61.36	74.00	-12.64	peak	
2	*	5350.000	7.54	39.32	46.86	54.00	-7.14	AVG	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.


Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	996



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.17	39.32	61.49	74.00	-12.51	peak	
2	*	5350.000	7.80	39.32	47.12	54.00	-6.88	AVG	

REMARKS:
 (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	996



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1	*	10579.66	49.53	-1.23	48.30	68.30	-20.00	peak	


REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	996

Horizontal




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5350.000	22.76	39.32	62.08	74.00	-11.92	peak	
2	*	5350.000	7.34	39.32	46.66	54.00	-7.34	AVG	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2A_TX AX (HE80) Mode 5290 MHz	RU configuration	996




No.	Mk.	Freq.	Reading Level	Correct Factor	Measurement	Limit	Margin		
		MHz	dBuV	dB	dBuV/m	dBuV/m	dB	Detector	Comment
1	*	10579.44	49.94	-1.22	48.72	68.30	-19.58	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
 (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE80) Mode 5530 MHz	RU configuration	26




No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5454.788	21.82	39.45	61.27	74.00	-12.73	peak	
2	*	5454.788	12.79	39.45	52.24	54.00	-1.76	AVG	
3		5460.000	22.05	39.46	61.51	74.00	-12.49	peak	
4		5460.000	5.97	39.46	45.43	54.00	-8.57	AVG	
5		5470.000	21.97	39.47	61.44	68.30	-6.86	peak	

REMARKS:

- (1) Measurement Value = Reading Level + Correct Factor.
- (2) Margin Level = Measurement Value - Limit Value.

Orthogonal Axis	X		
Test Mode	UNII-2C_TX AX (HE80) Mode 5530 MHz	RU configuration	26

Horizontal



No.	Mk.	Freq. MHz	Reading Level dBuV	Correct Factor dB	Measure- ment dBuV/m	Limit dBuV/m	Margin dB	Detector	Comment
1		5453.750	22.63	39.45	62.08	74.00	-11.92	peak	
2	*	5453.750	8.97	39.45	48.42	54.00	-5.58	AVG	
3		5460.000	22.30	39.46	61.76	74.00	-12.24	peak	
4		5460.000	5.38	39.46	44.84	54.00	-9.16	AVG	
5		5470.000	21.49	39.47	60.96	68.30	-7.34	peak	

REMARKS:

(1) Measurement Value = Reading Level + Correct Factor.

(2) Margin Level = Measurement Value - Limit Value.