



# WIRELESS FULL SIZE KEYBOARD with AIR MOUSE GO PLUS



WKB-5300CB

## QuickGuide English

www.adesso.com

### Limited Warranty

Adesso provides a one year limited warranty for all of its products against defects in material and workmanship.

During this period, Adesso will repair or replace any product which proves to be defective. However, Adesso will not warranty any product which has been subject to improper freight handling, shipping abuse, neglect, improper installation or unauthorized repair. The warranty will not cover products installed with components not approved by Adesso and products where the sealed assembly trace has been broken.

If you discover a defect, Adesso will, at its option, repair or replace the product at no charge to you provided you return it during the warranty period with freight charges pre-paid to Adesso. Before returning any product, you must obtain a Return Merchandise Authorization number (RMA). This RMA # must be clearly marked on the outside of the package you are returning for warranty service. Be certain to also include your name, shipping address (no PO Boxes), telephone number, and a copy of the invoice showing proof of purchase in the package.

### SUPPORT

FAQ: <http://www.adesso.com/faqs>.

Email Support: [support@adesso.com](mailto:support@adesso.com)

#### Telephone Support:

Toll Free: (800) 795-6788  
9:00AM to 5:00PM PST Monday - Friday

### Contents:

- Air Mouse Go Plus
- Wireless Full Size Keyboard
- Desktop charging cradle and USB charging cable
- 2.4 GHz USB Receiver
- Quick Start Guide
- Downloadable MotionTools software

#### Keyboard Specification:

Key Layout: 104-Key US Layout  
Key Type: Scissor-Switch Technology  
Wireless Technology: 2.4 Ghz Wireless Technology  
Distance: 30 ft (10m)  
Battery: AAA\*2  
Internet Hotkeys: 5 Hotkeys (Home, Email, Forward, Back, Search)  
Media Hotkeys: 7 Hotkeys ( Play/Pause, Stop, Next Track, Previous Track, Volume Down, and Mute)

Dimension: 17.5" x 5.3" x 0.7" (445 x 135 x 18.40mm)  
Weight: 1.20 lb (545g)


#### Mouse Specification:

Tracking Method: Optical Sensor  
Hand Orientation: Both Hands  
Wireless Technology: 2.4 Ghz Wireless Technology  
Distance: 100 ft (30m)  
Battery: Rechargeable Internal lithium-ion battery  
Dimension: 4.6 x 2.3 x 1.6 in (120 x 58 x 40mm)  
Weight: 0.28 lb (130g)

#### Requirement:

Operating System: Windows 10/8/7/Vista/XP  
Connectivity: Available USB Port


### Keyboard Overview




- 1 Home
- 2 E-mail
- 3 Previous
- 4 Next
- 5 Search
- 6 Play / Pause
- 7 Stop
- 8 Previous Track
- 9 Next Track
- 10 Volume Up
- 11 Volume Down
- 12 Mute
- 13 Windows Button
- 14 Function Key

### Getting Started


1 Make sure that your computer is turned OFF before installing the keyboard




2 Insert the USB receiver into an available USB port on your computer.



3 Turn on your computer, operating system will detect the device automatically, no driver required.



### Air Mouse Overview



#### A: Mouse Mode

- 1 Left Mouse Button
- 2 LED light
- 3 Right Mouse Button
- 4 Scroll Wheel
- 5 Backward Button
- 6 Forward Button
- 7 DPI Button
- 8 Lithium-ion Battery
- 9 Non-Function
- 10 Mouse Connect Button
- 11 2.4 GHz USB Receiver


#### B: Presenter Mode

- 1 Left Mouse Button
- 2 LED light
- 3 Right Mouse Button
- 4 Scroll Wheel
- 5 Page Up
- 6 Page Down
- 7 Gesture Button
- 8 Lithium-ion Battery
- 9 In-Air Activation Trigger
- 10 Mouse Connect Button
- 11 2.4 GHz USB Receiver


### Getting Started

1 Remove Insulator tab.


Press the release button on the bottom of the mouse and remove battery pack. Remove and discard the plastic insulator tab. Replace Battery.




2 Plug one end of the included USB charging cable into the desktop charger and the other end into an available USB port. Place the mouse on the charging cradle and charge for 4 hours. The LED will remain RED while charging.



3 Insert the USB receiver into an available USB port on your computer.



4 Press the connect button on the bottom of the mouse.



5 The computer will automatically detect and configure the Air Mouse.


6 Visit <https://www.adesso.com/downloads> the MotionTools software and enjoy gesture recognition for your favorite applications.

### In-Air Operation


7 Hold the mouse using a comfortable handshake position. Use your index finger to access the in-air activation trigger and your thumb to access the top mouse buttons.

#### Top Buttons


#### Trigger



8 Click and hold the in-air activation trigger then move the cursor over a target and release the trigger before clicking. This parks the cursor over the target and allows you to click more accurately.



9 Press and hold the gesture button and flex your wrist slightly in 8 ways to easily enable motion controls. You can define the motion control function in Motion Tool.



10 Double-clicking the in-air activation trigger puts the Air Mouse in motion mode so you can move the cursor without holding the trigger.

**FCC Caution.**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.