

英语说明书 BC26 Coospo

材质：80克光道林纸（偏黄色）单色双面印刷 风琴折

切线：——

折线：- - - -

版本	版本说明	修改日期	修改人	审核
A	生产	2021/10/28	郑春阳	谢海亮
品名 英语说明书 BC26 Coospo				
材料 英文说明书 BC26 91x67mm 80克 偏黄色光道林纸 单色双面印刷 风琴折 (Coospo)			产品型号	BC26
			物料编号/文件编号	53.BC26-0003-00
制图	日期	页次	比例	图档名
郑春阳	2021/10/28	1 / 1	1:1	53.BC26-0003-00
审核	日期	深圳市汇泰科电子有限公司		
谢海亮	2021/10/28	Shenzhen Fitcare Electronics Co.,Ltd.		
核准	日期			

封面

91 mm

67 mm

正面

USER MANUAL

GPS Bike Computer

Model : BC26

Button function

Up Left
 Short Press: Switch Data Type / Numerical Value

Left Down
 Short Press: Switch Data Type / Numerical Value
 Long Press: Enter / Exit Setting Mode

Right Button
 Short Press: Power on / Start Riding / Switch Settings
 Long Press: Power off / End the ride

Status Icons

	Time		Total riding time
	No satellite signal		Time zone
	Satellite signal level		Hour
	Alert sound on / off		Unit
	Riding		
	Manual pause (Auto pause)		
	Bluetooth connected		
	Battery level		
	Average speed		
	Maximum speed		
	Miles per hour		
	Kilometers per hour		
	Riding time		
	Distance		
	Altitude		
	Odometer (Total distance)		

Standard accessories

Main Device x 1 Charging Cable x 1 User Manual x 1

Standard bike mount x 1 Rubber pad for standard bike mount x 1 Big size rubber ring x 2 Small size rubber ring x 2

How to Install

Standard Mount Installation

1. Install the rubber pad onto the mount.
2. Tie the mount onto the bar with the rubber rings.
3. Tie up the mount.
4. Install the main device onto the mount.
5. Rotate the main device for 90 degrees.
6. Installation completed.

Charging

- 1 Please charge the device before first time use.
- 2 Please use DC 5V power adaptor for charging.
- 3 During the charging, the battery icon will flash until fully charged.

Open the rubber cover, connect the device with usb cable to charge.

USB DC 5V power adaptor / Computer

The product has a built-in battery. Do not throw the product into a fire. Please choose an adapter that meets the rated voltage of the device to charge the device to avoid damage to the device.

Acquiring Satellite Signals, Time Setting and Auto Backlight

Acquiring Satellite Signals
 This device can use speed sensor or GPS for speed tracking, when using please make sure the device is outdoor and under a clear view of sky. Usually it may take 15-90 seconds for the bike computer to locate satellite signals, remain stationary when acquiring satellite signals.

Time Setting
 The time and date will be calibrated automatically after locate the satellite signals.(Check how to set the time zone correctly, please refer to the time zone setting chapter).

Auto Backlight
 This device will automatically calculate the sunrise and sunset time, from the time half an hour before sun set to half an hour after sun rise, the backlight will be automatically lighted; the backlight will be turned off if no operation detected in 15 seconds.

Time Zone Setting

- 1.1 Long press to enter the setting mode (P1-P3), P1 time zone setting, the currently set numerical value flicker display;
- 1.2 Short press to switch numerical value;
- 1.3 Short press to confirm the current setting, and enter the next digit or the next setting (P2 metric / imperial setting);
- 1.4 The device will automatically save and exit after 15s no operation or long press to exit the setting.

Long press to increase or decrease the numerical value

Short press to increase or decrease the numerical value

Long press to save the settings and exit, if no operation for more than 15 seconds, automatically save and exit

Short press to confirm the current setting, enter the next digit or the next setting

Setting Metric and Imperial Units

- 1.1 Long press to enter setting mode (P1-P3), short press to enter P2 metric / imperial setting;
- 1.2 Short press to switch between metric (KMH) / imperial (MPH);
- 1.3 Short press to confirm the current setting and enter the next setting (P3 speed alert setting).

Setting flicker display

Short press to switch between metric (KMH) / imperial (MPH)(default KMH)

Short press to save the current setting and enter the next setting

Maximum Speed Alert Setting

- 1.1 Long press to enter the setting mode (P1-P3), short press to enter the P3 maximum speed alert setting, the currently set numerical value flicker display;
- 1.2 Short press to switch numerical value;
- 1.3 Short press to confirm the current setting and enter the next digit setting or the next setting;
- 1.4 Short press to set the prompt tone on / off, after the setting is completed, Long press to exit or no operation for 15s to automatically save and exit.

Setting flicker display

Short press to increase or decrease the number value

Short press to set alert on / off

GPS Positioning

1. Auto GPS positioning after the bike computer is power on. Please start cycling after the GPS positioning is successful.
2. Please make sure you are outdoor when positioning. Bad weather and dense forest may affect GPS signal. You can stand still 2-5 minutes to get more connections with satellites for better GPS signal.
3. If you lost GPS Positioning during riding, the speed data (real-time, average, maximum) will be displayed as "---", and the rest of the data remains the same.

Search signal Weak signal Normal signal Strong signal

No Speed data display

Cycling

Turn on the device, short press to start riding, short press to pause / start; Long press to end riding (when the speed is 0 or there is no data during riding, or when the speed is too low, the bike computer will automatic pause / automatic start). When there is no speed data during riding, the cycling computer will automatically enter dormant after 15 minutes, and it will return to the previous riding state after pressing to turn it on).

Countdown Long press to end

Short press Pause / start

Automatically Pause

Riding Data Display

- 1.1 Short press to cycle to switch real-time speed, maximum speed, and average speed.
- 1.2 Short press to switch time, distance, altitude and time & distance display mode automatically switch data.

Real-time Speed Maximum Speed Average Speed

3 seconds automatic cycle switching display

Short press, cycle switch

Time & distance display mode

Automatically switch data

Bluetooth Connection

- 1 Download CoospoRide in Google Play or App Store

Compatible with

- iOS 9.0 version and above, iPhone 4s and above
- Any Bluetooth 4.0 enabled Android device with Android 4.3 and above

Power on the bike computer;

- 2 Power on the bike computer;
- 3 Open the CoospoRide App, enter the binding cycling computer step, select the BC26 bike computer in the device list to bind the device, (the phone needs to turn on Bluetooth and allow Bluetooth permissions);

- 4 In the activity page of the App, click on the connected device to enter the record synchronization operation page (through the authorization to Strava in the App more settings, the computer data can be synchronized to the Strava platform at the same time);
- 5 Select the record to be synchronized and click , and the record on the bike computer will be deleted automatically after synchronization.

Basic Parameters

Wireless	Bluetooth
Display	FSTN Screen, 2.3 inch
Backlight	Yes
Locate mode	GPS & BDS
Storage Format	FIT
Water Resistance	IPX7
Weight	34g
Language	English
Battery Capacity	600mAh
Battery Life	20 hours for a single use after fully charged
Material	PC+ABS
Dimension	72.26x50x21.55 mm
File Transfer	Bluetooth (Specified App Compatible)

Manufacture : Shenzhen Fitcare Electronics Co., Ltd.
Address:6th Floor(south), Building A, Dingxin Science Park, Hongliang North 2nd Road, 67 District, Bao'an, Shenzhen, China.

Attention

The water resistant level of the bicycle computer is IPX7. It can be used in the rain if you close the protective cover on the back tightly. It is recommended to take down the bicycle computer and put it into waterproof bag if it rains heavily.

Responsibility Disclaimer

- The information contained in this manual just for reference. The product described above may be subject to alteration owing to the manufacturer's continuing research and development plans, without making an announcement in advance.
- We shall not bare any legal responsibility for any direct or indirect, accidental or special damages, losses and expenses arising from or in connection with this manual or the contained product.

背面

折法:上下折+风琴折

第一步:上下折

第二步:风琴折

封面

封面

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.