


THE OFFICIAL SOCCER BOTS GUIDEBOOK

For Age: 6+

IMPORTANT STATEMENT:


- Please read this manual carefully before operating your product and keep it for future reference
- When pairing Soccer Bots to the remote transmitter, please switch on the Bot first, then the transmitter. When pairing multiple Bots, pair them one at a time, not all at once
- Please operate this product in a clean, indoor area free of dust, hair and other foreign objects that may impede the Soccer Bot's functions and cause equipment breakdown

Soccer Bot Diagram




-1-

Transmitter Diagram




Transmitter Battery Instructions

Unscrew the battery cover on the back of the remote and then load 2 AAA batteries as indicated within the battery compartment. (Batteries are NOT INCLUDED, please do not mix old batteries with new ones or different brands.)



Charging/Replacing Soccer Bot Battery

When the Power Indicator of the Robot appears to slowly flash, the Soccer Bot has entered into Low Battery Mode and you will need to charge the Soccer Bot's battery.




Charging time of the battery is 60-70 minutes. USB indicator will be "ON" when charging, and "OFF" when fully charged. A full charge delivers 40+ minutes of operation.


-2-

Assembling the Controlling Bumpers


Align the Controlling Bumpers with the side slots and click into Beginner Mode or Pro Mode positions described below:



Assemble the Goal



Pairing




1. Confirm that the Soccer Bot and transmitter are both in the "OFF" position before beginning pairing sequence.
2. Switch on the Robot. The Soccer Bots Power Indicator will begin flashing slowly.
3. Switch on the Transmitter. The Soccer Bot's LED Power Indicator will remain on, indicating a successful pairing.


-3-

Operation

The Transmitter range extends up to 25 feet. Please operate your Soccer Bot within this range.




Move your Soccer Bot forward or backward using the directional keys on the left side of the Transmitter.




Spin your Soccer Bot left or right using the directional keys on the right side of the Transmitter.

2 Kicking Modes



Use the top right button to kick the ball on the ground with your Bot's right foot. Use the top left button to kick the ball in the air with your Bot's left foot.

Trim Adjustment



When your Soccer Bot is not moving in a straight line, press the left or right trim to correct your Bot's alignment.

-4-

FCC WARNING:

"THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES AND INDUSTRY CANADA LICENSE-EXEMPT RSS STANDARD(S). OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION."

THE USER MANUAL FOR AN INTENTIONAL OR UNINTENTIONAL RADIATOR SHALL CAUTION THE USER THAT CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

(SAMPLE) NOTE: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE.

SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

FCC RADIATION EXPOSURE STATEMENT

THIS EQUIPMENT COMPLIES WITH FCC RADIATION EXPOSURE LIMITS SET FORTH FOR AN UNCONTROLLED ENVIRONMENT. THIS EQUIPMENT SHOULD BE INSTALLED BETWEEN THE RADIATOR & YOUR BODY.

THE INFORMATION LISTED ABOVE PROVIDES THE USER WITH INFORMATION NEEDED TO MAKE HIM OR HER AWARE OF A RF EXPOSURE, AND WHAT TO DO TO ASSURE THAT THIS RADIO OPERATES WITHIN THE FCC EXPOSURE LIMITS OF THIS RADIO.

INDUSTRY CANADA (IC) WARNING:

THIS DEVICE COMPLIES WITH INDUSTRY CANADA LICENSE-EXEMPT RSS STANDARD(S). OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRABLE OPERATION OF THE DEVICE.

FRENCH EQUIVALENT:

LE PRÉSENT APPAREIL EST CONFORME AUX CNR D'INDUSTRIE CANADA APPLICABLE AUX APPAREILS RADIO EXEMPTS DE LICENCE. L'EXPLOITATION EST AUTORISÉE AUX DEUX CONDITIONS SUIVANTES : (1) L'APPAREIL NE DOIT PAS PRODUIRE DE BROUILLAGE, ET (2) L'UTILISATEUR DE L'APPAREIL DOIT ACCEPTER TOUT BROUILLAGE RADIOELECTRIQUE SUBI, MEME SI LE BROUILLAGE EST SUSCEPTIBLE D'EN COMPROMETTRE LE FONCTIONNEMENT.

IC RADIATION EXPOSURE STATEMENT:

THIS DEVICE IS IN COMPLIANCE WITH SAR FOR GENERAL POPULATION/UNCONTROLLED