

User Manual

M03

1. Getting to know your phone

1.1 Your Phone

1.2 Installing SIM card and battery

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.
- (4) Follow the sign for SIM1 and SIM2 on the phone to install SIM1 and SIM2. Please make sure that the golden contacts of the card face into the phone and the notched corner has the same direction with the card slot, then push the other side of the card gently until it fixes itself in the card slot.
- (5) Replace the battery with its golden contact part facing the set phone battery contact piece, and then replace the battery cover.

1.3 Installing Storage card

- (1) Hold on **【End Key】** for about three seconds to switch off the phone.
- (2) Remove the battery cover.
- (3) Remove the battery.

- (4) Follow the sign of the T-Card slot cover, push the T-Card into the slot, make sure that the gold contacts of the card face upwards, until the card fixes itself in the card slot.

1.4 Battery charging

Charged by the travel charger

- (1) Install the battery correctly into the phone.
- (2) Insert the lead of the travel charger to connecting slot of the phone, and then connect the charger to a standard power socket.

When charging is complete, unplug the charger from the standard power socket first, and then disconnect the phone and charger.

1.5 Power on/ off

1.5.1 Power on

Hold on **【End Key】** for three seconds to switch on the phone.

1.5.2 Power off

Hold on **【End Key】** for three seconds to switch off the phone.

2. Using Call Function

2.1 Making a call

- (1) On the Home Screen, input the area code and phone number.
- (2) Select **<Options → Call → Voice call → SIM1/SIM2>** to select SIM1 or SIM2 to call.

2.2 Answering or rejecting a call

2.2.1 Answer a call

When there is an incoming call, you can press **【Left Soft Key】** to answer.

2.2.2 Reject a call

When there is an incoming call, you can press **【End Key】** to reject it.

2.3 Adjusting call volume

During a call, you can press **【Up/Down Key】** to adjust the earphone volume.

2.4 Ending a call

Press **【End Key】** to end the call.

3. My files

This menu allows you to manage files stored in the phone or storage card.

4. Contacts

4.1 View a contact

Enter the phonebook, the phone is defaulted to show contact list with all entries.

4.2 Adding anew contact

On the Contacts list, select **<Options → New>** to create a new contact.

- ❖ **Phone:** You can input the contact name, mobile phone, etc. You can also set special ring for the contact entry.
- ❖ **SIM1:** The input record will be saved to SIM1, with each name one phone number.
- ❖ **SIM2:** The input record will be saved to SIM2, with each name one phone number.

5. Calls

5.1 call logs

5.1.1 Missed calls

Display recent calls unpicked up.

5.1.2 Dialed calls

Display recent calls dialed.

5.1.3 Received calls

Display recent calls received.

5.1.4 Rejected calls

Display recent calls rejected.

5.1.5 Delete all

Delete all the call entries.

5.1.6 Call timers

Select the desired SIM Card, and then you can view all relevant information about the SIM Card.

5.1.7 GPRS counter

You can view the detail about GPRS flowrate.

5.2 Call settings

5.2.1 Dual-SIM

- ❖ **Standby mode:** You can select the standby mode for SIM card, either to have one SIM card standby, or to have both SIM cards standby simultaneously.
- ❖ **Reply by original SIM:** You can activate the function to reply from current SIM card for call and SMS.
- ❖ **Set SIM name:** You can name the Card as you want.
- ❖ **Set SIM color:** You can set SIM color as you want.

5.2.2 Call divert

Based the set diverting conditions, incoming calls will be forwarded into voice mail or other numbers.

5.2.3 Call waiting (Need network support)

- ❖ **Activate:** If you set the function on, the network will alert you that there is an incoming call. You can keep current call and answer another one.
- ❖ **Off:** Cancel call waiting function, then the new incoming calls won't be answered while you're on the phone already.
- ❖ **Check status:** Select it to view current status of this function.

5.2.4 Call barring

This function helps you to restrict the incoming and outgoing calls.



Caution:

1. Some network operators forbid the function. For more details, please contact your network service provider.
2. The network operator will provide you the initial network password while you apply for this service.

5.2.5 Hide ID (Need network support)

- ❖ **Hide ID:** While calling, the recipient won't see your phone number.

- ❖ **Show ID:** While calling, your phone number will be visible for the recipient.
- ❖ **Set by network:** While calling, whether your phone number will be visible or not for the receiver depends on the network presetting.

5.2.6 Others

❖ IP prefix

After activating this function, selecting <**Options** → **Call** → **IP call**>, then preset IP number will be automatically added before the number you want to dial and call via it.

❖ Call time minute reminder

If you activate the function, an elapsed time reminder will be heard at the set second of every minute during your call, so that you may end the call timely to save the phone fare.

❖ Auto redial

If you set this function on, the phone will redial the number after an unsuccessful call.

❖ Vibration when connected

The phone will vibrate to prompt you when the recipient answers your phone.

❖ Reply SMS after reject

You can select whether to reply an SMS after rejecting a call.

❖ Auto record voice call

To record the call automatically.

6. Multimedia

6.1 Video recorder

Enter the main menu, and select [**Multimedia** → **Video recorder**] to enter the video preview screen, and press **【OK Key】** to start recording the video.

6.2 Image

The function provides a prompt access to view the photos and pictures.

6.3 Audio

Enter the main menu, and select [**Audio**] to enter the Audio Player screen:

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Left/Right Key】** to skip to last /next one
- ❖ Press **【Up/Down Key】** to adjust the playing volume

6.4 Video

Enter the Main menu, and click [**Multimedia** → **Video player**].

- ❖ Press **【OK Key】** to play or pause

- ❖ Press **【Up/Down Key】** to adjust the playing volume
- ❖ Press **【Left/Right Key】** to skip to last /next one

6.5 FM radio

Enter the Main menu, then select **【Multimedia→FM radio】**.

- ❖ Press **【OK Key】** to play or pause
- ❖ Press **【Left/Right Key】** to adjust the radio frequency.

Press **【Up/Down Key】** to adjust the playing volume

6.6 Recorder

Enter the main menu, select **【Multimedia→Recorder】**, and press **【OK Key】** to start recording. After ceasing the recording, the recorded file will be automatically save in the folder **【Audio】**, select **<Options→Record file list>** to check.

6.7 Snake

For specific operation, please refer to **Help** option of the game.

6.8 My files

This menu allows you to manage files stored in the phone or storage card.

8.1 Analog TV

Pull the antenna, enter the main menu, and select **【Multimedia→Analog TV】** to enter the TV function.

Press **【Left/Right Key】** to switch between last or next channel

Press **【Up/Down Key】** to adjust the volume

Press **【OK Key】** to display on full screen

7. Message

7.1 Write message

7.1.1 New SMS

Enter the main menu and select **【Message→Write message→New SMS】** to edit a new SMS directly.

After writing an SMS, select **<Send>** to send the message.

7.1.2 New MMS

Enter the main menu and select **【Message→Write message→New MMS】** to create a new MMS.

7.2 Inbox

Store all received SMS and MMS.

7.3 Outbox

Store all SMS and MMS failed to be sent.

7.4 Drafts

Save edited SMS and MMS haven't sent.

7.5 Sentbox

Store all the SMS and MMS successfully sent out.

7.6 Security message box

The mail security management.

4.6 Templates

While editing messages, you can directly cite the preset common phrases. Select <Edit> to set the common phrases by yourselves.

7.7 Broadcast message

You can receive broadcasttext messages with various contents via network service, such as news, weather or traffic information. For more details, please consult your network operator.

7.8 Voice mail server

This function works like an answering machine, which can transfer a missed call to your personal voice mail, allowing the caller to leave a voice message and notify you by an SMS. Voice Mail is a part of the bundled software provided by

network operator, therefore, you need to register to active this function, and manually set the phone. Please contact with your network operator for more details.

8. Profiles

The mobile phone provides multiple user profiles, so that you can customize some settings to adapt to the specific events and environments.

Customize the user profiles according to your preference and then activate the user profiles. The user profiles fall into seven scenarios: **Normal, Silent, Meeting, Indoor, Outdoor.**

9. Tools

9.1 Browser

Enter the wanted website, and select<OK> to connect it.



Caution:

1. Your network service provider may not support some functions. In order to ensure the browser work normally, please confirm first that your SIM card supports and have the Internet function activated.
2. If you browse the web page, flowrate fee

will be charged.

9.1.1 Bookmarks

Bookmarks are defaulted as blank, and you are able to edit it as you want. Save the common visited website into the Favorites, and marked by simple names. Select one saved name, then the corresponding web will be connected.

9.1.2 History

Record the websites you visited before.

9.1.3 Offline pages

After saving a website as snapshot, you can browse the website while offline.

9.2 Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc.

9.3 Alarm

On the Home Screen, press **【Left Soft Key】** to enter the main menu, and select **[Tools→Alarm]**, then you can set the alarm name, time, ring and mode.

9.4 Calculator

Directly input numbers, press **【Navigation Key】**

to select your desired operation symbols (+, -, /, X). Press **【OK Key】** to get the answer.

9.5 Bluetooth

With Bluetooth, you can make a wireless connection to other compatible devices, such as mobile phones, headsets and car kits. You can use the Bluetooth to send images, video clips, music, sound clips and notes, and transfer files from your compatible pc.

9.6 FlashLight

You can use this function to turn on/off the flashlight which situates at the top of the phone.

11.5 World clock

This function allows you to check the standard time in different areas of the world.

11.6 Stopwatch

Select **<Start>** to count.

9.5 Ebook

You can view file in TXT format by Ebook and copy the TXT file to the **[Ebook]** folder in the phone or memory card from your PC.

10. Settings

10.1 Phone settings

10.1.1 Date& time

- ❖ **Set time:** Directly input the time or press **【Up /Down Key】** to set it.
- ❖ **Set date:** Directly input the date or press **【Up /Down Key】** to set it.

10.1.2 Language settings

You can select the language you want.

10.1.3 Shortcut settings

You can change the responsible shortcuts for **【Navigation Key】** under standby mode.

10.1.4 Auto power on/off

You can set the phone to switch on/off at a scheduled time.

10.1.5 Power management

Display the battery capacity.

10.1.6 Restore factory settings

Reset all parameter values into default status. Please enter the privacy preserving password (Initial password is 1234 or 0000) to resume factory setting.

10.2 Display settings

10.2.1 Animation effect

You can select the preset animation or others as the power on/off animation for your phone.

10.2.2 Wallpaper settings

Select the default or other pictures as the wallpaper of the phone.

10.2.3 Idle display settings

You can select whether to display the time & date, SIM1, SIM2 on the idle screen.

10.2.4 Contrast

Press **【Left /Right Key】** to adjust the contrast.

10.2.5 Keypad backlight time

Select the desired keypad light time.

10.2.6 Auto keypad lock

After activating this function, the phone will be locked automatically if the time you set is arrived, so as to avoid error operations.

10.3 Security

10.3.1 PIN

PIN code is the personal identification number for SIM card. If never be modified, the initial password set by network operator should be 1234 or 0000. If activated the power-on PIN code, then you have to input the PIN password each

time you switch the phone on. You can modify the PIN code to prevent your SIM card being used by others.



Caution:

If you input your PIN code incorrectly three times in succession, the SIM card will be locked automatically, and prompting to enter PUK code to unlock it. Therefore, please do remember the PIN code, if you modify it.

PUK code (PUK1) is made up by 8 digits, unmodifiable. When the phone is locked by PIN code, please enter correct PUK code to unlock the phone. If you incorrectly input the PUK code ten times in succession, then the SIM card cannot be used any more. Some PUK codes are provided together with the SIM card, some should be gained from the network service provider. If you don't know the PUK code while your PIN code is locked, please never input the code casually. In this case, please call the hotline of the service provider for your SIM card, after simply checking about the user identity, you can gain the PUK code for free to unlock your phone.



Caution:

Please be careful when use this function. If you forget PUK code, please consult your network operator. If you incorrectly input the PUK code ten times in succession, the SIM card will be scrap.

10.3.2 Modify PIN2

PIN2 code is the personal identification code required for some certain functions (such as set fixed number, set phone fare, etc).

PIN2 code is another password provided together with SIM card by service provider. If wrongly input it for three times in succession, the phone will be locked until correct PUK2 code entered, for detailed operation, please refer to PIN code and PUK code.



Caution:

If you incorrectly input the PUK2 code ten times in succession, you will not be able to use SIM card. Please be careful when use this function.

10.3.3 Phone locked

After activated this function, you should input

password each time you switch the phone on.

The defaulted password is “1234 or 0000”.

10.3.4 Modify the cellphone password

You can change the phone password.

The defaulted password is “1234 or 0000”.

10.3.5 Privacy

Secured by phone password, the phone will be protected from other unauthorized users. When password function has been activated for call logs or message, you have to enter correct password on corresponding main menu or sub-menu. The defaulted password is “1234 or 0000”.

10.3.6 Lock screen by end-key

Once activated this function, when the backlight is on, press【End Key】to turn off the backlight and auto lock the keypad.

10.3.7 Guardlock

When the Guardlock is on, once your SIM card is replaced, the phone will automatically send stolen information to the prior SIM card.

10.3.8 Fixed dialing

After setting the fixed dialing number and activating this function, the phone can only dial the number you set.

10.3.9 Blacklist

He or she can't call you if you set the blacklist status to on and add his or her number to blacklist.

10.4 Connections

Through this function, you can select network and set preferred network.

11. Camera

Enter the main menu, and select [Camera] to enter the camera preview screen, press 【OK Key】 to take a photo.

12. FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a

circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6

W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is **0.742W/Kg** and when worn on the body, as described in this user guide, is **0.247W/Kg**(Body-worn measurements differ among phone models, depending upon available accessories and FCC

requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

FCC ID: 2ACQKTELCO002 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at

<http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 15mm must be maintained between the user's body and the handset, including the antenna.

Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components.

Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.