



AVGO 35" 2.1 Channel Bluetooth Soundbar
with Wireless Subwoofer

MODEL NO.: NOXPR

Made In China

Dear Customer,

Congratulations on purchasing this equipment. Please read this manual carefully and take note of the following hints on installation and use, to avoid technical damages.


Contents

Scope of Supply
Safety Instructions
Device Description
Remote Control
Operation
Technical Data
FCC Warning


Scope of Supply

- 1 Subwoofer
- 1 Sound bar
- 1 Audio cable
- 1 User manual
- 1 Remote control

IMPORTANT Safety Instructions


1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
 2. Keep these instructions – The safety and operating instructions should be retained for future reference.
 3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
 4. Follow all instructions – All operating and use instructions should be followed.
 5. Do not use this apparatus near water – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
 6. Clean only with dry cloth.
 7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
 8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
 9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
 10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
 11. Only use attachments/accessories specified by the manufacturer.
 12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 
13. Unplug the apparatus during lightning storms or when unused for long periods of time.
 14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
 15. CAUTION: These servicing instructions are for use by qualified service personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

Device Description




Soundbar (Back)

1. USB INPUT
2. AUX INPUT
3. DC INPUT
4. OPTICAL FUNCTION
5. HDMI FUNCTION(ARC Version)




Subwoofer (Back)

- A. MFB-WIRELESS CONNECTED
- B. WL LED-WIRELESS LED LIGHT
- C. DC INPUT



1. ⏮ : Skip to the previous track.
2. ⏭ : Skip to the next track
3. ⏪-Press this button to USB/AUX/Optical HDMI/Bluetooth mode.
4. ▶⏸ :Begin to play or pause the USB/Bluetooth Optical/HDMI mode.

Remote Control



1. POWER : Press this button to turn to Standby mode.
2. INPUT : Press this button to USB/AUX/Optical/HDMI/Bluetooth mode.
3. VOLUME+/-: Increase volume or reduce the volume
4. ⏮ : Skip to the previous track.
5. ▶⏸ : Begin to play or pause the USB/Bluetooth/Optical/HDMI mode.
6. TRE+/- : Increase treble or reduce treble
7. BASS+/- : Increase bass or reduce bass
8. EQ : To choose audio output sound field effect
9. 🔇 : To mute the sound
10. ⏭ : Skip to the next track

Operation

1. Firstly, plug the subwoofer & sound bar adaptor to the unit and external socket, then switch on the unit, the bar will turn up with red LED color.
Note: Adapter difference, 24V 2.5A for subwoofer, 20V 2.4A for bar only.
2. The default mode is a standby function. Press the power button on the remote control or touch the ⏪ but ton for 3-5seconds on the Sound bar to enter working status
3. When a USB card is inserted, it will play automatically.
4. In the Optical/HDMI(ARC) mode, take one Optical/HDMI cable and plug one side into Optical/HDMI port and the other side into TV port to connect.
5. Press INPUT key on remote controller, the unit enters into Bluetooth playback, LED display of bar front panel will flash in red color. Search for "NOXPR" on BT device and pair the devices with the speaker system, then LED display of bar front panel will keep lighting up in red color after connected successfully.
Note: BT working range is about 8 meters in an open area.

Technical Data

Item number	NOXPR
Power source	100-240 V~ 50/60 Hz
Power consumption	60 W
S/N Ratio	75 dB
Separation	>45dB
THD Distortion	<0.5% at 1W output @1KHz
Speaker Impedance	4 Ohm

FCC Warning

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation."

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

*NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help."

FCC Radiation Exposure Statement

This equipment complied with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.