


versa
WATER
WATER LEAK DETECTOR
2GIG COMPATIBLE

versa
WATER



Water Detector
Prevent floods, leaks
and overflows.

versa
WATER
WATER LEAK DETECTOR
2GIG COMPATIBLE

SPECIFICATIONS

PART NUMBER	Versa-Water
BATTERY	CR123A lithium battery (replaceable)
BATTERY LIFE	10 years (typical)
WARRANTY	5 years
RF MODULATION	ASK
RF FREQUENCY	345 MHz ± 15KHz
RF TRANSMISSION POWER	+9 to +13dBm
OPERATING VOLTAGE	2.2 ~ 3V
POWER CONSUMPTION	3µA
OPERATING HUMIDITY	0 - 90%
OPERATING TEMPERATURE	32°F (0°C) - 140°F (60°C)
STORAGE HUMIDITY	0 - 90%
STORAGE TEMPERATURE	32°F (0°C) - 104°F (40°C)
INDICATOR	Low Battery LED
TAMPER SWITCH	Yes

versa

For information on how to install the Versa
Wireless Water Leak Detector, please visit:
versawireless.com



©2018 Versa Wireless Inc. All rights reserved. Patent pending.
Country of Origin: China

FLOOD PREVENTION

Simply place the water detector in areas of your home or business where
leaks are likely to occur and be alerted at the first signs of a water leak.
Installing security has never been easier.



SIZE & WEIGHT

DIMENSIONS
Length: 3.5"
Width: 1.85"
Height: .85"
Weight: 1.76 oz

FCC statements

This device complies with FCC Rules Part 15. Operation is subject to the
following two conditions:
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference
that may cause undesired operation.



versa

For information on how to install the Versa
Wireless Water Leak Detector, please visit:
versawireless.com

2GIG COMPATIBLE

2GIG COMPATIBLE

Operating Instructions

The Versa Water is a wireless water detector with sensor cable designed to warn in case of floods, leaks, overflows and other potential water damage situations.

Installing the Versa Water

The sensor and transmitter can both be mounted using screws or double-sided tape (both included). For best results follow the directions below.

1. Remove the screw fastening the rear cover of the transmitter module and slide the rear cover off. Insert a CR123A battery into the battery compartment. The LED will flash multiple times to indicate the sensor is active.
2. Replace the rear cover and the fastening screw.
3. Install the transmitter module at a higher location for better RF range and away from potential water exposure.
4. Install the sensor at the desired monitoring location, keeping in mind that both metallic contacts will need to come in contact with water for proper notification.

Programming

The following steps describe general guidelines for programming (learning) the sensor into the alarm control panel memory. For more details, please refer to the security panel manufacturer's installation & programming instructions.

1. Program as **Day Zone (05)** on loop 3.
2. Takes 3 minutes and 3 seconds to trip and 3 minutes and 3 seconds to reset.
3. 2GIG panel firmware must be 1.0.1 or higher.

Box Contents

1. 1 Complete Water Sensor
2. 4 Mounting Screws
3. Strip of Double-Sided Tape
4. 1 Panasonic CR123A 3V Lithium Battery

FCC Statement

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

FCC Caution
"the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment."

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Statement

This Class (B) digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe (B) est conforme à la norme NMB-003 du Canada.

This device complies with RSS-210 and IC ES-003 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of this device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



Specifications

PART NUMBER	Water-2GIG
BATTERY	CR123A Lithium battery (replaceable)
BATTERY LIFE	10 years (typical)
WARRANTY	5 years
RF FREQUENCY	345 MHz ± 15KHz
RF TRANSMISSION POWER	-9 to +13dBm
OPERATING VOLTAGE	2.2 - 3V
POWER CONSUMPTION	3µA
OPERATING HUMIDITY	0 - 90%
OPERATING TEMPERATURE	32°F (0°C) - 140°F (60°C)
STORAGE HUMIDITY	0 - 90%
STORAGE TEMPERATURE	32°F (0°C) - 104°F (40°C)
INDICATOR	Low Battery LED
TAMPER SWITCH	Yes
FUNCTIONS	Flood Sensor
COLOR	White
DIMENSIONS (l x w x h)	3.9" x 1" x .85"
WEIGHT	1.76 oz