

USER MANUAL



SS1022B

USER MANUAL-EN
ユーザーマニュアル-JP

Includes:

- Soundbar
- Adaptor
- Optical cable
- Aux cable
- HDMI cable
- Coaxial cable
- Remote control
- Manual

IMPORTANT SAFETY INSTRUCTIONS

TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE AMPLIFIER PLATE. NO USER SERVICEABLE PARTS INSIDE. WE RECOMMEND TAKING THE UNIT TO A QUALIFIED SERVICE TECHNICIAN FOR ANY REPAIRS.


This sound bar was especially developed for LED/LCD/Plasma televisions. Don't combine it with CRT (Cathode Ray Tube)televisions, to avoid image interference.

- Do not place on an unstable surface. The speaker may fall over, causing serious injury to a child or adult and serious damage to the unit.
- Do not use near water, for example, near a bathtub, sink, in a wet basement, or near a swimming pool.
- The soundbar should be situated away from heat sources such as radiators, heat registers, stoves, or other devices that produce heat.
- These speakers should be connected to a power supply outlet of the same voltage as that which is specified on the unit. Protect the power cord from being stepped on or pinched, particularly at plugs, convenience receptacles, and the point where it exits from the unit.
- Clean only with a soft damp cloth. Unplug this product from the wall outlet before cleaning.
- Upon any servicing or repairs, request the service center/shop uses factory authorized replacement parts. Replacement with unauthorized parts may result in fire, electrical shock, or other hazards.

Sound Bar

M	Optical-Coaxial-HDMI/ARC-AUX-USB-BT
V+ / V-	PRV / VOL+
EQ	Movie/Game/Music
V- / V+	NEXT / VOL-
Power	Long Pressing for Power ON/OFF , Short Pressing for Pausing/Playing.


Usage Scenarios



Please Note:

- HDMI ARC interface can connect devices, such as TV, DVD etc.
- While if directly connected with standard HDMI, there may be no sound.

Remote Control



Bluetooth Paring

1. Connecting it to an AC power source, power-on.
The light on the sound amplifier button will flash steadily.
2. Turn on the phone Bluetooth and ensure that it is in "discoverable".
Switch Remote control (BT) into Bluetooth mode.
Choose " **SS1022B** " to connect.
3. Wait some seconds for paring.
Once paired, it will stop flashing and remain on.
4. Select one local music or online song to play.

Please note: playback functions(play/pause, volume, tracks)can be controlled from your bluetooth device (e.g. phone/mp3 player) and the remote.

USB

1. Connecting it to an AC power source, power-on.
2. Plug in your USB flash drive.
The unit will automatically read the files and begin playing music.
3. Can control playback(volume, tracks, play/pause, stop). via remote.
4. To exit USB mode you can remove your USB flash drive
or press the M button on unit to select another mode.

Please note: it supprts USB drive up to 32GB and the Mp3 file format, while the USB port does not support charging. And no matter in which mode, (local) music will be played automatically when the USB terminal is inserted.

AUX

Use the 3.5mm AUX jack to connect computers or any other external sound source with a 3.5mm output.

1. Connecting it to an AC power source, power-on. Pressing the M button on unit to switch the mode into AUX IN.
2. Use the cable with diameter of 3.5mm plug to connect the sound source.
3. Functions of the Prev and Next keys are not available in AUX, HDMI, Optical and Coaxial mode. Only works with bluetooth and usb mode.

Features

- BT+Aux in+Optical in+DSP output+HDMI ARC+USB+Speech Function+Coaxial
- Bluetooth Version: 5.0
- Bluetooth Distance: 10M
- Speaker output: 10W x 2 = 20W (RMS)
- Frequency response: 45Hz-20KHz
- Sensibility: $\geq 72\text{dB}$
- Degree of distortion $\leq 1\%$ (1K/1W)
- Power supply: DC:12V/ 2000mA ; AC:100-240 50Hz-60Hz
- Unit Size: L410*D74*H77mm

TROUBLESHOOTING

PROBLEM	SOLUTION
No power	1. Make sure the soundbar are plugged in and turned-on.
No sound	1. Make sure you've selected the proper source. 2. Make sure the volume is set properly on the unit and at the playback source (BLUETOOTH Android device, HDMI and AUX inputs).
Bluetooth pairing fails	1. Check to see that both devices are turned on and that your Bluetooth device is discoverable. 2. Turn both devices off and then on again. 3. Make sure you've selected the proper source. 4. Make sure that the Bluetooth device is within the supported distance of BT 5.0. 5. Move both devices away from other Bluetooth devices, microwaves, wireless routers, and other electronics. 6. Make sure that the unit is not paired to a previously paired device.
Files on USB memory device will not play back	1. Make sure you've selected the proper source. 2. Make sure that the audio files are in the MP3 format. 3. Make sure the memory device capacity is no more than 32 Gb.
No sound when receiving TV input	1. Make sure that all connections are secure. 2. If using HDMI, make sure that the TV has a dedicated HDMI ARC port. 3. Make sure the volume is set properly on the unit and at the television.

Warranty Card



If you have any questions about the products you received, please feel free to contact us via email.

- Detailed and thoughtful customer service
- Return guarantee within one month from the date of purchase
- Replacement guarantee within 12 months from the date of purchase

We will be very grateful if you share your impression of our products. Our belief is to respond to customers' needs with the best service.



desobry-service@outlook.com

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.