capello

User's Guide

Qi Wireless Charging Tray Clock
CA-80WC

HELLO,

Thanks for choosing Capello. We're a small team that believes in the simple joy of nicely designed products. If you need a hand, we're here to help you:

clocks@hellocapello.com

A little story from the designer:

I remember going to the science museum in Pittsburgh as a kid and seeing the electric arc between my hand and the Van de Graaff generator. Electricity though the air was like holding lightning. Wireless charging has been a long time coming to phones and it's so cool and convenient to simply set your phone down and have it charge. Welcome to the future!

Enjoy, *Matthew*

Installation

Plug in the AC/DC power adapter to an AC wall outlet and then plug its DC jack into the back of the clock. Your clock will turn on and is now ready to use.

Backup Battery Installation

- 1. Slide to remove the battery cover on the bottom of the clock.
- 2. Insert 2 new AA batteries (not included) with "+" and "-" ends of battery aligned as indicated (the "-" side of the battery touches the contact spring on your clock).
- 3. Replace the battery cover.
- Do not mix old and new batteries.
- Do not mix alkaline, standard and rechargeable batteries.
- Alkaline batteries are recommended

Setting Time

- On the top of the clock, press and hold ⊕, the hour digits "12" will flash. Press + or - to set the hours. (You can hold down to change the time faster.) As you cycle through, the hours will change from AM to PM.
- 2. Press \odot again, the minutes digits "00" will flash. Press + or to set the minutes.
- 4. Press ③ again to exit the setup (or if no key pressed for about 10 seconds it will automatically exit the setup).

Troubleshooting

If your clock is not functioning properly, it may be caused by electro-static discharge or other interference.

Unplug the DC jack and remove backup batteries, plug the DC jack to the clock. Reinstall the backup batteries after 10 seconds.

Your clock will reset to default settings and you will need to set it again.


Setting the Alarm


- Press and hold A, the hour digit will flash. Press + or to set the alarm hour. (You can hold down to change the time faster.) As you cycle through, the hours will change from AM to PM.
- 2. Press ♠ again, the alarm minutes digit will flash. Then press + or to set alarm minutes.
- 3. Press ♠ again, the snooze time "05" will flash. Then press + or to set snooze duration from 5-60 minutes.
- 4. Press **A** to exit the setup (or if no key pressed for about 10 seconds it will automatically exit the setup).

Adjusting the Display Brightness

Tap **SNOOZE** to adjust the brightness of the LED backlight.

NOTE: This can only be done when the adapter is being used to power the clock. If only the backup batteries are being used to power the clock, press **SNOOZE** to turn on the backlight for 10 seconds and then it will go off again.





Qi Wireless Charging

- Place your wireless device on top of the tray. Charging will begin on contact.
- When wireless charging, the LED indicator is continuously solid green.
- 3. There is a protective circuit that detects when foreign objects or devices that are not Qi certified are placed on the charging and will disable power to the charger as a safety precaution. When triggered the LED indicator will flash red and green.

NOTE: works with Qi devices including: iPhone 8, iPhone X iPhone XS, iPhone XR or newer iPhone models, compatible Android and Google Pixel phones.

USB Charging Mobile Devices

Connect the charging cable of your 5V devices to the USB port at the front of the clock, then connect the other end to your device. Your clock supplies 1A of power and will charge you phone or other devices automatically.

NOTE: Charging cables for your device are not included.

Using the Alarm

- 1. Press **a** once to activate Alarm 1 and the **a** icon will show on the display.
- Press A again to turn Alarm 1 off and the A icon will disappear from the display.

Repeat the same procedure using **4** to set Alarm 2.

Note: The Snooze duration is set during the alarm setup.

When the Alarm Sounds

To **SNOOZE**, tap the top of Sleep & Charge to snooze the alarm. The Snooze duration is set during the alarm setup.

To stop the alarm and reset it to sound again tomorrow, press any button on the top of your clock (besides the Snooze button). The alarm will stop buzzing and will be set to sound again tomorrow.

Product Care

- Place your clock away from areas with direct sunlight, excessive heat or moisture.
- 2. Protect your furniture when placing your clock on a natural wood and lacquered finish by using a cloth or protective material between it and the furniture.
- 3. Clean your clock with a soft cloth moistened only with mild soap and water. Stronger agents such as Benzine, thinner or similar materials can damage the surface of the unit.
- 4. Do not use old or used battery in your clock.
- 5. If the clock is not to be used for over a month or longer, remove the battery to prevent possible corrosion. If the battery compartment become corroded or dirty, clean the compartment and replace with new battery.

Specifications Alarm duration: 60 minutes (buzzer)

Snooze duration: 5-60 minutes (buzzer)
Defaults:Time - 12:00AM; Alarm 1 & 2 - 6:00AM Snooze - 5 minutes
Power: The output of the provided AC/DC adapter is 5V/2A

FCC Disclaime

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.