



**Front**



ORION


WIRELESS NECKBAND

## Instruction Manual




www.digitalessentials.technology

**Product overview**




- 1. Flexible Neckband
- 2. Charging Port
- 3. Vol+/Next Track
- 4. Vol-/Previous Track
- 5. LED Indicator/ Multi-function Button
- 6. Magnetic Clasp
- 7. Power Button


**Package contents**



Wireless Neckband x 1pc



Instruction Manual x 1pc



Micro USB Charging Cable x 1pc

**Power On/Off**

**Power on**  
 Slide button to 'ON' position to turn on the wireless neckband. It will vibrate for a second with a beep sound and the LED indicator will flash in blue and red.

**Power off**  
 Slide button to 'OFF' position to turn off the wireless neckband. It will vibrate for a second and the LED indicator will go out.

**Bluetooth pairing**

1. Keep the distance between your wireless neckband and mobile phone (or other devices) within 32.8 Feet.
2. Power on the wireless neckband and it will automatically turn to Bluetooth pairing mode. The LED indicator will flash in blue and red.
3. Activate the Bluetooth function on your phone within range and select "DEEP-0176" from the list shown.
4. You will hear a beep sound and the wireless neckband will vibrate for a second after pairing is successful.

**Reconnect Bluetooth**

When powered on, the wireless neckband will automatically connect with the last successfully paired device.

**Technical specification**

Driver Diameter:	10 mm
Frequency Response:	20 Hz - 20 KHz
Sensitivity:	105 dB +/- 3 dB
Impedance:	32 Ohms
Charging Time:	2 Hours
Playing Time:	2-3 Hours
Battery Capacity:	170 mAh
Battery Type:	Li-ion Battery 3.7 V
Receiver Distance:	≤ 32.8 Feet
Bluetooth Version:	4.2

**How to use**

**Volume control**

Long press + : Increase volume  
 Long press - : Decrease volume

**Track control**

Short press + : Play next track  
 Short press - : Play previous track

**Back**

**How to use**

**Answering a call**

When there is an incoming call, the wireless neckband will ring and vibrate, press the call button to answer the incoming call or answer the call via your mobile phone.

**Ending a call**

Press the call button once to end the call or hang up via your mobile phone.

**Rejecting a call**

Press the call button for 2 seconds when the wireless neckband rings.

**Redialing a call**


Double press the call button for redialing the last number that you just called.

**Charging product**

1. Use the Micro USB cable provided with this wireless neckband.
2. Open the cover, connect the Micro USB plug to Micro USB charging port on the wireless neckband, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
3. The light will turn red while charging and will turn off once fully charged.

**NOTE:**

- You must select a qualified charger from a regular manufacturer.
- You must charge the wireless neckband if it has been not used for more than 12 months.



**FAQ**

- **If the product cannot be paired with your device, please try the following:**  
 Ensure that your product is in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.
- **If the product will not turn on:**  
 Make sure the product is fully charged.
- **Can I change the battery for the product?**  
 This product uses a built-in non-detachable battery which cannot be removed.
- **If the product cannot be recharged:**  
 If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

**Digital Essentials 1-Year Limited Warranty**

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to product used for any industrial, professional or commercial purposes.

**Technical Assistance**

For service on any defective under 12 months warranty policy, please contact Consumer Support.

Email: consumersupport@zeeva.com

Digital Essentials is a brand of Zeeva International Ltd.  
**Keep All Relevant Information for Future Reference**

**⚠ Safety instructions for the rechargeable lithium ion battery and charging the product**

- The input voltage to the product is 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging this product.
- Only charge the product at ambient temperatures between 10 deg C/ 50 deg F and 40 deg C/104 deg F
- Do not heat above 70 deg C/158 deg F, e.g. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (e.g. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development

**FCC STATEMENT**

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
 (1) This device may not cause harmful interference.  
 (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**RF warning statement:**  
 The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ADMS-DEEP-0176