
Date: 28 June 2023 Product: EP-0686 IM

Size: 222.75(W) x 105(H)mm

Z E E V A

FRONT SIDE



FAQ

BACK SIDE

Recharge Charging Case Method 1 $_{\ensuremath{\Delta}}$ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product. 1. Use the USB Type-C charging cable provided with the packaging. 2. Connect the USB plug to a USB port on a computer or wall adapte then connect the USB Type-C plug to the USB Type-C charging port on the charging case to begin charging 3. The Battery Level Indicator on the charging case will be on and start flashing during charge. 4. Once fully charged, the Battery Level Indicator will stop flashing. 5. The LED will be on during earbuds is charging and will be off after You must select a qualified charger from a regular manufacturer. You must charge the charging case and earbuds if it has been not used for more than 6 months. USB Type-C Plug USB Plug

▲ CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

Recharge Charging Case

Method 2

You can also charge your Charging Case by wireless charging pad as below way. Put the BOTTOM of the charging case on the wireless charging pad as



Wireless charge will not start if USB charging is input from USB port.

Wireless charging pad is not included

If the wireless earbuds cannot be paired with your device.

please try the following: Ensure that your earbuds are in pairing mode or reconnection mode Ensure that Rigetonth search function of your mobile device is activated

If the wireless earbuds will not turn on Make sure the earbuds are fully charged.

Make sure the protective stickers are removed from the Earbuds

Can I change the battery for the earbuds and the charging case? which cannot be removed.

If the charging case cannot be recharged:
If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

-The input voltage to the product is 5V 1A.

-In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.

Only charge the product at ambient temperatures between 10 °C/50 °F and 40 °C/104 °F.

- Do not heat above 70 °C/158 °F, eg. Do not expose to sunlight or throw into fire.

-Switch off the product after use.

-Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this

product. -In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that
- may cause undesired operation.

 2. Changes or modifications not expressly approved by the party responsible for
- compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



FCC ID: 2ADM5-EP-0686

ITEM# EP-0686

Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China

Keep all relevant information for future reference