EP-0608 Instruction Manual

Size: 105(H) x 297(W) mm

	Product Overview	Package Contents
	Earbud	Core Wireless Earbud x 1 Portable Charging Case x 1 Micro USB Cable x 1 Instruction Manual x 1
CORE		Technical Specification
WIRELESS EARBUD INSTRUCTION MANUAL Thank you for purchasing the Core Wireless Earbud. This manual provides more information about the wireless earbud, please read the instructions before using.	Charging Case	WIRELESS EARBUD PORTABLE CHARGING CASE Driver Diameter: 8 mm Impedance: 16 Ohms Frequency Response: 20Hz-20KHz Sensitivity: 96 dB +/-3 dB Power Supply: Li-ion Battery 3.7V 40 mAh Playing Time: 1 - 1.5 hours Charging Time: 1.5 hours Bluetooth Range: 32.8 Feet
		Bluetooth Version: 5.0 Micro USB Cable Included
	6	Power On/Off
		 Power On Press and hold down the On/Off Button for 3 seconds and the LED will flash. Power Off
	1. Microphone 2. On/Off Button/	Proves and hold down the On/Off Button for 4 seconds and the LED will turn off.
	Play/Pause Music Answer/End Call	Pair the wireless earbud with your mobile device
	3. LED Indicator 4. Magnetic Charging Port 5. Charging Case Cover	 Keep the distance between your wireless earbud and mobile phone (or other devices) within 32.8 Feet.
	8 6. LED Indicator 7. Charging Port	2. Power on the wireless earbud. 3. Activate the Bluetooth function on your phone within range and select "BT CORE EARBUD" from the list shown.
	9 8. LED Indicator	BI CORE EARBOD IIOIII the list shown.
	9. Charging On/Off Button	4. The LED blinks in blue when paired successfully.
		 4. The LED blinks in blue when paired successfully. Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again.
Reconnect the wireless earbud to your mobile device	9. Charging On/Off Button	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT
Reconnect the wireless earbud to your mobile device When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference.
When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated.	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to th following two conditions: (1) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for
When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to th following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference tha may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button 9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. • If the wireless earbud will not turn on: Make sure the earbud are fully charged. • Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to th following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a
When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button 9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. • If the wireless earbud will not turn on: Make sure the earbud are fully charged. • Can I change the battery for the earbud?	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to th following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment guererates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction may cause harmful interference to radio communications. However, there is no may find the fourted to the substruction may cause harmful interference to radio communications.
When powered on, the wireless earbud will automatically connect with the last successfully paired device.	9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. • If the wireless earbud will not turn on: Make sure the earbud are fully charged. • Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which cannot be removed.	 Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to th following two conditions:
When powered on, the wireless earbud will automatically connect with the last successfully paired device. Disconnect the wireless earbud from your mobile device Power off the wireless earbud; or Switch off the Bluetooth on your mobile phone; or Leave the earbud 60ft away from your mobile phone or further. Answer / Reject a call When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone. Long press On/Off Button to reject a call.	9. Charging On/Off Button 9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. • If the wireless earbud will not turn on: Make sure the earbud are fully charged. • Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which cannot be removed. • If the wireless earbud cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.	 Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
When powered on, the wireless earbud will automatically connect with the last successfully paired device. Disconnect the wireless earbud from your mobile device Power off the wireless earbud; or Switch off the Bluetooth on your mobile phone; or Leave the earbud 60ft away from your mobile phone or further. Answer / Reject a call When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone.	 9. Charging On/Off Button FAQ If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. If the wireless earbud will not turn on: Make sure the earbud are fully charged. Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which cannot be removed. If the wireless earbud cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered. A Safety instructions for the lithium battery and charging the product The input voltage to the product is 5V 1A. In order to charge the product is 5V 1A. Only charge the product at ambient temperatures between 10 deg "C/ 50 deg "F 	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructor may cause harmful interference to radio or television reception, while can be determined by turning the enterstes uses and can radiate radio to to to be determined by turning the entertes uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructor may cause harmful interference to radio or television reception, while is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, while is no guarantee that interference by one or more of the following measures: - Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The
When powered on, the wireless earbud will automatically connect with the last successfully paired device. Power off the wireless earbud from your mobile device Power off the wireless earbud; or Switch off the Bluetooth on your mobile phone; or Leave the earbud 60ft away from your mobile phone or further. Answer / Reject a call When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone. Long press On/Off Button to reject a call. ind a call	9. Charging On/Off Button 9. Charging On/Off Button FAQ • If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. • If the wireless earbud will not turn on: Make sure the earbud are fully charged. • Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which cannot be removed. • If the wireless earbud cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered. • A Safety instructions for the lithium battery and charging the product • The input voltage to the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. • Only charge the product at mabient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/104 deg °F. • Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to so unlight or throw into fire.	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device may not cause harmful interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference with the instruction may cause harmful interference to radio communications. However, there is no guarantee that interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement:
When powered on, the wireless earbud will automatically connect with the last successfully paired device. Power off the wireless earbud from your mobile device Power off the wireless earbud; or Switch off the Bluetooth on your mobile phone; or Leave the earbud 60ft away from your mobile phone or further. Answer / Reject a call When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone. Long press On/Off Button to reject a call. Press the On/Off Button once to end the call or hang up your mobile phone.	9. Charging On/Off Button 9. Charging the product 9. Charging the product at ambient temperatures between 10 deg °C/ 50 deg °F 9. Do not heat above 70 deg °C/158 deg °F, eg.	Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference. (2) This device must accept any interference received, including interference that may cause undesired operation. 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the sequiration between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. RF warning statement: The device has been evaluated to meet general RF exposure requirement. The
When powered on, the wireless earbud will automatically connect with the last successfully paired device. Power off the wireless earbud from your mobile device Power off the wireless earbud; or Switch off the Bluetooth on your mobile phone; or Leave the earbud 60ft away from your mobile phone or further. When you receive a call, press the On/Off Button once to accept the call, or answer / Reject a call When you receive a call, press the On/Off Button once to accept the call, or answer the call normally via your mobile phone. Long press On/Off Button to reject a call. Fress the On/Off Button once to end the call or hang up your mobile phone. Charging your Earbud LED indicator light turns red when charging your earbud	 9. Charging On/Off Button FAQ If the wireless earbud cannot be paired with your device, please try the following: Ensure that your earbud are in pairing mode or reconnection mode Ensure that Bluetooth search function of your mobile device is activated. If the wireless earbud will not turn on: Make sure the earbud are fully charged. Can I change the battery for the earbud? The wireless earbud use a built-in non-detachable battery which cannot be removed. If the wireless earbud cannot be recharged: If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered. A Safety instructions for the lithium battery and charging the product The input voltage to the product in safe manner and reliable conditions, please only adopt certified appropriate chargerid adpet for charging the product. On the at above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire. Switch off the product afer use. Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. 	 Attention: If the pairing is not successful within 3 minutes, the earbud will power off, please repeat the pairing procedures to try again. FCC STATEMENT This device complies with Part 15 of the FCC Rules. Operation is subject to following two conditions: