




BT SPEAKER TABLE

Instruction Manual

Thank you for purchasing the Sound Top Wireless Speaker. This manual provides more information about this wireless speaker, please read the instructions before using.



Product Overview



① Micro USB Charging Port ② Led Indicator ③ On / Off Switch

Package Contents

Sound Top Wireless Speaker x 1
Leg x 3
EVA Sticker x 3

Micro USB Charging Cable x 1
Instruction Manual x 1


Technical specification

Driver Diameter: 102 mm
Impedance: 4 Ohms
Power Supply: Li-ion Battery 3.7V 1200 mAh
Playtime: 4-5.5 Hours
Charging Time: 2-3 Hours


Bluetooth Range: 32.8 Feet
Charging Method: USB Charging
Micro USB Charging Cable Included

How To Assemble


Screw the leg into the hole at the bottom panel of the table speaker.




Repeat the assembly sequence for the remaining legs.



Check all legs are well fixed.



Place a EVA sticker (Attached) on the bottom side of leg if uneven of table happened.



Power On/Off

Power on
Slide the Power Switch to On Position.
Power off
Slide the Power Switch to Off Position.

Note: Always power off the speaker when not in use.

Pair Wireless speaker with your mobile device

1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
2. Power on the wireless speaker.
3. Activate the Bluetooth function on your phone within range and select "BT SPEAKER TBL" from the list shown.
4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Charging your Wireless speaker

- ⚠ For your safety, please always use appropriate 5V input charger/Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.
- 1. Use the Micro USB charging cable provided with this wireless speaker
- 2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
- 3. The LED indicator will turn red while charging and will turn off once fully charged.

NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Wireless speaker if it has been not used for more than 6 months.



FAQ

- If the Wireless speaker cannot be paired with your device, please try the following:
Ensure that your speaker is in pairing mode or reconnection mode.
Ensure that Bluetooth search function of your mobile device is activated.
- If the Wireless speaker cannot be recharged:
If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

⚠ Safety instructions for the lithium battery and the product

- Make sure the product is cleaned thoroughly before using.
- Clean only with a slightly damp, lint-free cloth.
- The input voltage to the product is DC 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/ 104 deg °F.
- Do not heat above 70 deg °C/ 158 deg °F, eg. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Never put heavy objects or sit on the table. It's only handle less than 30 lbs.
- Do not use product for other than its intended use. Indoor use only. Do not use outdoors.
- This product has no waterproof function, so please do not put it in water or use it where there is water.
- Do not store or use the product at high temperature, humidity, and near the source of the fire.
- Don't disassemble, repair and transform them.
- In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



FCC ID: 2ADMS-SP-0161

ITEM# SP-0161

Distributed by 1616 Holdings, Inc.
701 Market Street, Suite 200
Philadelphia, PA 19106
Made in China

Keep All Relevant Information For Future Reference