Size: H: 100mm x W: 195mm



# **Product Overview** 2 < Button 3 > Button 6 USB Type-C Charging port A LED Indicator 00000

### Package Contents

1(One) Aura Wireless Speaker 5.5in. x 5.5in. x 5in.(14cm x 14cm x 12.7cm) 1(One) USB Type-C Charging Cable 19.7in. (50cm)

Power on
Press the ON/OFF button for 3 seconds and enter Bluetooth Mode. The clock lights up

# Power off Press the ON/OFF button for 3 seconds. Automatic shutdown after 5 minutes of no connection or 5 minutes of pause.

### Pair Wireless speaker with your mobile device

- Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
- 2. Power on the wireless speaker
- Activate the Bluetooth function on your phone within range and select "SP-0252 SPK" from the list shown.
- 4. You will hear a beep sound when pairing is successful.

### Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last

### **Technical Specification**

Driver Diameter: 52 mm Impedance: 3 Ohms Speaker Power : 5W Power Supply: Li-ion Battery 3.7V 500 mAh Playtime: 1.5-2 Hours

Charging Time: 1.5-2 Hours Bluetooth Range: 32.8 Feet Bluetooth Version: 5.3

USB Type-C Charging Cable Included

## **Bluetooth Mode**

- 1 Short press On/Off Button to Play or Pause the music
- . Short press the < or > Buttons to switch to next or previous track
- 3. Long press the < or > Buttons to tune the volume up or down.

### TWS Mode (2pcs Aura Wireless Speaker is needed for TWS mode)

- 1. Turn On both wireless speakers.
- 2. Disconnect both wireless speakers from any Bluetooth device
- Keep both wireless speakers side by side.
   Double press the Mode Button on ONE of the wireless.
- speakers. And then it will have an alert sound.

  5. The wireless speakers will paired in few seconds. When successfully
- paired, both wireless speakers will have another alert sound.
- 6. Now you can follow the "Pair Wireless speaker with your mobile device" to pair with the mobile device.
- 7. To disable the TWS mode, double press on the Mode Button on ONE of
- he wireless speakers. They will have an alert sound and then unpaired

NOTE: TWS mode is not supported in FM mode

- In Bluetooth or FM Mode, double press the Power button to turn on/off the clock display
- Short press the Mode Button in Bluetooth Mode will enter to Clock Only Mode.
   Short press the Mode Button again will enter to FM Mode.
   Or, long press the Mode Button to enter Clock Adjustment Mode.

### Clock Adjustment Mode

Digital Clock

- 1. Short press Mode Button to switch hour and minute.
  2. Short press < or > Button to increase or decrease 1 hour/minute.
  3. Long press < or > Button to increase or decrease continuously.
- 4. Long press Mode Button to exit Clock Adjustment Mode. Note: The clock data will be lost when the battery is drained. Please connect to a wall

- Plug-in the USB-Type-C charging cable as FM antenna.
   Long press Mode Button to start auto scanning FM channels or stop scanning.
- 3. Short press < or > Button to switch channels.
  4. Long press < or > Button to adjust the volume.
  5. Long press the Mode Button to enter Bluetooth Mode

## Charging your Wireless speaker

- ⚠ For your safety, please always use appropriate 5V output charger/Adapter to charge the product. DO NOT USE Culcic Charging (USS Adapter to charge the product, as it might dismage the product. It use the USS Type-C charging cashe provided with the packaging.
  2. Connect the USS Type-C pulg to USS Type-C charging port on the product, then connect the USS type to a wail adaptive to begin charging.
  3. The LED on the product will be on during charge.
  4. Once thigh charged, the LED will be of the charge.

NOTE:

You must select a qualified charger from a regular manufacturer.

You must charge the product if it has been not used for more than 6 months.



# USB Type-C Charging Cable rating 5V/1A Max.

▲ CAUTION: The USB Type-C charging cable included with this item is intended for use with this product. Only use the included USB Type-C charging cable to charge this product.

- If the Wireless speaker cannot be paired with your device, please try the following:
   Ensure that your speaker is in pairing mode or reconnection mode. Ensure that Bluetooth search function of your mobile device is activated.

- If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

-The input voltage to the product is DC 5V 1A

- -In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product. -Only charge the product at ambient temperatures between 10°C/50°F and 40°C/104 °F.
- Do not heat above 70°C/158°F. Do not expose to sunlight or throw into fire. -Switch off the product after use.

-Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product.

-In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development

The Bluetooth® word mark and logos are registered trademarks owned by

Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners

# FCC Statement

This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.

- · Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the
- · Consult the dealer or experienced radio/ TV technician for help

### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



FCC ID: 2ADM5-SP-0252

Item# SP-0252

Class 1 LED product

Keep All Relevant Information for Future Reference