

SPECTRUM WIRELESS SPEAKER


Instruction Manual

Thank you for purchasing the Spectrum Wireless Speaker. This manual provides more information about this wireless speaker, please read the instructions before using.





Product Overview



- 1, LED Indicator (Speaker) USB Type-C Charging
 Port (Speaker)
 Power On/Off
- 4. Bluetooth
- FM Radio Button
- 5. Volume Up / Next Song Button
 6. Volume Down / Previous
 Song Button
 7. USB Type-C Charging
- Port (Charging Dock) 8. LED Indicator

(Charging Dock)

Package Contents

1(One) Spectrum Wireless Speaker with Charging Dock 4.1in. x 7.6in. x 4.1in. (10cm x 19.3cm x 10cm)

1(One) Charging Cable 19.7in. (50cm) 1(One) Instruction Manual

Power On/Off

Power on Press and hold 2 second on the Power Button.
Power off Press and hold 2 second on the Power Button. Note: Always power off the speaker when not in use

Pair Wireless speaker with your mobile device

- 1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32 Feet.
- 2. Power on the wireless speaker.
- Activate the Bluetooth function on your phone within range and select "SP-0255 SPK" from the list shown.
- 4. You will hear a beep sound when pairing is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Charging your Wireless speaker

⚠ For your safety, please always use appropriate 5V output charger/ Adapter to charge the product. **DO NOT USE** Quick Charging USB Adapter to charge the product, as it might damage the product.



- 1. Use the USB Type-C charging cable
- 1. Use the USB Type-C charging cable provided with this wireless speaker.
 2. Connect the USB Type-C plug to USB Type-C port on the charging dock, then connect the USB plug to the wall adapter.

 The LED Indicator on the Charging Dock will always on.
- Dock will always on. 3. Place the wireless speaker on to the
- charging dock to begin charging.

 The LED Indicator on the wireless speaker will turn red while charging and will turn off once fully charged.

Charging your Wireless speaker without Charging Dock

- Use the USB Type-C charging cable provided with this wireless speaker.
 Connect the USB Type-C plug to USB Type-C charging port on the speaker, then connect the USB plug to a wall adapter to begin charging.
- 3. The LED Indicator will turn red while charging and will turn off once

You must select a qualified charger from a regular manufacturer.
 You must charge the Wireless speaker if it has been not used for more than 6 months.



Bluetooth Mode

Short press Power Button to Play or Pause the music.
Short press the Volume Up or Down Buttons to switch to next or previous track.
Long press the Volume Up or Down Buttons to tune the volume.

Change to FM Radio Mode

Short press the Mode Button once to change to FM Radio mode. Short press the Mode Button twice to scan channels. Short press the Volume Up or Down Buttons to switch to next or previous channel.

Long press the Volume Up or Down Buttons to tune the volume t press the Mode Button once again to change to Bluetooth mode.

Technical specification

Specifications: Speaker Power: 5W Driver Diameter: 52 mm Impedance: 4 Ohms Playing Time: 1.5 - 2 Hours

ver Supply: Li-Ion Battery 3.7V 300 mAh Bluetooth Range: 32 feet Bluetooth Version: 5.3 USB Type-C Charging Cable Included

Charging Time: 1.5 - 2 Hours USB Type-C Charging Cable Rating 5V/1A Max.

FAQ

If the Wireless speaker cannot be paired with your device, please try the following:
 Ensure that your speaker is in pairing mode or reconnection mode.
 Ensure that Bluetooth search function of your mobile device is activated.

. If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works.

⚠ Safety instructions for the lithium battery and charging the product

The input voltage to the product is DC 5V 1A.

In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/adapter for charging the product, Only charge the product at ambient temperatures between 10°C/50°F and 40°C/104°F.

40°C/104°F.
Do not heat above 70°C/158°F, eg. Do not expose to sunlight or throw into fire.
-Switch off the product after use.
-Please note that we won't take any responsibility for any wrong operation (eg.
-Voltage higher than 5V) as this may result in severe injury or loss of property,
and we cannot control the operating process during the time the user using this
product

In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

FCC STATEMENT

This device complies with the part 15 of the FCC rules. Operation is subject to the Inis device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are class B digital device, pursuant to Part 15 of the PCC Rules. Inese limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. The user is encouraged to

- try to correct the interference by one or more of the following measures:

 Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or experienced radio/ TV technician for help.

RF Warning Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

The Bluetooth* word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by 1616 Holdings, Inc. is under license. Other trademarks and trade names are those of their respective owners.



FCC ID: 2ADM5-SP-0255

Keep All Relevant Information

For Future Reference

ITEM# SP-0255

Distributed by 1616 Holdings, Inc. 701 Market Street, Suite 200 Philadelphia, PA 19106 Made in China