

Waterproof Bluetooth Speaker



FEATURES:

- Bluetooth® enabled
- Waterproof for use in the shower, pool side, beach, or outdoors (not intended for use submerged under water)
- Clear audio streaming from your favourite app
- Built-in mic for handsfree phone calls
- Suction cup allows for attachment to any smooth flat surface

SPECIFICATIONS:

- Works with all Bluetooth® enabled devices
- Battery life: approximately 4 hours of use when fully charged
- Battery charge time – 3 hours
- Bluetooth pairing name – BOWER SPEAKER2
- Range – 3.3 ft / 10 meters
- Power supply – DC5V/100-120mA
- Battery – 3.7V400mAh Lithium

BOX CONTAINS:

- Waterproof IPX4 Bluetooth® Speaker with handsfree mic
- Suction cup
- Micro USB charging cable

BLUETOOTH PAIRING INSTRUCTIONS:


- 1) Press and hold the Power On/Off button for about 6 seconds, until the blue LED light flashes
- 2) Activate your Bluetooth® device by going to your device settings and scan for a new Bluetooth® pairing called BOWER SPEAKER2
- 3) Connect your device to BOWER SPEAKER2
- 4) If asked for a password, type in 0000 (four zeros)

TROUBLESHOOTING:

| SYMPTOM | CAUSE | SOLUTION |
|---------------------------------|--------------------------------|--|
| Speaker will not turn on | Battery is empty | Fully charge the battery by connecting the speaker with the Micro USB charging cord to a safe power source |
| Speaker will not pair to device | Speaker is not in pairing mode | Refer to above Bluetooth® pairing directions and look for BOWER SPEAKER2 on your Bluetooth® enabled device |

MUSIC / PHONE MODES:

- Press to turn On/Off speaker
- Short press for previous song, long press to turn down the volume
- Short press for next song, long press to turn up the volume
- Press the Phone button to answer or hang-up a phone call
- Press the phone button twice to redial the last phone number called
- Press to Play/Pause music



RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 5mm between the radiator and any part of your body.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CHARGING:

- Insert the micro USB charging cable into the DC5V socket found at the side of the speaker
- Connect the USB end to a power source
- The battery is charging when the red LED indicator light is on
- Once the battery is fully charged, the LED light will turn off

NOTICE:

- Do not insert metal objects into charging port
- Do not take apart or try to fix this product yourself
- Do not place this product into a fire
- Do not submerge speaker under water

For a Class B digital device or peripheral, the instructions furnished the user shall include the following or similar statement, placed in a prominent location in the text of the manual:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

