
Set in Stone Desktop Bluetooth Speaker

Instruction Manual DSBT065A-C

FRAGILE HANDLE WITH CARE



Functions:

- 1. Micro USB Port
- 2. LED Indicator
- 3. 3.5mm Aux input port
- 4. ON/OFF Switch

What's included:

- 1 x Cement Desktop Bluetooth Speaker
- 1 x USB to Micro-USB Cable
- 1 x Instruction Manual

Tech Specifications

- · Pairing Name: "Set in Stone BT speaker" Input: 5V/1A
- · Playback time at max volume: 6hrs
- · Charge time: 4hrs

Instructions:

- 1. Charging the Bluetooth Speaker
- . Connect the provided charging cable to a power source and to the Micro USB input port(1) on the speaker.
- The charging LED indicator(2) will glow RED when charging and will turn off when fully charged.

2. Bluetooth® Setup:

- . Turn ON/OFF switch(4) to the ON position. LED Indictor will flash BLUE and tone
- · Turn on the Bluetooth function on mobile device. Select "Set in Stone BT speaker" pairing name.
- A tone will prompt and bluetooth LED indicator(2) will turn solid BLUE if successfully paired.
- · Use your mobile device to cycle between songs and adjust the volume.
- * Speaker will automatically pair if the mobile device has been paired before.
- . Turn ON/OFF switch to the OFF position to turn off the device.

4 Aux Connection:

. Connect a AUX cable (NOT INCLUDED) to the 3.5mm Aux input port(3) of the speaker and mobile device to play music directly.

SAFETY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed:
- 1. Read all the instructions before use.
- 2. Never store or use this product in temperatures below 32°F(0°C) or above 115°F(45°C).
- 3. Do not overcharge Phone. Unit may get hot with excessive use. Remove Phone when it is fully charged. Never charge for more than 7 hours at a time.

- 4. To reduce the risk of injury, close supervision is necessary when the product is used near children.
- 5. Do not expose the device to moisture.
- 6. Do not use the device in excess of its output rating. Overload outputs above
- rating may result in a risk of fire or injury. 7. Do not use the device if damaged or
- modified 8 Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 9. Do not expose the device to fire or excessive temperature. Exposure to fire or temperatures above 104°F may cause explosion.
- 10. Ensure that qualified service professionals use only identical replacement parts to ensure product safety

FCC Statement:

- · This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- * Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority

to operate the equipment.

FC MADE IN CHINA



FSC® C161647

FSC 31.2 mm MIX Paper from responsible sources

20 mm



FSC® C161647

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.