



PSD NVNT n20 5260MHz Ant1



PSD NVNT n20 5320MHz Ant1



PSD NVNT n20 5500MHz Ant1



PSD NVNT n20 5700MHz Ant1



PSD NVNT n20 5745MHz Ant1



PSD NVNT n20 5825MHz Ant1



PSD NVNT n40 5190MHz Ant1



PSD NVNT n40 5230MHz Ant1



PSD NVNT n40 5270MHz Ant1



PSD NVNT n40 5310MHz Ant1




PSD NVNT n40 5510MHz Ant1



PSD NVNT n40 5670MHz Ant1




PSD NVNT n40 5755MHz Ant1



PSD NVNT n40 5795MHz Ant1




PSD NVNT ac20 5180MHz Ant1



PSD NVNT ac20 5240MHz Ant1




PSD NVNT ac20 5260MHz Ant1



PSD NVNT ac20 5320MHz Ant1



PSD NVNT ac20 5500MHz Ant1



PSD NVNT ac20 5700MHz Ant1



PSD NVNT ac20 5745MHz Ant1



PSD NVNT ac20 5825MHz Ant1



PSD NVNT ac40 5190MHz Ant1



PSD NVNT ac40 5230MHz Ant1



PSD NVNT ac40 5270MHz Ant1



PSD NVNT ac40 5310MHz Ant1




PSD NVNT ac40 5510MHz Ant1




PSD NVNT ac40 5670MHz Ant1




PSD NVNT ac40 5755MHz Ant1



PSD NVNT ac40 5795MHz Ant1



PSD NVNT ac80 5210MHz Ant1



PSD NVNT ac80 5290MHz Ant1




PSD NVNT ac80 5530MHz Ant1



PSD NVNT ac80 5610MHz Ant1





ANT2

Test Graphs
PSD NVNT a 5180MHz Ant2



PSD NVNT a 5240MHz Ant2



PSD NVNT a 5260MHz Ant2



PSD NVNT a 5320MHz Ant2



PSD NVNT a 5500MHz Ant2



PSD NVNT a 5700MHz Ant2




PSD NVNT a 5745MHz Ant2



PSD NVNT a 5825MHz Ant2




PSD NVNT n20 5180MHz Ant2



PSD NVNT n20 5240MHz Ant2



PSD NVNT n20 5260MHz Ant2



PSD NVNT n20 5320MHz Ant2



PSD NVNT n20 5500MHz Ant2



PSD NVNT n20 5700MHz Ant2



PSD NVNT n20 5745MHz Ant2



PSD NVNT n20 5825MHz Ant2




PSD NVNT n40 5190MHz Ant2



PSD NVNT n40 5230MHz Ant2



PSD NVNT n40 5270MHz Ant2



PSD NVNT n40 5310MHz Ant2



PSD NVNT n40 5510MHz Ant2



PSD NVNT n40 5670MHz Ant2



PSD NVNT n40 5755MHz Ant2



PSD NVNT n40 5795MHz Ant2



PSD NVNT ac20 5180MHz Ant2



PSD NVNT ac20 5240MHz Ant2




PSD NVNT ac20 5260MHz Ant2




PSD NVNT ac20 5320MHz Ant2



PSD NVNT ac20 5500MHz Ant2



PSD NVNT ac20 5700MHz Ant2




PSD NVNT ac20 5745MHz Ant2



PSD NVNT ac20 5825MHz Ant2



PSD NVNT ac40 5190MHz Ant2



PSD NVNT ac40 5230MHz Ant2



PSD NVNT ac40 5270MHz Ant2



PSD NVNT ac40 5310MHz Ant2




PSD NVNT ac40 5510MHz Ant2




PSD NVNT ac40 5670MHz Ant2



PSD NVNT ac40 5755MHz Ant2



PSD NVNT ac40 5795MHz Ant2



PSD NVNT ac80 5210MHz Ant2



PSD NVNT ac80 5290MHz Ant2




PSD NVNT ac80 5530MHz Ant2



PSD NVNT ac80 5610MHz Ant2





4. Frequency Stability

4.1 Ant1

4.1.1 Test Result

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	a	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NVNT	a	5260	Ant1	5259.98	-20000	-3.8	25	Pass
NVNT	a	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NVNT	a	5500	Ant1	5499.96	-40000	-7.27	25	Pass
NVNT	a	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NVNT	a	5745	Ant1	5744.94	-60000	-10.44	25	Pass
NVNT	a	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NVNT	n20	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	n20	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NVNT	n20	5260	Ant1	5259.98	-20000	-3.8	25	Pass
NVNT	n20	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NVNT	n20	5500	Ant1	5499.96	-40000	-7.27	25	Pass
NVNT	n20	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NVNT	n20	5745	Ant1	5744.98	-20000	-3.48	25	Pass
NVNT	n20	5825	Ant1	5824.94	-60000	-10.3	25	Pass
NVNT	n40	5190	Ant1	5189.96	-40000	-7.71	25	Pass
NVNT	n40	5230	Ant1	5229.96	-40000	-7.65	25	Pass
NVNT	n40	5270	Ant1	5270	0	0	25	Pass
NVNT	n40	5310	Ant1	5309.96	-40000	-7.53	25	Pass
NVNT	n40	5510	Ant1	5509.92	-80000	-14.52	25	Pass
NVNT	n40	5670	Ant1	5669.96	-40000	-7.05	25	Pass
NVNT	n40	5755	Ant1	5754.96	-40000	-6.95	25	Pass
NVNT	n40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ac20	5180	Ant1	5179.96	-40000	-7.72	25	Pass
NVNT	ac20	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NVNT	ac20	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NVNT	ac20	5320	Ant1	5319.94	-60000	-11.28	25	Pass
NVNT	ac20	5500	Ant1	5499.94	-60000	-10.91	25	Pass
NVNT	ac20	5700	Ant1	5699.98	-20000	-3.51	25	Pass
NVNT	ac20	5745	Ant1	5744.94	-60000	-10.44	25	Pass
NVNT	ac20	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NVNT	ac40	5190	Ant1	5189.96	-40000	-7.71	25	Pass
NVNT	ac40	5230	Ant1	5230	0	0	25	Pass
NVNT	ac40	5270	Ant1	5270	0	0	25	Pass
NVNT	ac40	5310	Ant1	5310	0	0	25	Pass
NVNT	ac40	5510	Ant1	5510	0	0	25	Pass
NVNT	ac40	5670	Ant1	5669.96	-40000	-7.05	25	Pass
NVNT	ac40	5755	Ant1	5755	0	0	25	Pass
NVNT	ac40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ac80	5210	Ant1	5210	0	0	25	Pass
NVNT	ac80	5290	Ant1	5290	0	0	25	Pass
NVNT	ac80	5530	Ant1	5529.92	-80000	-14.47	25	Pass
NVNT	ac80	5610	Ant1	5610	0	0	25	Pass
NVNT	ac80	5775	Ant1	5775	0	0	25	Pass

4.1.2 Test Graph

<p>Test Graphs</p> <p>Freq. Stability NVNT a 5180MHz Ant1</p>



Freq. Stability NVNT a 5240MHz Ant1



Freq. Stability NVNT a 5260MHz Ant1



Freq. Stability NVNT a 5320MHz Ant1



Freq. Stability NVNT a 5500MHz Ant1



Freq. Stability NVNT a 5700MHz Ant1




Freq. Stability NVNT a 5745MHz Ant1



Freq. Stability NVNT a 5825MHz Ant1



Freq. Stability NVNT n20 5180MHz Ant1



Freq. Stability NVNT n20 5240MHz Ant1



Freq. Stability NVNT n20 5260MHz Ant1



Freq. Stability NVNT n20 5320MHz Ant1




Freq. Stability NVNT n20 5500MHz Ant1



Freq. Stability NVNT n20 5700MHz Ant1



Freq. Stability NVNT n20 5745MHz Ant1



Freq. Stability NVNT n20 5825MHz Ant1



Freq. Stability NVNT n40 5190MHz Ant1



Freq. Stability NVNT n40 5230MHz Ant1



Freq. Stability NVNT n40 5270MHz Ant1




Freq. Stability NVNT n40 5310MHz Ant1



Freq. Stability NVNT n40 5510MHz Ant1



Freq. Stability NVNT n40 5670MHz Ant1



Freq. Stability NVNT n40 5755MHz Ant1



Freq. Stability NVNT n40 5795MHz Ant1




Freq. Stability NVNT ac20 5180MHz Ant1



Freq. Stability NVNT ac20 5240MHz Ant1



Freq. Stability NVNT ac20 5260MHz Ant1



Freq. Stability NVNT ac20 5320MHz Ant1




Freq. Stability NVNT ac20 5500MHz Ant1



Freq. Stability NVNT ac20 5700MHz Ant1



Freq. Stability NVNT ac20 5745MHz Ant1



Freq. Stability NVNT ac20 5825MHz Ant1



Freq. Stability NVNT ac40 5190MHz Ant1



Freq. Stability NVNT ac40 5230MHz Ant1



Freq. Stability NVNT ac40 5270MHz Ant1



Freq. Stability NVNT ac40 5310MHz Ant1



Freq. Stability NVNT ac40 5510MHz Ant1



Freq. Stability NVNT ac40 5670MHz Ant1



Freq. Stability NVNT ac40 5755MHz Ant1



Freq. Stability NVNT ac40 5795MHz Ant1



Freq. Stability NVNT ac80 5210MHz Ant1



Freq. Stability NVNT ac80 5290MHz Ant1




Freq. Stability NVNT ac80 5530MHz Ant1



Freq. Stability NVNT ac80 5610MHz Ant1



Freq. Stability NVNT ac80 5775MHz Ant1



BTF Testing Lab (Shenzhen) Co., Ltd.

F101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street,
Bao'an District, Shenzhen, China

www.btf-lab.com

-- END OF REPORT --