







PSD NVNT n40 5190MHz Ant2





PSD NVNT n40 5230MHz Ant2












PSD NVNT ac20 5180MHz Ant2




PSD NVNT ac20 5240MHz Ant2



PSD NVNT ac20 5260MHz Ant2



PSD NVNT ac20 5320MHz Ant2




PSD NVNT ac20 5500MHz Ant2



PSD NVNT ac20 5700MHz Ant2




PSD NVNT ac20 5745MHz Ant2




PSD NVNT ac20 5825MHz Ant2




PSD NVNT ac40 5190MHz Ant2




PSD NVNT ac40 5230MHz Ant2




PSD NVNT ac40 5270MHz Ant2




PSD NVNT ac40 5310MHz Ant2




PSD NVNT ac40 5510MHz Ant2




PSD NVNT ac40 5670MHz Ant2




PSD NVNT ac40 5755MHz Ant2




PSD NVNT ac40 5795MHz Ant2




PSD NVNT ac80 5210MHz Ant2




PSD NVNT ac80 5290MHz Ant2




PSD NVNT ac80 5530MHz Ant2



PSD NVNT ac80 5610MHz Ant2





PSD NVNT ac80 5775MHz Ant2




PSD NVNT ax160 5250MHz Ant2







PSD NVNT ax20 5240MHz Ant2




PSD NVNT ax20 5260MHz Ant2




PSD NVNT ax20 5320MHz Ant2




PSD NVNT ax20 5500MHz Ant2




PSD NVNT ax20 5700MHz Ant2




PSD NVNT ax20 5745MHz Ant2




PSD NVNT ax20 5825MHz Ant2




PSD NVNT ax40 5190MHz Ant2




PSD NVNT ax40 5230MHz Ant2



PSD NVNT ax40 5270MHz Ant2




PSD NVNT ax40 5310MHz Ant2




PSD NVNT ax40 5510MHz Ant2




PSD NVNT ax40 5670MHz Ant2




PSD NVNT ax40 5755MHz Ant2




PSD NVNT ax40 5795MHz Ant2




PSD NVNT ax80 5210MHz Ant2




PSD NVNT ax80 5290MHz Ant2




PSD NVNT ax80 5530MHz Ant2



PSD NVNT ax80 5610MHz Ant2



PSD NVNT ax80 5775MHz Ant2



Frequency Stability

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NVNT	a	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NVNT	a	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NVNT	a	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NVNT	a	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NVNT	a	5500	Ant1	5499.96	-40000	-7.27	25	Pass
NVNT	a	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NVNT	a	5745	Ant1	5744.96	-40000	-6.96	25	Pass
NVNT	a	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NVNT	n20	5180	Ant1	5179.96	-40000	-7.72	25	Pass
NVNT	n20	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NVNT	n20	5260	Ant1	5259.94	-60000	-11.41	25	Pass
NVNT	n20	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NVNT	n20	5500	Ant1	5499.98	-20000	-3.64	25	Pass
NVNT	n20	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NVNT	n20	5745	Ant1	5744.94	-60000	-10.44	25	Pass
NVNT	n20	5825	Ant1	5824.92	-80000	-13.73	25	Pass
NVNT	n40	5190	Ant1	5190	0	0	25	Pass
NVNT	n40	5230	Ant1	5230	0	0	25	Pass
NVNT	n40	5270	Ant1	5269.96	-40000	-7.59	25	Pass
NVNT	n40	5310	Ant1	5309.92	-80000	-15.07	25	Pass
NVNT	n40	5510	Ant1	5509.96	-40000	-7.26	25	Pass
NVNT	n40	5670	Ant1	5669.96	-40000	-7.05	25	Pass
NVNT	n40	5755	Ant1	5754.96	-40000	-6.95	25	Pass
NVNT	n40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ac20	5180	Ant1	5179.96	-40000	-7.72	25	Pass
NVNT	ac20	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NVNT	ac20	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NVNT	ac20	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NVNT	ac20	5500	Ant1	5499.94	-60000	-10.91	25	Pass
NVNT	ac20	5700	Ant1	5699.94	-60000	-10.53	25	Pass
NVNT	ac20	5745	Ant1	5744.96	-40000	-6.96	25	Pass
NVNT	ac20	5825	Ant1	5824.94	-60000	-10.3	25	Pass
NVNT	ac40	5190	Ant1	5189.96	-40000	-7.71	25	Pass
NVNT	ac40	5230	Ant1	5229.96	-40000	-7.65	25	Pass
NVNT	ac40	5270	Ant1	5270	0	0	25	Pass
NVNT	ac40	5310	Ant1	5309.92	-80000	-15.07	25	Pass
NVNT	ac40	5510	Ant1	5509.96	-40000	-7.26	25	Pass
NVNT	ac40	5670	Ant1	5669.96	-40000	-7.05	25	Pass
NVNT	ac40	5755	Ant1	5755	0	0	25	Pass
NVNT	ac40	5795	Ant1	5795	0	0	25	Pass
NVNT	ac80	5210	Ant1	5209.92	-80000	-15.36	25	Pass
NVNT	ac80	5290	Ant1	5289.92	-80000	-15.12	25	Pass
NVNT	ac80	5530	Ant1	5530.08	80000	14.47	25	Pass
NVNT	ac80	5610	Ant1	5609.92	-80000	-14.26	25	Pass
NVNT	ac80	5775	Ant1	5774.92	-80000	-13.85	25	Pass
NVNT	ax160	5250	Ant1	5250	0	0	25	Pass
NVNT	ax160	5570	Ant1	5570	0	0	25	Pass
NVNT	ax20	5180	Ant1	5179.96	-40000	-7.72	25	Pass
NVNT	ax20	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NVNT	ax20	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NVNT	ax20	5320	Ant1	5319.98	-20000	-3.76	25	Pass
NVNT	ax20	5500	Ant1	5499.94	-60000	-10.91	25	Pass
NVNT	ax20	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NVNT	ax20	5745	Ant1	5744.96	-40000	-6.96	25	Pass

NVNT	ax20	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NVNT	ax40	5190	Ant1	5189.96	-40000	-7.71	25	Pass
NVNT	ax40	5230	Ant1	5229.96	-40000	-7.65	25	Pass
NVNT	ax40	5270	Ant1	5269.96	-40000	-7.59	25	Pass
NVNT	ax40	5310	Ant1	5310	0	0	25	Pass
NVNT	ax40	5510	Ant1	5510	0	0	25	Pass
NVNT	ax40	5670	Ant1	5669.96	-40000	-7.05	25	Pass
NVNT	ax40	5755	Ant1	5754.96	-40000	-6.95	25	Pass
NVNT	ax40	5795	Ant1	5794.96	-40000	-6.9	25	Pass
NVNT	ax80	5210	Ant1	5209.92	-80000	-15.36	25	Pass
NVNT	ax80	5290	Ant1	5289.92	-80000	-15.12	25	Pass
NVNT	ax80	5530	Ant1	5530	0	0	25	Pass
NVNT	ax80	5610	Ant1	5610	0	0	25	Pass
NVNT	ax80	5775	Ant1	5775	0	0	25	Pass

Test Graphs


Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT a 5260MHz Ant1




Freq. Stability NVNT a 5320MHz Ant1




Freq. Stability NVNT a 5500MHz Ant1




Freq. Stability NVNT a 5700MHz Ant1




Freq. Stability NVNT a 5745MHz Ant1




Freq. Stability NVNT a 5825MHz Ant1




Freq. Stability NVNT n20 5180MHz Ant1




Freq. Stability NVNT n20 5240MHz Ant1




Freq. Stability NVNT n20 5260MHz Ant1




Freq. Stability NVNT n20 5320MHz Ant1




Freq. Stability NVNT n20 5500MHz Ant1




Freq. Stability NVNT n20 5700MHz Ant1




Freq. Stability NVNT n20 5745MHz Ant1




Freq. Stability NVNT n20 5825MHz Ant1




Freq. Stability NVNT n40 5190MHz Ant1




Freq. Stability NVNT n40 5230MHz Ant1




Freq. Stability NVNT n40 5270MHz Ant1




Freq. Stability NVNT n40 5310MHz Ant1




Freq. Stability NVNT n40 5510MHz Ant1




Freq. Stability NVNT n40 5670MHz Ant1




Freq. Stability NVNT n40 5755MHz Ant1




Freq. Stability NVNT n40 5795MHz Ant1




Freq. Stability NVNT ac20 5180MHz Ant1




Freq. Stability NVNT ac20 5240MHz Ant1




Freq. Stability NVNT ac20 5260MHz Ant1




Freq. Stability NVNT ac20 5320MHz Ant1




Freq. Stability NVNT ac20 5500MHz Ant1




Freq. Stability NVNT ac20 5700MHz Ant1




Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5825MHz Ant1




Freq. Stability NVNT ac40 5190MHz Ant1




Freq. Stability NVNT ac40 5230MHz Ant1




Freq. Stability NVNT ac40 5270MHz Ant1




Freq. Stability NVNT ac40 5310MHz Ant1




Freq. Stability NVNT ac40 5510MHz Ant1




Freq. Stability NVNT ac40 5670MHz Ant1




Freq. Stability NVNT ac40 5755MHz Ant1




Freq. Stability NVNT ac40 5795MHz Ant1




Freq. Stability NVNT ac80 5210MHz Ant1




Freq. Stability NVNT ac80 5290MHz Ant1





Freq. Stability NVNT ac80 5530MHz Ant1




Freq. Stability NVNT ac80 5610MHz Ant1







Freq. Stability NVNT ax160 5570MHz Ant1




Freq. Stability NVNT ax20 5180MHz Ant1




Freq. Stability NVNT ax20 5240MHz Ant1




Freq. Stability NVNT ax20 5260MHz Ant1




Freq. Stability NVNT ax20 5320MHz Ant1




Freq. Stability NVNT ax20 5500MHz Ant1





Freq. Stability NVNT ax20 5700MHz Ant1




Freq. Stability NVNT ax20 5745MHz Ant1








Freq. Stability NVNT ax40 5230MHz Ant1




Freq. Stability NVNT ax40 5270MHz Ant1








Freq. Stability NVNT ax40 5670MHz Ant1




Freq. Stability NVNT ax40 5755MHz Ant1







Freq. Stability NVNT ax80 5290MHz Ant1




Freq. Stability NVNT ax80 5530MHz Ant1



Freq. Stability NVNT ax80 5610MHz Ant1



Freq. Stability NVNT ax80 5775MHz Ant1





BTF Testing Lab (Shenzhen) Co., Ltd.

F101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street,
Bao'an District, Shenzhen, China

www.btf-lab.com

-- END OF REPORT --