


4.1.1 Test Result

Mode	Frequency (MHz)	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
a	5180	5179.96	-40000	-7.72	25	Pass
a	5240	5239.94	-60000	-11.45	25	Pass
a	5260	5259.96	-40000	-7.6	25	Pass
a	5320	5319.94	-60000	-11.28	25	Pass
a	5500	5499.94	-60000	-10.91	25	Pass
a	5700	5699.96	-40000	-7.02	25	Pass
a	5745	5744.96	-40000	-6.96	25	Pass
a	5825	5824.96	-40000	-6.87	25	Pass
n20	5180	5179.94	-60000	-11.58	25	Pass
n20	5240	5239.98	-20000	-3.82	25	Pass
n20	5260	5259.98	-20000	-3.8	25	Pass
n20	5320	5319.94	-60000	-11.28	25	Pass
n20	5500	5499.96	-40000	-7.27	25	Pass
n20	5700	5699.96	-40000	-7.02	25	Pass
n20	5745	5744.94	-60000	-10.44	25	Pass
n20	5825	5824.98	-20000	-3.43	25	Pass
n40	5190	5190	0	0	25	Pass
n40	5230	5229.96	-40000	-7.65	25	Pass
n40	5270	5269.92	-80000	-15.18	25	Pass
n40	5310	5309.96	-40000	-7.53	25	Pass
n40	5510	5509.92	-80000	-14.52	25	Pass
n40	5670	5669.96	-40000	-7.05	25	Pass
n40	5755	5754.96	-40000	-6.95	25	Pass
n40	5795	5794.96	-40000	-6.9	25	Pass
ac20	5180	5180	0	0	25	Pass
ac20	5240	5239.96	-40000	-7.63	25	Pass
ac20	5260	5259.98	-20000	-3.8	25	Pass
ac20	5320	5319.94	-60000	-11.28	25	Pass
ac20	5500	5499.94	-60000	-10.91	25	Pass
ac20	5700	5699.94	-60000	-10.53	25	Pass
ac20	5745	5744.96	-40000	-6.96	25	Pass
ac20	5825	5824.96	-40000	-6.87	25	Pass
ac40	5190	5189.96	-40000	-7.71	25	Pass
ac40	5230	5230	0	0	25	Pass
ac40	5270	5270	0	0	25	Pass
ac40	5310	5309.96	-40000	-7.53	25	Pass
ac40	5510	5509.96	-40000	-7.26	25	Pass
ac40	5670	5669.92	-80000	-14.11	25	Pass
ac40	5755	5754.92	-80000	-13.9	25	Pass
ac40	5795	5794.96	-40000	-6.9	25	Pass
ac80	5210	5209.92	-80000	-15.36	25	Pass
ac80	5290	5290	0	0	25	Pass
ac80	5530	5529.92	-80000	-14.47	25	Pass
ac80	5610	5609.92	-80000	-14.26	25	Pass
ac80	5775	5774.92	-80000	-13.85	25	Pass
ax160	5250	5250.16	0	0	25	Pass
ax160	5570	5570	160000	0	25	Pass
ax20	5180	5179.96	-40000	-7.72	25	Pass
ax20	5240	5239.98	-20000	-3.82	25	Pass
ax20	5260	5260	0	0	25	Pass
ax20	5320	5319.98	-20000	-3.76	25	Pass
ax20	5500	5500	0	0	25	Pass
ax20	5700	5699.96	-40000	-7.02	25	Pass
ax20	5745	5744.96	-40000	-6.96	25	Pass


ax20	5825	5824.96	-40000	-6.87	25	Pass
ax40	5190	5189.96	-40000	-7.71	25	Pass
ax40	5230	5229.96	-40000	-7.65	25	Pass
ax40	5270	5269.96	-40000	-7.59	25	Pass
ax40	5310	5310	0	0	25	Pass
ax40	5510	5509.96	-40000	-7.26	25	Pass
ax40	5670	5670	0	0	25	Pass
ax40	5755	5754.96	-40000	-6.95	25	Pass
ax40	5795	5794.96	-40000	-6.9	25	Pass
ax80	5210	5210.08	80000	15.36	25	Pass
ax80	5290	5290	0	0	25	Pass
ax80	5530	5529.92	-80000	-14.47	25	Pass
ax80	5610	5610.08	80000	14.26	25	Pass
ax80	5775	5775	0	0	25	Pass

4.1.2 Test Graph


Test Graphs
Freq. Stability NVNT a 5180MHz Ant1




Freq. Stability NVNT a 5240MHz Ant1




Freq. Stability NVNT a 5260MHz Ant1




Freq. Stability NVNT a 5320MHz Ant1




Freq. Stability NVNT a 5500MHz Ant1




Freq. Stability NVNT a 5700MHz Ant1



Freq. Stability NVNT a 5745MHz Ant1




Freq. Stability NVNT a 5825MHz Ant1




Freq. Stability NVNT n20 5180MHz Ant1




Freq. Stability NVNT n20 5240MHz Ant1




Freq. Stability NVNT n20 5260MHz Ant1




Freq. Stability NVNT n20 5320MHz Ant1




Freq. Stability NVNT n20 5500MHz Ant1




Freq. Stability NVNT n20 5700MHz Ant1



Freq. Stability NVNT n20 5745MHz Ant1




Freq. Stability NVNT n20 5825MHz Ant1



Freq. Stability NVNT n40 5190MHz Ant1




Freq. Stability NVNT n40 5230MHz Ant1




Freq. Stability NVNT n40 5270MHz Ant1




Freq. Stability NVNT n40 5310MHz Ant1



Freq. Stability NVNT n40 5510MHz Ant1




Freq. Stability NVNT n40 5670MHz Ant1



Freq. Stability NVNT n40 5755MHz Ant1




Freq. Stability NVNT n40 5795MHz Ant1



Freq. Stability NVNT ac20 5180MHz Ant1




Freq. Stability NVNT ac20 5240MHz Ant1




Freq. Stability NVNT ac20 5260MHz Ant1




Freq. Stability NVNT ac20 5320MHz Ant1




Freq. Stability NVNT ac20 5500MHz Ant1




Freq. Stability NVNT ac20 5700MHz Ant1




Freq. Stability NVNT ac20 5745MHz Ant1




Freq. Stability NVNT ac20 5825MHz Ant1



Freq. Stability NVNT ac40 5190MHz Ant1




Freq. Stability NVNT ac40 5230MHz Ant1



Freq. Stability NVNT ac40 5270MHz Ant1




Freq. Stability NVNT ac40 5310MHz Ant1



Freq. Stability NVNT ac40 5510MHz Ant1



Freq. Stability NVNT ac40 5670MHz Ant1



Freq. Stability NVNT ac40 5755MHz Ant1




Freq. Stability NVNT ac40 5795MHz Ant1




Freq. Stability NVNT ac80 5210MHz Ant1




Freq. Stability NVNT ac80 5290MHz Ant1




Freq. Stability NVNT ac80 5530MHz Ant1



Freq. Stability NVNT ac80 5610MHz Ant1




Freq. Stability NVNT ac80 5775MHz Ant1




Freq. Stability NVNT ax160 5250MHz Ant1



Freq. Stability NVNT ax160 5570MHz Ant1




Freq. Stability NVNT ax20 5180MHz Ant1



Freq. Stability NVNT ax20 5240MHz Ant1




Freq. Stability NVNT ax20 5260MHz Ant1




Freq. Stability NVNT ax20 5320MHz Ant1




Freq. Stability NVNT ax20 5500MHz Ant1




Freq. Stability NVNT ax20 5700MHz Ant1




Freq. Stability NVNT ax20 5745MHz Ant1




Freq. Stability NVNT ax20 5825MHz Ant1




Freq. Stability NVNT ax40 5190MHz Ant1



Freq. Stability NVNT ax40 5230MHz Ant1




Freq. Stability NVNT ax40 5270MHz Ant1



Freq. Stability NVNT ax40 5310MHz Ant1




Freq. Stability NVNT ax40 5510MHz Ant1




Freq. Stability NVNT ax40 5670MHz Ant1




Freq. Stability NVNT ax40 5755MHz Ant1




Freq. Stability NVNT ax40 5795MHz Ant1




Freq. Stability NVNT ax80 5210MHz Ant1





Freq. Stability NVNT ax80 5290MHz Ant1



Freq. Stability NVNT ax80 5530MHz Ant1





BTF Testing Lab (Shenzhen) Co., Ltd.

F101, 201 and 301, Building 1, Block 2, Tantou Industrial Park, Tantou Community, Songgang Street,
Bao'an District, Shenzhen, China

www.btf-lab.com

-- END OF REPORT --