

**TECNO**


**TECNO PHANTOM**  
**V PEN**

User Manual

Active Pen  
Model: TCP02

# About Your Active Pen

\* The active pen can only be used on the inner screen of the mobile phone. As the main screen of the foldable device employs a precision mechanism, please avoid pressing firmly on the main screen with the active pen.




1. Indicator
2. Upper Button
3. Lower Button
4. Replaceable Pen Tip (Rotate to Remove)

# Charge

Connect the active pen to a power outlet using the included USB data cable and power adapter, or connect the active pen to a USB port on your computer via the USB data cable.

Please use the original TECNO USB data cable and power adapter. Any device damage caused by using non-original charging accessories will void the warranty.



# Connection Method

1. The active pen needs to be charged and activated for the first time. Connect the active pen to your mobile phone via Bluetooth.
2. If the active pen is not connected to the mobile phone during the first charge, slide the active pen across the inner screen of your mobile phone. The phone will display a connection pop-up window. Tap Connect to connect the active pen.

## Resetting the Active Pen

Press and hold the upper button on the active pen for **8 seconds** to reset it.

# **Overvoltage Protection (Solid Orange Light)**

This product has an overvoltage protection feature to protect you and your device. When the charger detects an input voltage exceeding the preset safe range, it automatically activates the overvoltage protection. An indicator light may flash orange, indicating the overvoltage status.

In this case, immediately unplug the charger and check if the voltage from the power outlet is normal. Long-time abnormal voltage may damage the charger and even pose a fire risk. If the voltage returns to normal, you can re-insert the charger and continue using it. If the issue persists, please stop using it and contact our customer support for further assistance.

# FCC Caution:

## **Labeling requirements.**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

## **Information to user.**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## **Information to the user.**

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

#### RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.