


WIRELESS SENSOR (outdoor sensor)



1. Battery compartment
2. **TX**: Searches for weather station
3. Channel switch
4. Open the battery compartment.

GETTING STARTED

INSTALL BATTERIES IN MAIN UNIT

1. Remove the battery compartment cover.
2. Insert the 2x AA batteries, matching the polarities.

WIRELESS SENSOR

The main unit can collect data from up to 3 sensors.


To set up the sensor:

1. Open the battery compartment.
2. Slide the channel switch to select a channel.
3. Press **TX** after each battery change.


3. Close the battery door.

4. Place the sensor with in 30m(98ft) of the main unit.

TIP Ideal placements for the sensor would be in any location on the exterior of the home at a height of not more than 1.5m (5ft) and which can shield it from direct sunlight or wet conditions for an accurate reading.



NOTE

- Use alkaline batteries for longer usage and consumer grade lithium batteries in temperatures below freezing.
- Replace the batteries when  displays, or when the display backlight is dim.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

FCC compliance statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.