

# notion


Quick Start  
Guide



01

Plug the bridge into any centrally located power outlet.

Your new bridge needs some juice to wake up from its nap before you get started.



02

Download the  
Notion app.



Visit the Apple App Store, the Google Play Store,  
or [getnotion.com/app](https://getnotion.com/app) to download the Notion  
app on your smartphone.



03

## Register your account.

Sign up and follow the instructions to set up your Notion sensors.



04

## Stay connected to your home.

Set up custom alerts tailored to your home.  
Let Notion focus on the little stuff, so you  
can focus on the things you love.

# Need help?

Call us at (877) 668-4660  
Email us at [support@getnotion.com](mailto:support@getnotion.com)  
Tweet us @notion



Box may contain equipment pertaining to:  
FCC ID: 2AESC-5280-S1 and IC: 20391-5280S1 | FCC ID: 2AESC-5280-B1 and IC: 20391-5280B1

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC and IC RF (Radio Frequency) exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum separation distance of 20 centimeters between the device/antenna and the user's head/body.

**Caution:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

*Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

CAN ICES-3 (B)/NMB-3(B)

In order to comply with the maximum permissible exposure (MPE) limit for radio frequency (RF) energy allowed by both the FCC and IC, the bridge must be placed no closer than 20 cm to the operator during normal operation placed no closer than 20 cm to the operator during normal operation

Afin de se conformer à l'exposition tolérée (EMT) limite maximale pour la fréquence radio (RF) a permis à la fois par la FCC et IC, le pont doit être placé pas moins de 20 cm à l'opérateur pendant le fonctionnement normal.

Happy  
Monitoring!