

WALKIE TALKIE PHONES



2 PACK



6+


- 120 FOOT RANGE
- 2 WAY COMMUNICATION
- BATTERIES INCLUDED

USES 4X AG13 / LR441.5 BUTTON CELL BATTERIES (INCLUDED)

WALKIE TALKIE PHONES


FCC ID: 2AE6BT-5024
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.



↑ Pull the antenna for better range and clarity

Speaker

ON/OFF SWITCH When button is pressed down, Walkie Talkie is ON.



Uses 4 AG13 / LR441.5 button cell (Included)

⚠ WARNING:
CHOKING HAZARD – SMALL PARTS.
NOT FOR CHILDREN UNDER 3 YEARS.

-Specifications and colors may vary as shown
-Keep this information for any possible correspondence
-Packaging is not a toy. Keep away from children and pets
-All clips, binders, rubber bands, plastic bags and other packing materials are not part of the toy. Remove before giving to child
All Lollipop Toys meet or exceed American toy safety standards
CONFORMS TO ASTM F963-17

Push to talk
Use the talk key button to communicate. When button is pressed you can begin speaking. Let go of button when done speaking.

Note: When button is pressed, person at other end will not be able to speak to you. Release talk button in order to listen.

WALKIE TALKIE INSTRUCTIONS:

To replace the battery for the Walkie Talkie:

1. Remove the screw on the battery door with a screwdriver.
2. Open the battery door and insert 4 AG13.LR44 1.5V batteries with the correct polarity into the battery compartment.
3. Replace the battery door and screw it into position.

WALKIE TALKIE OPERATION:

1. Push the ON/OFF switch to ON position.
2. Place walkie talkie earphone near ear and microphone 2-3 inches from mouth for maximum clarity.
3. Press the Push to Talk button to transmit when you speak into the microphone.
4. Release the Push to Talk button when you have finished speaking.
5. Turn the ON/OFF switch to OFF position when you are not using the Walkie Talkie.

USER MANUAL

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
----Reorient or relocate the receiving antenna.
----Increase the separation between the equipment and receiver.
----Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
----Consult the dealer or an experienced radio/TV technician for help.

