

SELF CAMERA MONOPOD SPECIFICATION:

- 1.Bluetooth V3.0, low power consumption, highspeed without delay;
- 2.Compatible with IOS and Android dual system;
- 3 automatic default system, no need to switch Android or IOS system;
- 4.Do not need to install the APP;
- 5.Distance:10m;
- 6.Working frequency: 2.402-2.480GHz, work mode: GFSK;
- 7.Working current: 1mA (primary dormancy 0.5mA)
- 8.Working voltage: 3 V to 4.2 V
- 9.Working temperature: - 10-55 degrees;
- 10.Work humidity: 10% to 70%;
- 11.Battery: 100mA Lithium batteries;



**SELF CAMERA MONOPOD**

1. CELLPHONE HOLDER
4. FOCUS ENARGE KEY
7. 1/4 SCREW

My selftimer Use method:

- 1.Open:short press the power switch, LED lights up, after 1second, the green LED lights down;
- 2.Paired / online:
- 2.1 Press the Camera key for 2 seconds, the green LED is flashing , the device is pairing mode;
- 2.2 Open mobile phone search Bluetooth device, the bluetooth device is self timer-03;
- 2.3 Click the self timer-03 link of Bluetooth devices;Wait for 8 seconds, when the green LED is constant lighting, they are paring successful;
- 3.Photos: light press the photo keys, photo is complete.
- 4:4 Focal length setting: long press "+" button to enlarge the focal length, long press "-" key to narrow the focus;
- 5.Power off: press 3 seconds power key;
- 6.Charging: The MIRCO USB interface is at the bottom of the selftimer, when you charge it, and the red LED is lighting.

2. STELL MONOPOD
5. FOCUS NARROW KEY1
3. CAMERA KEY
6. POWER KEY
8. Micro USB Charging
9. Power LED



Use method 1:
 1. Screw up flexible pipe with cellphone fixed mount.
 2. Insert the flexible pipe to remote joystick and fixture.
 3. Put the cellphone connecting the flexed mount.

Use method 2: Method Two
 1. Screw up the cellphone fixed mount with tripod
 2. Put the cellphone connecting the fixed mount.

Not include the tripod

Sleeping mode:

- 1.When the device is not used for 5 minutes, the device is sleeping mode, the bluetooth is discon-necting.
2. Short press the camera key, the device cance the dormant, and connecting the phone automatically.
3. When the cellphone bluetooth and the device is disconnecting, connection again, short press the camera key, the device is connecting automaticilly.

Note: my selftimer support the iOS5.0 above and the android2.3.6above.
 Because the android is open source system,so a little phoner/tablet models may not support remote cameras.

IN THE BOX

1. SELF CAMERA MONOPOD*1
2. USER Manual*1
3. Micro-USB Charging Cable
4. Cellphone Holder

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the

interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.