


# R/C LIGHTED FIRE ENGINE

This fun size 27 mHz Remote Control Fire Engine has working alarm light, headlight & taillight. 3 channel remote control is easy to use, and fun to play with!

#### **HOW IT WORKS:**


- \* Turn the power switch of the Fire Engine to "ON" position, the top alarm will light up.
- \* Press the forward button on the remote control, the car will go forward & turn, and the headlight will on.
- \* Press the backward button on the remote control, the car will move backward & turn, and the tail light will on.
- \* Fire Engine & Remote Control unit use 3 X AA & 1 x 9V battery (both not included) respectively.

## **INSTALLING THE BATTERIES: FIRE ENGINE**



- 1. Remove the battery cover with a screwdriver and insert 3 new AA alkaline batteries correctly as per the illustration above, observing the polarity on the compartment. Close the battery cover.
- 2. Turn the power switch to "ON" position.

#### REMOTE CONTROL



Remove the battery cover with a screwdriver and insert a new 9V battery as per the illustration above, observing the polarity on the compartment. Close the battery cover.

#### **BATTERY CAUTIONS:**

#### IMPORTANT: only adults should replace batteries.

- \* Do not use rechargeable batteries.
- \* Do not attempt to recharge non-rechargeable batteries.
- \* Insert batteries as marked and always follow the toy & battery manufacturer's instructions.
- \* Use only the same or equivalent type of battery as recommended.
- \* Do not short-circuit the supply terminals.
- \* Do not mix old & new batteries. Do not mix different types of batteries, such as alkaline, standard (carbon-zinc), rechargeable (nickel-cadmium).
- \* Always remove exhausted or dead batteries from the product.
- \* Remove batteries from the product before extended storage.

### **WARNINGS:**

#### FCC ID: 2AEJP-SYN-2015

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 16 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

We, Syngergistic Industrial Ltd, hereby declare that this Radio Control Fire Engine is in compliance with the essential requirements and other relevant provisions of Directives 1999/5/EC.







