

AGE 6+


1:14 SCALE



Enjoy your BMW i8 Concept from RadioShack. Please read this user's guide before using your vehicle.

What's Included

- BMW i8 Concept
- Controller
- User's Guide



Features

- REALISTIC DETAIL
- INTERIOR LIGHT AND WORKING HEADLIGHT, TAIL LIGHT
- INDEPENDENT SUSPENSION
- 2.4 GHz REMOTE CONTROL

Specifications

Speed up to 492 ft/min (150m/min)

Control Distance66 ft (20m)

Climbing Angle 10°

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.


BMW i8 Concept

The BMW logo and BMW wordmark are trademarks of BMW AG and used under license

CHOKING HAZARD!
Small parts. Not for children under 3 years.

Install the Controller Battery

1. Turn off the controller.
2. Install one 9V battery (not included), matching the polarity symbols (+ and -) marked inside the battery compartment.



Pair the Controller


Before driving, you must pair the controller and vehicle. To play with more than one BMW at the same time, pair each vehicle separately.

1. Place the controller within 3 ft. (1m) of the vehicle.
2. Turn on the controller and then the vehicle. The controller LED flashes quickly, and turns off when paired.


Note: If pairing fails, turn off the controller and the vehicle, move closer, and then try again.



LED
Flashing = Searching
Off = Paired
Lit = When a driving key is pressed.
Indicates controller battery power




Press the back of car to turn on/off the headlight, tail light and interior light.



Install Batteries in the BMW i8 Concept

1. Turn off the vehicle.
2. Use a coin to turn the battery cover latch to unlock it, then open the battery compartment.
3. Insert five AA batteries (not included) matching the polarity symbols (+ and -) marked inside, and replace the battery cover. Lock the latch.



ON/OFF

Battery Cover Latch

Wheel Alignment

If your vehicle pulls to the left, turn this switch toward **R**; if the vehicle pulls to the right, turn this switch toward **L**.

© 2015 Regal Worldwide Trading LLC. All rights reserved.
RadioShack is a registered trademark used by Regal Worldwide Trading LLC under license of Global Franchising Corporation.

FCC Information

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Safety and Care

- Turn off your vehicle and controller when not in use.
- Not recommended for children under 6 years of age. Adult supervision recommended at all times.
- A nearby CB radio can interfere with your vehicle's control. If this happens, move the vehicle away from the CB radio.
- Do not play with your vehicle in the street.
- Avoid collisions with people and objects.

Battery Notes:

- For best performance use only fresh alkaline batteries of the required size and type. Do not mix old and new batteries, or batteries of different capacities, types or chemistries.
- Remove batteries during longer storage periods.
- Dispose of the old batteries promptly and properly. Do not burn or bury them.



Printed in China
08A15
6001353

AGE 6+

1:14 SCALE



Forward
↑
Stop
↓
Reverse



← Left Straight → Right

Enjoy your Reventón Roadster from RadioShack. Please read this user's guide before using your vehicle.

What's Included

- Reventón Roadster
- Controller
- User's Guide



Features

- REALISTIC DETAIL
- WORKING HEAD AND TAIL LIGHTS
- INDEPENDENT SUSPENSION
- 2.4 GHz REMOTE CONTROL

Specifications

Speed up to 492 ft/min (150m/min)
Control Distance 66 ft (20m)
Climbing Angle 10°

Specifications are subject to change and improvement without notice. Actual product may vary from the images found in this document.


Reventón Roadster

The trademarks, copyrights and design rights associated with the Lamborghini vehicle Reventón Roadster are used under license of Automobili Lamborghini S.p.A., Italy.

CHOKING HAZARD!
Small parts. Not for
children under 3 years.

Install the Controller Battery

1. Turn off the controller.
2. Install one 9V battery (not included), matching the polarity symbols (+ and -) marked inside the battery compartment.



Pair the Controller

Everytime before driving, you must pair the controller and vehicle. To play with more than one Reventón at the same time, pair each vehicle separately.

1. Place the controller within 3 ft. (1m) of the vehicle.
2. Turn on the controller, and then the vehicle. The controller LED flashes quickly, and turns off when paired.

Note: If pairing fails, turn off the controller and the vehicle, move closer, and then try again.



LED

Flashing = Searching
Off = Paired
Lit = When a driving key is pressed.
Indicates controller battery power


Red tail lights turn on when reversing.

Headlights light up automatically when driving forward.



Install Batteries in the Reventón

1. Turn off the vehicle.
2. Use a coin to turn the battery cover latch to unlock it, then open the battery compartment.
3. Insert five AA batteries (not included) matching the polarity symbols (+ and -) marked inside, and replace the battery cover. Lock the latch.



ON/OFF

Battery Cover Latch

Wheel Alignment

If your vehicle pulls to the left, turn this switch toward **R**; if the vehicle pulls to the right, turn this switch toward **L**.

Safety and Care

- Turn off your vehicle and controller when not in use.
- Not recommended for children under 6 years of age. Adult supervision recommended at all times.
- A nearby CB radio can interfere with your vehicle's control. If this happens, move the vehicle away from the CB radio.
- Do not play with your vehicle in the street.
- Avoid collisions with people and objects.

Battery Notes:

- For best performance use only fresh alkaline batteries of the required size and type. Do not mix old and new batteries, or batteries of different capacities, types or chemistries.
- Remove batteries during longer storage periods.
- Dispose of the old batteries promptly and properly. Do not burn or bury them.



FCC Information

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If you cannot eliminate the interference, the FCC requires that you stop using your equipment.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.