


83.5mm

# ring

## Beams Bridge




83.5mm

RIN-MN00001-AP  
 USER MANUAL RING BEAMS BRIDGE ENGLISH V1.0  
 REV: 1.1  
 TOTAL PAGES: 5  
 DATE: 26-Nov-2018  
 APPROVE BY: GIL S. TALANGAR



GIL S. TALANGAR

Tolerance: -1/+1 mm

 <p><b>GPA   GLOBAL</b> INNOVATING SOLUTIONS</p>	<b>Customer:</b> Ring	<b>Style:</b> Ring-18042	<b>Date:</b>
	<b>CAD#:</b>	<b>Size:</b>	<b>Total Rule:</b>
	<b>Material:</b> 105g C2S	<b>Stock:</b>	<b>View:</b>
	<b>Prepress Designer :</b> Dylan	<b>Grain/Flute:</b>	<b>Reference:</b>



## How to set up your Ring Beams Bridge

### Download the Ring app.

The app walks you through setting up and managing your Bridge.

Search for “Ring” in one of the app stores below, or visit: [ring.com/app](http://ring.com/app)



### Grab your Wi-Fi password.


You'll need it to set up your Bridge. Write it down here so it's handy when you need it:



### Choose a good location.

For the best wireless range, place your Bridge near the front of your home, ideally near a window.

Once you've decided on a good spot, plug the provided power supply into an outlet, and connect it to your Bridge with the included USB cable.






## Set up your Bridge in the Ring app.

In the app, tap **Set Up a Device**.

When prompted, select **Beams** and follow the in-app instructions.



## Set up your Ring Beams lights.

Since you have a Ring Beams Bridge, you may have one or more Ring Beams lights. Now that your Bridge is set up, it's time to set up your lights.

To get started, tap **Set Up a Device**, select **Beams**, and follow the instructions in the app or the included manuals.



### Need a little help with setup?

If your in-app setup doesn't go as planned, try these tips:

#### Get your Wi-Fi password just right.

The most common setup issues come from entering the wrong Wi-Fi password. These passwords are case-sensitive, and every little error counts.

### Reboot your router.

If you entered the right password but you're having no luck, try turning your Wi-Fi router off, wait 30 seconds, then turn it back on.

Then, begin setup again in the Ring app.



For additional help, visit: [ring.com/help](http://ring.com/help)

Or give us a call...

**[US 1 800 656 1918](tel:18006561918)**

---

**[Canada 1 855 300 7289](tel:18553007289)**

---

**[Worldwide +1 310 929 7085](tel:+13109297085)**

---

For a list of all our customer support numbers, visit: [ring.com/callus](http://ring.com/callus)

To review your warranty coverage, please visit [www.ring.com/warranty](http://www.ring.com/warranty).

Patents: [www.ring.com/patents](http://www.ring.com/patents)

© 2018 Ring LLC or its affiliates.

RING, ALWAYS HOME, and all related logos are trademarks of Ring LLC or its affiliates.

Last updated: 09/21/18

## FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

• If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION: Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment.

## RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to

provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

## IC:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radio électrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### ***IC RF Exposure statement***

Radiation Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un min